



## **Cisco Aironet 1100 Series Access Point Installation and Configuration Guide**

Cisco IOS Release 12.2(4)JA  
October, 2002

### **Corporate Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 526-4100

Text Part Number: OL-2851-01



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCIP, the Cisco Arrow logo, the Cisco *Powered* Network mark, the Cisco Systems Verified logo, Cisco Unity, Follow Me Browsing, FormShare, iQ Breakthrough, iQ Expertise, iQ FastTrack, the iQ Logo, iQ Net Readiness Scorecard, Networking Academy, ScriptShare, SMARTnet, TransPath, and Voice LAN are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, Discover All That's Possible, The Fastest Way to Increase Your Internet Quotient, and iQuick Study are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherSwitch, Fast Step, GigaStack, Internet Quotient, IOS, IP/TV, LightStream, MGX, MICA, the Networkers logo, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, RateMUX, Registrar, SlideCast, StrataView Plus, Stratm, SwitchProbe, TeleRouter, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0208R)

*Cisco Aironet 1100 Series Access Point Installation and Configuration Guide*  
Copyright © 2002, Cisco Systems, Inc.  
All rights reserved.



<b>Preface</b>	<b>xv</b>
Audience	xv
Purpose	xv
Organization	xv
Conventions	xvii
Related Publications	xix
Obtaining Documentation	xix
World Wide Web	xix
Documentation CD-ROM	xix
Ordering Documentation	xx
Documentation Feedback	xx
Obtaining Technical Assistance	xx
Cisco.com	xx
Technical Assistance Center	xxi
Cisco TAC Web Site	xxi
Cisco TAC Escalation Center	xxii

---

**CHAPTER 1**

<b>Overview</b>	<b>1-1</b>
Features	1-2
Hardware Features	1-2
Single Radio Operation	1-2
Ethernet Port	1-2
Status Indicators	1-3
Power Sources	1-3
UL 2043 Certification	1-4
Anti-Theft Features	1-4
Software Features	1-4
Management Options	1-5
Roaming Client Devices	1-5
Network Configuration Examples	1-6
Root Unit on a Wired LAN	1-6
Repeater Unit that Extends Wireless Range	1-7
Central Unit in an All-Wireless Network	1-8

**CHAPTER 2**

**Installing the Access Point 2-1**

- Safety Information 2-2
  - FCC Safety Compliance Statement 2-2
  - General Safety Guidelines 2-2
- Warnings 2-2
- Unpacking the Access Point 2-3
  - Package Contents 2-3
- Basic Installation Guidelines 2-3
- Before Beginning the Installation 2-4
- Installation Summary 2-4
- Connecting the Ethernet and Power Cables 2-5
  - Connecting to an Ethernet Network with an Inline Power Source 2-6
  - Connecting to an Ethernet Network with Local Power 2-6
  - Powering Up the Access Point 2-7

**CHAPTER 3**

**Configuring the Access Point for the First Time 3-1**

- Before You Start 3-2
  - Resetting the Access Point to Default Settings 3-2
- Obtaining and Assigning an IP Address 3-3
- Connecting to the Access Point Locally 3-3
- Assigning Basic Settings 3-4
  - Default Settings on the Express Setup Page 3-7
- Protecting Your Wireless LAN 3-8
- Using the IP Setup Utility 3-8
  - Obtaining and Installing IPSU 3-8
  - Using IPSU to Find the Access Point's IP Address 3-9
  - Using IPSU to Set the Access Point's IP Address and SSID 3-10
- Assigning an IP Address Using the CLI 3-11
- Using a Telnet Session to Access the CLI 3-11

**CHAPTER 4**

**Using the Web-Browser Interface 4-1**

- Using the Web-Browser Interface for the First Time 4-2
- Using the Management Pages in the Web-Browser Interface 4-2
  - Using Action Buttons 4-3
  - Character Restrictions in Entry Fields 4-5
- Using Online Help 4-5

**CHAPTER 5****Using the Command-Line Interface 5-1**

- IOS Command Modes 5-2
- Getting Help 5-3
- Abbreviating Commands 5-3
- Using no and default Forms of Commands 5-3
- Understanding CLI Messages 5-4
- Using Command History 5-4
  - Changing the Command History Buffer Size 5-4
  - Recalling Commands 5-5
  - Disabling the Command History Feature 5-5
- Using Editing Features 5-5
  - Enabling and Disabling Editing Features 5-5
  - Editing Commands through Keystrokes 5-6
  - Editing Command Lines that Wrap 5-7
- Searching and Filtering Output of show and more Commands 5-8
- Accessing the CLI 5-8
  - Opening the CLI with Telnet 5-8
  - Opening the CLI with Secure Shell 5-9

**CHAPTER 6****Administering the Access Point 6-1**

- Preventing Unauthorized Access to Your Access Point 6-2
- Protecting Access to Privileged EXEC Commands 6-2
  - Default Password and Privilege Level Configuration 6-2
  - Setting or Changing a Static Enable Password 6-3
  - Protecting Enable and Enable Secret Passwords with Encryption 6-4
  - Configuring Username and Password Pairs 6-5
  - Configuring Multiple Privilege Levels 6-6
    - Setting the Privilege Level for a Command 6-6
    - Logging Into and Exiting a Privilege Level 6-7
- Controlling Access Point Access with RADIUS 6-7
  - Default RADIUS Configuration 6-8
  - Configuring RADIUS Login Authentication 6-8
  - Defining AAA Server Groups 6-9
  - Configuring RADIUS Authorization for User Privileged Access and Network Services 6-11
  - Displaying the RADIUS Configuration 6-12
- Configuring the Access Point for Local Authentication and Authorization 6-12
- Configuring the Access Point for Secure Shell 6-13
  - Understanding SSH 6-13

- Configuring SSH 6-14
- Managing the System Time and Date 6-14
  - Understanding the System Clock 6-14
  - Understanding Network Time Protocol 6-15
  - Configuring NTP 6-16
    - Default NTP Configuration 6-17
    - Configuring NTP Authentication 6-17
    - Configuring NTP Associations 6-19
    - Configuring NTP Broadcast Service 6-20
    - Configuring NTP Access Restrictions 6-21
    - Configuring the Source IP Address for NTP Packets 6-23
    - Displaying the NTP Configuration 6-24
  - Configuring Time and Date Manually 6-24
    - Setting the System Clock 6-25
    - Displaying the Time and Date Configuration 6-25
    - Configuring the Time Zone 6-26
    - Configuring Summer Time (Daylight Saving Time) 6-27
- Configuring a System Name and Prompt 6-29
  - Default System Name and Prompt Configuration 6-29
  - Configuring a System Name 6-29
  - Understanding DNS 6-30
    - Default DNS Configuration 6-30
    - Setting Up DNS 6-30
    - Displaying the DNS Configuration 6-31
- Creating a Banner 6-31
  - Default Banner Configuration 6-32
  - Configuring a Message-of-the-Day Login Banner 6-32
  - Configuring a Login Banner 6-33

**CHAPTER 7**

- Configuring Radio Settings 7-1**
  - Disabling and Enabling the Radio Interface 7-2
  - Configuring the Role in Radio Network 7-2
  - Configuring Radio Data Rates 7-3
  - Configuring Radio Transmit Power 7-5
    - Limiting the Power Level for Associated Client Devices 7-5
  - Configuring Radio Channel Settings 7-6
  - Enabling and Disabling World-Mode 7-7
  - Disabling and Enabling Short Radio Preambles 7-7

Configuring Transmit and Receive Antennas	7-8
Disabling and Enabling Aironet Extensions	7-9
Configuring the Ethernet Encapsulation Transformation Method	7-10
Enabling and Disabling Reliable Multicast to Workgroup Bridges	7-10
Enabling and Disabling Public Secure Packet Forwarding	7-11
Configuring the Beacon Period and the DTIM	7-12
Configure RTS Threshold and Retries	7-12
Configuring the Maximum Data Retries	7-13
Configuring the Fragmentation Threshold	7-13

**CHAPTER 8****Configuring Multiple SSIDs 8-1**

Understanding Multiple SSIDs	8-2
Configuring Multiple SSIDs	8-2
Default SSID Configuration	8-3
Creating an SSID	8-3
Using a RADIUS Server to Restrict SSIDs	8-4

**CHAPTER 9****Configuring WEP and WEP Features 9-1**

Understanding WEP	9-2
Configuring WEP and WEP Features	9-2
Creating WEP Keys	9-3
Enabling and Disabling WEP and Enabling TKIP and MIC	9-3
Enabling and Disabling Broadcast Key Rotation	9-4

**CHAPTER 10****Configuring Authentication Types 10-1**

Understanding Authentication Types	10-2
Open Authentication to the Access Point	10-2
Shared Key Authentication to the Access Point	10-2
EAP Authentication to the Network	10-3
MAC Address Authentication to the Network	10-5
Combining MAC-Based, EAP, and Open Authentication	10-5
Configuring Authentication Types	10-6
Default Authentication Settings	10-6
Assigning Authentication Types to an SSID	10-6
Configuring Authentication Holdoffs, Timeouts, and Intervals	10-8
Matching Access Point and Client Device Authentication Types	10-9

**CHAPTER 11**

**Configuring RADIUS Servers 11-1**

- Understanding RADIUS 11-2
- RADIUS Operation 11-2
- Configuring RADIUS 11-4
  - Default RADIUS Configuration 11-4
  - Identifying the RADIUS Server Host 11-4
  - Configuring RADIUS Login Authentication 11-7
  - Defining AAA Server Groups 11-9
  - Configuring RADIUS Authorization for User Privileged Access and Network Services 11-11
  - Starting RADIUS Accounting 11-12
  - Configuring Settings for All RADIUS Servers 11-13
  - Configuring the Access Point to Use Vendor-Specific RADIUS Attributes 11-13
  - Configuring the Access Point for Vendor-Proprietary RADIUS Server Communication 11-14
- Displaying the RADIUS Configuration 11-15

**CHAPTER 12**

**Configuring VLANs 12-1**

- Understanding VLANs 12-2
  - Related Documents 12-3
  - Incorporating Wireless Devices Into VLANs 12-4
- Configuring VLANs 12-4
  - Configuring a VLAN 12-4
  - Using a RADIUS Server to Assign Users to VLANs 12-6
  - Viewing VLANs Configured on the Access Point 12-6
- VLAN Configuration Example 12-7

**CHAPTER 13**

**Configuring QoS 13-1**

- Understanding QoS for Wireless LANs 13-2
  - QoS for Wireless LANs Versus QoS on Wired LANs 13-2
  - Impact of QoS on a Wireless LAN 13-2
  - Precedence of QoS Settings 13-3
- Configuring QoS 13-3
  - Configuration Guidelines 13-4
  - Configuring QoS Using the Web-Browser Interface 13-4
  - Adjusting Radio Traffic Class Definitions 13-8
- QoS Configuration Examples 13-10
  - Prioritizing for Voice Traffic 13-10
  - Prioritizing for Video Traffic 13-12



---

**CHAPTER 14****Configuring Proxy Mobile IP 14-1**

- Understanding Proxy Mobile IP 14-2
  - Overview 14-2
  - Components of a Proxy Mobile IP Network 14-2
  - How Proxy Mobile IP Works 14-3
    - Agent Discovery 14-3
    - Subnet Map Exchange 14-4
    - Registration 14-5
    - Tunneling 14-5
  - Proxy Mobile IP Security 14-6
- Configuring Proxy Mobile IP 14-6
  - Configuration Guidelines 14-6
  - Configuring Proxy Mobile IP on Your Wired LAN 14-7
  - Configuring Proxy Mobile IP on Your Access Point 14-7

---

**CHAPTER 15****Configuring Filters 15-1**

- Understanding Filters 15-2
- Configuring Filters Using the CLI 15-2
- Configuring Filters Using the Web-Browser Interface 15-2
  - Configuring and Enabling MAC Address Filters 15-2
    - Creating a MAC Address Filter 15-3
  - Configuring and Enabling IP Filters 15-5
    - Creating an IP Filter 15-6
  - Configuring and Enabling Ethertype Filters 15-8
    - Creating an Ethertype Filter 15-9

---

**CHAPTER 16****Configuring CDP 16-1**

- Understanding CDP 16-2
- Configuring CDP 16-2
  - Default CDP Configuration 16-2
  - Configuring the CDP Characteristics 16-2
  - Disabling and Enabling CDP 16-3
  - Disabling and Enabling CDP on an Interface 16-4
- Monitoring and Maintaining CDP 16-4

**CHAPTER 17**

**Configuring SNMP 17-1**

- Understanding SNMP 17-2
  - SNMP Versions 17-2
  - SNMP Manager Functions 17-3
  - SNMP Agent Functions 17-3
  - SNMP Community Strings 17-3
  - Using SNMP to Access MIB Variables 17-4
- Configuring SNMP 17-4
  - Default SNMP Configuration 17-5
  - Disabling the SNMP Agent 17-5
  - Configuring Community Strings 17-5
  - Configuring Trap Managers and Enabling Traps 17-7
  - Setting the Agent Contact and Location Information 17-9
  - Using the snmp-server view Command 17-9
  - SNMP Examples 17-9
- Displaying SNMP Status 17-10

**CHAPTER 18**

**Configuring Repeater and Standby Access Points 18-1**

- Understanding Repeater Access Points 18-2
- Configuring a Repeater Access Point 18-3
  - Default Configuration 18-4
  - Guidelines for Repeaters 18-4
  - Setting Up a Repeater 18-4
  - Verifying Repeater Operation 18-5
  - Setting Up a Repeater as a LEAP Client 18-6
- Understanding Hot Standby 18-7
- Configuring a Hot Standby Access Point 18-7

**CHAPTER 19**

**Managing Firmware and Configurations 19-1**

- Working with the Flash File System 19-2
  - Displaying Available File Systems 19-2
  - Setting the Default File System 19-3
  - Displaying Information about Files on a File System 19-3
  - Changing Directories and Displaying the Working Directory 19-4
  - Creating and Removing Directories 19-4
  - Copying Files 19-5
  - Deleting Files 19-5
  - Creating, Displaying, and Extracting tar Files 19-6

Creating a tar File	19-6
Displaying the Contents of a tar File	19-6
Extracting a tar File	19-7
Displaying the Contents of a File	19-8
Working with Configuration Files	19-8
Guidelines for Creating and Using Configuration Files	19-9
Configuration File Types and Location	19-9
Creating a Configuration File by Using a Text Editor	19-10
Copying Configuration Files by Using TFTP	19-10
Preparing to Download or Upload a Configuration File by Using TFTP	19-10
Downloading the Configuration File by Using TFTP	19-11
Uploading the Configuration File by Using TFTP	19-11
Copying Configuration Files by Using FTP	19-12
Preparing to Download or Upload a Configuration File by Using FTP	19-13
Downloading a Configuration File by Using FTP	19-13
Uploading a Configuration File by Using FTP	19-14
Copying Configuration Files by Using RCP	19-15
Preparing to Download or Upload a Configuration File by Using RCP	19-16
Downloading a Configuration File by Using RCP	19-16
Uploading a Configuration File by Using RCP	19-17
Clearing Configuration Information	19-18
Deleting a Stored Configuration File	19-18
Working with Software Images	19-18
Image Location on the Access Point	19-19
tar File Format of Images on a Server or Cisco.com	19-19
Copying Image Files by Using TFTP	19-20
Preparing to Download or Upload an Image File by Using TFTP	19-20
Downloading an Image File by Using TFTP	19-21
Uploading an Image File by Using TFTP	19-22
Copying Image Files by Using FTP	19-23
Preparing to Download or Upload an Image File by Using FTP	19-23
Downloading an Image File by Using FTP	19-24
Uploading an Image File by Using FTP	19-26
Copying Image Files by Using RCP	19-27
Preparing to Download or Upload an Image File by Using RCP	19-27
Downloading an Image File by Using RCP	19-29
Uploading an Image File by Using RCP	19-31
Reloading the Image Using the Web Browser Interface	19-32
Browser HTTP Interface	19-32
Browser TFTP Interface	19-33

**CHAPTER 20**

**Configuring System Message Logging 20-1**

- Understanding System Message Logging 20-2
- Configuring System Message Logging 20-2
  - System Log Message Format 20-2
  - Default System Message Logging Configuration 20-3
  - Disabling and Enabling Message Logging 20-4
  - Setting the Message Display Destination Device 20-5
  - Enabling and Disabling Timestamps on Log Messages 20-6
  - Enabling and Disabling Sequence Numbers in Log Messages 20-6
  - Defining the Message Severity Level 20-7
  - Limiting Syslog Messages Sent to the History Table and to SNMP 20-8
  - Setting a Logging Rate Limit 20-9
  - Configuring UNIX Syslog Servers 20-9
    - Logging Messages to a UNIX Syslog Daemon 20-10
    - Configuring the UNIX System Logging Facility 20-10
- Displaying the Logging Configuration 20-11

**CHAPTER 21**

**Troubleshooting 21-1**

- Checking the Top Panel Indicators 21-2
- Checking Basic Settings 21-4
  - SSID 21-4
  - WEP Keys 21-4
  - Security Settings 21-5
- Resetting to the Default Configuration 21-5
  - Using the MODE Button 21-5
  - Using the Web Browser Interface 21-6
- Reloading the Access Point Image 21-6
  - Using the MODE button 21-6
  - Web Browser Interface 21-7
    - Browser HTTP Interface 21-7
    - Browser TFTP Interface 21-8
- Obtaining the Access Point Image File 21-8
- Obtaining the TFTP Server Software 21-8
  - Activating and Configuring the TFTP Server 21-9

**APPENDIX A****Translated Safety Warnings A-1**

- Dipole Antenna Installation Warning A-2
- Explosive Device Proximity Warning A-3
- Lightning Activity Warning A-4
- Installation Warning A-5
- Circuit Breaker (15A) Warning A-5

**APPENDIX B****Declarations of Conformity and Regulatory Information B-1**

- Manufacturers Federal Communication Commission Declaration of Conformity Statement B-2
  - Department of Communications—Canada B-2
    - Canadian Compliance Statement B-2
  - European Community, Switzerland, Norway, Iceland, and Liechtenstein B-3
    - Declaration of Conformity with Regard to the R&TTE Directive 1999/5/EC B-3
- Declaration of Conformity for RF Exposure B-4
- Guidelines for Operating Cisco Aironet Access Points and Bridges in Japan B-5
  - Japanese Translation B-5
  - English Translation B-5

**APPENDIX C****Channels and Antenna Settings C-1**

- Channels C-2
- Maximum Power Levels C-3

**APPENDIX D****Mounting Instructions D-1**

- Overview D-2
- Mounting on a Horizontal or Vertical Surface D-3
- Mounting on a Suspended Ceiling D-4
- Using the Security Hasp Adapter D-6
- Mounting on a Cubical Wall Partition D-7
- Using the Desktop Holster D-8
- Using the Cable Lock Feature D-9

**APPENDIX E****Protocol Filters E-1****APPENDIX F****Supported MIBs F-1**

- MIB List F-1
- Using FTP to Access the MIB Files F-2

APPENDIX **G** [Access Point Specifications](#) G-1

APPENDIX **H** [Error and Event Messages](#) H-1

INDEX



## Preface

---

### Audience

This guide is for the networking professional who installs and manages the Cisco Aironet 1100 Series Access Point, hereafter referred to as the *access point*. To use this guide, you should have experience working with the Cisco IOS and be familiar with the concepts and terminology of wireless local area networks.

### Purpose

This guide provides the information you need to install and configure your access point. This guide provides procedures for using the IOS commands that have been created or changed for use with the access point. It does not provide detailed information about these commands. For detailed information about these commands, refer to the *Cisco Aironet 1100 Series Access Point Command Reference* for this release. For information about the standard IOS Release 12.2 commands, refer to the IOS documentation set available from the Cisco.com home page at **Service and Support > Technical Documents**. On the Cisco Product Documentation home page, select **Release 12.2** from the Cisco IOS Software drop-down list.

This guide also includes an overview of the access point web-based interface (APWI), which contains all the functionality of the command-line interface (CLI). This guide does not provide field-level descriptions of the APWI windows nor does it provide the procedures for configuring the access point from from the APWI. For all APWI window descriptions and procedures, refer to the access point online help, which is available from the Help buttons on the APWI pages.

### Organization

This guide is organized into these chapters:

[Chapter 1, “Overview,”](#) lists the software and hardware features of the access point and describes the access point’s role in your network.

[Chapter 2, “Installing the Access Point,”](#) describes installing your access point on a desktop, wall, or ceiling, and provides safety warnings and general guidelines.

[Chapter 3, “Configuring the Access Point for the First Time,”](#) describes how to configure basic settings on a new access point.

[Chapter 4, “Using the Web-Browser Interface,”](#) describes how to use the web-browser interface to configure the access point.

[Chapter 5, “Using the Command-Line Interface,”](#) describes how to use the command-line interface (CLI) to configure the access point.

[Chapter 6, “Administering the Access Point,”](#) describes how to perform one-time operations to administer your access point, such as preventing unauthorized access to the access point, setting the system date and time, and setting the system name and prompt.

[Chapter 7, “Configuring Radio Settings,”](#) describes how to configure settings for the access point radio such as the role in the radio network, data rates, transmit power, channel settings, and others.

[Chapter 8, “Configuring Multiple SSIDs,”](#) describes how to configure and manage multiple service set identifiers (SSIDs) on your access point. You can configure up to 16 SSIDs on your access point and assign different configuration settings to each SSID.

[Chapter 9, “Configuring WEP and WEP Features,”](#) describes how to configure Wired Equivalent Privacy (WEP), Message Integrity Check (MIC), Temporal Key Integrity Protocol (TKIP), and broadcast key rotation to protect your wireless LAN.

[Chapter 10, “Configuring Authentication Types,”](#) describes how to configure authentication types on the access point. Client devices use these authentication methods to join your network.

[Chapter 11, “Configuring RADIUS Servers,”](#) describes how to enable and configure the Remote Authentication Dial-In User Service (RADIUS), which provides detailed accounting information and flexible administrative control over authentication and authorization processes.

[Chapter 12, “Configuring VLANs,”](#) describes how to configure your access point to interoperate with the VLANs set up on your wired LAN.

[Chapter 13, “Configuring QoS,”](#) describes how to configure quality of service (QoS) on your access point. With this feature, you can provide preferential treatment to certain traffic at the expense of others.

[Chapter 14, “Configuring Proxy Mobile IP,”](#) describes how to configure your access point’s proxy mobile IP feature. When you enable proxy mobile IP on your access point and on your wired network, the access point helps client devices from other networks remain connected to their home networks.

[Chapter 15, “Configuring Filters,”](#) describes how to configure and manage MAC address, IP, and EtherType filters on the access point using the web-browser interface.

[Chapter 16, “Configuring CDP,”](#) describes how to configure Cisco Discovery Protocol (CDP) on your access point. CDP is a device-discovery protocol that runs on all Cisco network equipment.

[Chapter 17, “Configuring SNMP,”](#) describes how to configure the Simple Network Management Protocol (SNMP) on your access point.

[Chapter 18, “Configuring Repeater and Standby Access Points,”](#) describes how to configure your access point as a hot standby unit or as a repeater unit.

[Chapter 19, “Managing Firmware and Configurations,”](#) describes how to manipulate the Flash file system, how to copy configuration files, and how to archive (upload and download) software images.

[Chapter 20, “Configuring System Message Logging,”](#) describes how to configure system message logging on your access point.

[Chapter 21, “Troubleshooting,”](#) provides troubleshooting procedures for basic problems with the access point.

[Appendix A, “Translated Safety Warnings,”](#) provides translations of the safety warnings that appear in this publication.

[Appendix B, “Declarations of Conformity and Regulatory Information,”](#) provides declarations of conformity and regulatory information for the access point.



[Appendix C, “Channels and Antenna Settings,”](#) lists the access point radio channels and the maximum power levels supported by the world’s regulatory domains.

[Appendix D, “Mounting Instructions,”](#) describes how to mount the access point on a desktop, wall, or ceiling.

[Appendix E, “Protocol Filters,”](#) list some of the protocols that you can filter on the access point.

[Appendix F, “Supported MIBs,”](#) lists the Simple Network Management Protocol (SNMP) Management Information Bases (MIBs) that the access point supports for this software release.

[Appendix G, “Access Point Specifications,”](#) lists technical specifications for the access point.

[Appendix H, “Error and Event Messages,”](#) lists the CLI error and event messages and provides an explanation and recommended action for each message.

## Conventions

This publication uses these conventions to convey instructions and information:

Command descriptions use these conventions:

- Commands and keywords are in boldface text.
- Arguments for which you supply values are in italic.
- Square brackets ([ ]) mean optional elements.
- Braces ({ }) group required choices, and vertical bars (|) separate the alternative elements.
- Braces and vertical bars within square brackets ([{ | }]) mean a required choice within an optional element.

Interactive examples use these conventions:

- Terminal sessions and system displays are in screen font.
- Information you enter is in **boldface screen** font.
- Nonprinting characters, such as passwords or tabs, are in angle brackets (< >).

Notes, cautions, and timesavers use these conventions and symbols:



---

**Tip**

Means the following will help you solve a problem. The tips information might not be troubleshooting or even an action, but could be useful information.

---



---

**Note**

Means reader take note. Notes contain helpful suggestions or references to materials not contained in this manual.

---



---

**Caution**

Means reader be careful. In this situation, you might do something that could result equipment damage or loss of data.

---

**Warning**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. (To see translations of the warnings that appear in this publication, refer to the appendix "Translated Safety Warnings.")

**Waarschuwing**

Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van standaard maatregelen om ongelukken te voorkomen. (Voor vertalingen van de waarschuwingen die in deze publicatie verschijnen, kunt u het aanhangsel "Translated Safety Warnings" (Vertalingen van veiligheidsvoorschriften) raadplegen.)

**Varoitus**

Tämä varoitusmerkki merkitsee vaaraa. Olet tilanteessa, joka voi johtaa ruumiinvammaan. Ennen kuin työskentelet minkään laitteiston parissa, ota selvää sähkökytkentöihin liittyvistä vaaroista ja tavanomaisista onnettomuuksien ehkäisykeinoista. (Tässä julkaisussa esiintyvien varoitusten käännökset löydät liitteestä "Translated Safety Warnings" (käännetyt turvallisuutta koskevat varoitukset).)

**Attention**

Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant entraîner des blessures. Avant d'accéder à cet équipement, soyez conscient des dangers posés par les circuits électriques et familiarisez-vous avec les procédures courantes de prévention des accidents. Pour obtenir les traductions des mises en garde figurant dans cette publication, veuillez consulter l'annexe intitulée « Translated Safety Warnings » (Traduction des avis de sécurité).

**Warnung**

Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu einer Körperverletzung führen könnte. Bevor Sie mit der Arbeit an irgendeinem Gerät beginnen, seien Sie sich der mit elektrischen Stromkreisen verbundenen Gefahren und der Standardpraktiken zur Vermeidung von Unfällen bewusst. (Übersetzungen der in dieser Veröffentlichung enthaltenen Warnhinweise finden Sie im Anhang mit dem Titel "Translated Safety Warnings" (Übersetzung der Warnhinweise).)

**Avvertenza**

Questo simbolo di avvertenza indica un pericolo. Si è in una situazione che può causare infortuni. Prima di lavorare su qualsiasi apparecchiatura, occorre conoscere i pericoli relativi ai circuiti elettrici ed essere al corrente delle pratiche standard per la prevenzione di incidenti. La traduzione delle avvertenze riportate in questa pubblicazione si trova nell'appendice, "Translated Safety Warnings" (Traduzione delle avvertenze di sicurezza).

**Advarsel**

Dette varselsymbolet betyr fare. Du befinner deg i en situasjon som kan føre til personskade. Før du utfører arbeid på utstyr, må du være oppmerksom på de faremomentene som elektriske kretser innebærer, samt gjøre deg kjent med vanlig praksis når det gjelder å unngå ulykker. (Hvis du vil se oversettelser av de advarslene som finnes i denne publikasjonen, kan du se i vedlegget "Translated Safety Warnings" [Oversatte sikkerhetsadvarslar].)

**Aviso**

Este símbolo de aviso indica perigo. Encontra-se numa situação que lhe poderá causar danos físicos. Antes de começar a trabalhar com qualquer equipamento, familiarize-se com os perigos relacionados com circuitos eléctricos, e com quaisquer práticas comuns que possam prevenir possíveis acidentes. (Para ver as traduções dos avisos que constam desta publicação, consulte o apêndice "Translated Safety Warnings" - "Traduções dos Avisos de Segurança").

<b>¡Advertencia!</b>	<b>Este símbolo de aviso significa peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considerar los riesgos que entraña la corriente eléctrica y familiarizarse con los procedimientos estándar de prevención de accidentes. (Para ver traducciones de las advertencias que aparecen en esta publicación, consultar el apéndice titulado "Translated Safety Warnings.")</b>
<b>Varning!</b>	<b>Denna varningssymbol signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanligt förfarande för att förebygga skador. (Se förklaringar av de varningar som förekommer i denna publikation i appendix "Translated Safety Warnings" [Översatta säkerhetsvarningar].)</b>

---

## Related Publications

These documents provide complete information about the access point:

- *Release Notes for 1100 Series Access Points*
- *Cisco Aironet 1100 Series Access Point Command Reference*

Click this link to browse to the Cisco Aironet documentation home page:

<http://www.cisco.com/univercd/cc/td/doc/product/wireless/index.htm>

To browse to the 1100 series access point documentation, select **Aironet 1100 Series Wireless LAN Products > Cisco Aironet 1100 Series Access Points**.

## Obtaining Documentation

The following sections explain how to obtain documentation from Cisco Systems.

### World Wide Web

You can access the most current Cisco documentation on the World Wide Web at this URL:

<http://www.cisco.com>

Translated documentation is available at this URL:

[http://www.cisco.com/public/countries\\_languages.shtml](http://www.cisco.com/public/countries_languages.shtml)

### Documentation CD-ROM

Cisco documentation and additional literature are available in a Cisco Documentation CD-ROM package. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual subscription.

## Ordering Documentation

You can order Cisco documentation in these ways:

- Registered Cisco.com users (Cisco direct customers) can order Cisco product documentation from the Networking Products MarketPlace:  
[http://www.cisco.com/cgi-bin/order/order\\_root.pl](http://www.cisco.com/cgi-bin/order/order_root.pl)
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:  
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco Systems Corporate Headquarters (California, U.S.A.) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

## Documentation Feedback

You can submit comments electronically on Cisco.com. In the Cisco Documentation home page, click the **Fax** or **Email** option in the “Leave Feedback” section at the bottom of the page.

You can e-mail your comments to [bug-doc@cisco.com](mailto:bug-doc@cisco.com).

You can submit your comments by mail by using the response card behind the front cover of your document or by writing to the following address:

Cisco Systems  
Attn: Document Resource Connection  
170 West Tasman Drive  
San Jose, CA 95134-9883

We appreciate your comments.

## Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain online documentation, troubleshooting tips, and sample configurations from online tools by using the Cisco Technical Assistance Center (TAC) Web Site. Cisco.com registered users have complete access to the technical support resources on the Cisco TAC Web Site.

## Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information, networking solutions, services, programs, and resources at any time, from anywhere in the world.

Cisco.com is a highly integrated Internet application and a powerful, easy-to-use tool that provides a broad range of features and services to help you with these tasks:

- Streamline business processes and improve productivity
- Resolve technical issues with online support
- Download and test software packages

- Order Cisco learning materials and merchandise
- Register for online skill assessment, training, and certification programs

If you want to obtain customized information and service, you can self-register on Cisco.com. To access Cisco.com, go to this URL:

<http://www.cisco.com>

## Technical Assistance Center

The Cisco Technical Assistance Center (TAC) is available to all customers who need technical assistance with a Cisco product, technology, or solution. Two levels of support are available: the Cisco TAC Web Site and the Cisco TAC Escalation Center.

Cisco TAC inquiries are categorized according to the urgency of the issue:

- Priority level 4 (P4)—You need information or assistance concerning Cisco product capabilities, product installation, or basic product configuration.
- Priority level 3 (P3)—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- Priority level 2 (P2)—Your production network is severely degraded, affecting significant aspects of business operations. No workaround is available.
- Priority level 1 (P1)—Your production network is down, and a critical impact to business operations will occur if service is not restored quickly. No workaround is available.

The Cisco TAC resource that you choose is based on the priority of the problem and the conditions of service contracts, when applicable.

## Cisco TAC Web Site

You can use the Cisco TAC Web Site to resolve P3 and P4 issues yourself, saving both cost and time. The site provides around-the-clock access to online tools, knowledge bases, and software. To access the Cisco TAC Web Site, go to this URL:

<http://www.cisco.com/tac>

All customers, partners, and resellers who have a valid Cisco service contract have complete access to the technical support resources on the Cisco TAC Web Site. The Cisco TAC Web Site requires a Cisco.com login ID and password. If you have a valid service contract but do not have a login ID or password, go to this URL to register:

<http://www.cisco.com/register/>

If you are a Cisco.com registered user, and you cannot resolve your technical issues by using the Cisco TAC Web Site, you can open a case online by using the TAC Case Open tool at this URL:

<http://www.cisco.com/tac/caseopen>

If you have Internet access, we recommend that you open P3 and P4 cases through the Cisco TAC Web Site.

## Cisco TAC Escalation Center

The Cisco TAC Escalation Center addresses priority level 1 or priority level 2 issues. These classifications are assigned when severe network degradation significantly impacts business operations. When you contact the TAC Escalation Center with a P1 or P2 problem, a Cisco TAC engineer automatically opens a case.

To obtain a directory of toll-free Cisco TAC telephone numbers for your country, go to this URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Before calling, please check with your network operations center to determine the level of Cisco support services to which your company is entitled: for example, SMARTnet, SMARTnet Onsite, or Network Supported Accounts (NSA). When you call the center, please have available your service agreement number and your product serial number.



## Overview

---

Cisco Aironet 1100 Series Access Points (hereafter called *access points*) provide a secure, affordable, and easy-to-use wireless LAN solution that combines mobility and flexibility with the enterprise-class features required by networking professionals. With a management system based on Cisco IOS software, the 1100 series is a Wi-Fi certified, 802.11b-compliant wireless LAN transceiver. The 1100 series access point uses a single mini-PCI radio that can be upgraded to future radio technologies such as 802.11g.

The access point serves as the connection point between wireless and wired networks or as the center point of a stand-alone wireless network. In large installations, wireless users within radio range of an access point can roam throughout a facility while maintaining seamless, uninterrupted access to the network.

You can configure and monitor the access point using the command-line interface (CLI), the browser-based management system, or Simple Network Management Protocol (SNMP).

This chapter provides information on the following topics:

- [Features, page 1-2](#)
- [Management Options, page 1-5](#)
- [Roaming Client Devices, page 1-5](#)
- [Network Configuration Examples, page 1-6](#)

# Features

This section describes access point features. Refer to [Appendix G, “Access Point Specifications,”](#) for a list of access point specifications.


## Hardware Features

Key hardware features of the 1100 series access point include:

- [Single Radio Operation, page 1-2](#)
- [Ethernet Port, page 1-2](#)
- [Status Indicators, page 1-3](#)
- [Power Sources, page 1-3](#)
- [UL 2043 Certification, page 1-4](#)
- [Anti-Theft Features, page 1-4](#)

[Figure 1-1](#) shows the location of some of the hardware features.

**Figure 1-1 Access Point Layout and Connectors**



1	48 VDC power port	4	Mode button
2	Ethernet port (RJ-45)	5	Status LEDs
3	Cable lock slot	6	Antenna

## Single Radio Operation

The access point contains a 2.4-GHz radio in a mini-PCI slot and two 2.2-dBi dipole integrated antennas. You can perform a field upgrade to the mini-PCI radio and antennas to support future radio technologies.

## Ethernet Port

The auto-sensing Ethernet port accepts an RJ-45 connector, linking the access point to your 10BASE-T or 100BASE-T Ethernet LAN. The access point can receive power through the Ethernet cable from a power injector, switch, or power patch panel. The Ethernet MAC address is printed on the label on the back of the access point.




## Status Indicators

The three indicators on the top of the access point report Ethernet activity, association status, and radio activity.

- The Ethernet indicator signals Ethernet traffic on the wired LAN, or Ethernet infrastructure. This indicator is normally green when an Ethernet cable is connected, and blinks green when a packet is received or transmitted over the Ethernet infrastructure. The indicator is off when the Ethernet cable is not connected.
- The status indicator signals operational status. Steady green indicates that the access point is associated with at least one wireless client. Blinking green indicates that the access point is operating normally but is not associated with any wireless devices.
- The radio indicator signals wireless traffic over the radio interface. The light is normally off, but it blinks green whenever a packet is received or transmitted over the access point radio.

Figure 1-2 shows the three status indicators.

**Figure 1-2 Access Point Indicators**



## Power Sources

The access point draws up to 4.9W of DC power and can receive power from an external power module or through inline power using the Ethernet cable. Using inline power, you do not need to run a separate power cord to the access point. The access point supports the following power sources:

- Power supply (input 100–240 VAC, 50–60 Hz, output 48 VDC, 0.2A minimum)
- Inline power from:
  - Cisco Aironet Power Injector for 1100 and 1200 series access points
  - A switch capable of providing inline power, such as the Cisco Catalyst 3500XL, 3550, 4000, or 6500
  - An inline power patch panel, such as the Cisco Catalyst Inline Power Patch Panel

## UL 2043 Certification

The access point is encased in a durable plastic enclosure having adequate fire resistance and low smoke-producing characteristics suitable for operation in a building's environmental air space, such as above suspended ceilings, in accordance with Section 300-22(c) of the NEC, and with Sections 2-128, 12-010(3) and 12-100 of the *Canadian Electrical Code*, Part 1, C22.1.

## Anti-Theft Features

There are two methods of securing the access point to help prevent theft:

- Security cable keyhole—You can use the security cable slot to secure the access point using a standard security cable, such as those used on laptop computers.
- Security hasp—When you mount the access point on a wall or ceiling using the mounting bracket and the security hasp, you can lock the access point to the bracket with a padlock. Compatible padlocks are Master Lock models 120T and 121T or equivalent.

## Software Features

In addition to all the standard access point features, 1100 series access points also offer these software features:

- World mode—Use this feature to communicate the access point's regulatory setting information, including maximum transmit power and available channels, to world mode-enabled clients. Clients using world mode can be used between countries with different regulatory settings and automatically conform to local regulations.
- Repeater mode—Configure the access point as a wireless repeater to extend the coverage area of your wireless network.
- Standby mode—Configure the access point as a standby unit that monitors another access point and assumes its role in the network if the monitored access point fails.
- Multiple SSIDs—Create up to 16 SSIDs on your access point and assign any combination of these settings to each SSID:
  - Broadcast SSID mode for guests on your network
  - Client authentication methods
  - Maximum number of client associations
  - VLAN identifier
  - Proxy Mobile IP
  - RADIUS accounting list identifier
  - A separate SSID for infrastructure devices such as repeaters and workgroup bridges
- VLANs—Assign VLANs to the SSIDs on your access point (one VLAN per SSID) to differentiate policies and services between users.
- QoS—Use this feature to support quality of service for prioritizing traffic from the Ethernet to the access point. The access point also supports the voice-prioritization schemes used by 802.11b wireless phones such as Spectralink's Netlink™ and Symbol's Netvision™.
- Proxy Mobile IP—Use this feature to configure the access point to provide proxy mobile IP service for clients that do not have mobile IP software installed.

- RADIUS Accounting—Enable accounting on the access point to send accounting data about wireless client devices to a RADIUS server on your network.
- Enhanced security—Enable three advanced security features to protect against sophisticated attacks on your wireless network's WEP keys: Message Integrity Check (MIC), WEP key hashing, and broadcast WEP key rotation.
- Enhanced authentication services—Set up repeater access points to authenticate to your network like other wireless client devices. After you provide a network username and password for the repeater, it authenticates to your network using LEAP, Cisco's wireless authentication method, and receives and uses dynamic WEP keys.

## Management Options

You can use the access point management system through the following interfaces:

- The IOS command-line interface (CLI), which you use through a Telnet session. Most of the examples in this manual are taken from the CLI. [Chapter 5, “Using the Command-Line Interface,”](#) provides a detailed description of the CLI.
- A web-browser interface, which you use through a web browser. [Chapter 4, “Using the Web-Browser Interface,”](#) provides a detailed description of the web-browser interface.
- Simple Network Management Protocol (SNMP). [Chapter 17, “Configuring SNMP,”](#) explains how to configure your access point for SNMP management.

## Roaming Client Devices

If you have more than one access point in your wireless LAN, wireless client devices can roam seamlessly from one access point to another. The roaming functionality is based on signal quality, not proximity. When a client's signal quality drops, it roams to another access point.

Wireless LAN users are sometimes concerned when a client device stays associated to a distant access point instead of roaming to a closer access point. However, if a client's signal to a distant access point remains strong and the signal quality is high, the client will not roam to a closer access point. Checking constantly for closer access points would be inefficient, and the extra radio traffic would slow throughput on the wireless LAN.


# Network Configuration Examples

This section describes the access point's role in three common wireless network configurations. The access point's default configuration is as a root unit connected to a wired LAN or as the central unit in an all-wireless network. The repeater role requires a specific configuration.

## Root Unit on a Wired LAN

An access point connected directly to a wired LAN provides a connection point for wireless users. If more than one access point is connected to the LAN, users can roam from one area of a facility to another without losing their connection to the network. As users move out of range of one access point, they automatically connect to the network (associate) through another access point. The roaming process is seamless and transparent to the user. [Figure 1-3](#) shows access points acting as root units on a wired LAN.

**Figure 1-3** Access Points as Root Units on a Wired LAN



86301


## Repeater Unit that Extends Wireless Range

An access point can be configured as a stand-alone repeater to extend the range of your infrastructure or to overcome an obstacle that blocks radio communication. The repeater forwards traffic between wireless users and the wired LAN by sending packets to either another repeater or to an access point connected to the wired LAN. The data is sent through the route that provides the best performance for the client. [Figure 1-4](#) shows an access point acting as a repeater. Consult the [“Configuring a Repeater Access Point”](#) section on page 18-3 for instructions on setting up an access point as a repeater.

**Note**

Non-Cisco client devices might have difficulty communicating with repeater access points.


**Figure 1-4** Access Point as Repeater



## Central Unit in an All-Wireless Network

In an all-wireless network, an access point acts as a stand-alone root unit. The access point is not attached to a wired LAN; it functions as a hub linking all stations together. The access point serves as the focal point for communications, increasing the communication range of wireless users. [Figure 1-5](#) shows an access point in an all-wireless network.

**Figure 1-5** Access Point as Central Unit in All-Wireless Network





## Installing the Access Point

---

This chapter describes the setup of the access point and includes the following sections:

- [Safety Information, page 2-2](#)
- [Warnings, page 2-2](#)
- [Basic Installation Guidelines, page 2-3](#)
- [Unpacking the Access Point, page 2-3](#)
- [Before Beginning the Installation, page 2-4](#)
- [Installation Summary, page 2-4](#)
- [Connecting the Ethernet and Power Cables, page 2-5](#)

# Safety Information

Follow the guidelines in this section to ensure proper operation and safe use of the access point.

## FCC Safety Compliance Statement

The FCC with its action in ET Docket 96-8 has adopted a safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC certified equipment. When used with approved Cisco Aironet antennas, Cisco Aironet products meet the uncontrolled environmental limits found in OET-65 and ANSI C95.1, 1991. Proper installation of this radio according to the instructions found in this manual will result in user exposure that is substantially below the FCC recommended limits.

## General Safety Guidelines

- Do not touch or move antenna(s) while the unit is transmitting or receiving.
- Do not hold any component containing a radio so that the antenna is very close to or touching any exposed parts of the body, especially the face or eyes, while transmitting.
- The use of wireless devices in hazardous locations is limited to the constraints posed by the local codes, the national codes, and the safety directors of such environments.

## Warnings

Translated versions of the following safety warnings are provided in [Appendix A, “Translated Safety Warnings.”](#)



Warning

**In order to comply with FCC radio frequency (RF) exposure limits, dipole antennas should be located at a minimum of 7.9 inches (20 cm) or more from the body of all persons.**



Warning

**Do not operate your wireless network device near unshielded blasting caps or in an explosive environment unless the device has been modified to be especially qualified for such use.**



Warning

**Do not work on the system or connect or disconnect cables during periods of lightning activity.**



Warning

**Read the installation instructions before you connect the system to its power source.**



Warning

**This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that a fuse or circuit breaker no larger than 120 VAC, 15A U.S. (240 VAC, 10A international) is used on the phase conductors (all current-carrying conductors).**



# Unpacking the Access Point

Follow these steps to unpack the access point:

- 
- Step 1** Open the shipping container and carefully remove the contents.
  - Step 2** Return all packing materials to the shipping container and save it.
  - Step 3** Ensure that all items listed in the “Package Contents” section are included in the shipment. Check each item for damage. If any item is damaged or missing, notify your authorized Cisco sales representative.
- 

## Package Contents

Each access point package contains the following items:

- Access point power pack
- Wall or ceiling mounting bracket
- Security hasp adapter
- Cubical partition mounting bracket assembly
- Horizontal surface mounting holster
- Mounting hardware kit
- Product registration card

## Basic Installation Guidelines


Because the access point is a radio device, it is susceptible to common causes of interference that can reduce throughput and range. Follow these basic guidelines to ensure the best possible performance:

- Install the access point in an area where large steel structures such as shelving units, bookcases, and filing cabinets do not block the radio signals to and from the access point.
- Install the access point away from microwave ovens. Microwave ovens operate on the same frequency as the access point and can cause signal interference.

## Before Beginning the Installation

Before you begin the installation process, please refer to [Figure 2-1](#) to familiarize yourself with the access point's layout, features, and connectors.

**Figure 2-1** Access Point Layout and Connectors



<b>1</b>	48 VDC power port	<b>4</b>	Mode button
<b>2</b>	Ethernet port (RJ-45)	<b>5</b>	Status LEDs
<b>3</b>	Cable lock slot	<b>6</b>	Antenna

## Installation Summary


During the installation of the access point, you need to perform the following operations:

- Connect Ethernet and power cables (refer to the [“Connecting the Ethernet and Power Cables”](#) section on page 2-5).
- Configure basic settings (refer to [Chapter 3, “Configuring the Access Point for the First Time”](#)).
- Configure security and other access point options.
- Use the mounting brackets or docking cradle to locate the access point on a convenient flat horizontal or vertical surface, such as a desktop, book shelf, file cabinet, cubicle wall, room wall, or the room ceiling. For additional information, refer to [Appendix D, “Mounting Instructions.”](#)

# Connecting the Ethernet and Power Cables

The access point receives power through the Ethernet cable or an external power module. [Figure 2-2](#) shows the power options for the access point.

**Figure 2-2 Access Point Power Options**



The access point power options are listed below:

- A switch with inline power, such as a Cisco Catalyst 3500XL, 3550, 4000, or 6500 switch
- An inline power patch panel, such as a Cisco Catalyst Inline Power Patch Panel
- A power injector
- A power module (Universal power supply)



**Note**

If you use in-line power from a switch or patch panel, do not connect the power module to the access point. Using two power sources on the access point might cause the switch or patch panel to shut down the port to which the access point is connected.

## Connecting to an Ethernet Network with an Inline Power Source

Follow these steps to connect the access point to the Ethernet LAN when you have an inline power source:

- 
- Step 1** Connect the Ethernet cable to the RJ-45 Ethernet connector labeled *Ethernet* on the access point.
- Step 2** Connect the other end of the Ethernet cable to one of the following:
- A switch with inline power, such as a Cisco Catalyst 3500XL, 3550, 4000, or 6500 switch.
  - An inline power switch panel, such as a Cisco Catalyst Inline Power Patch Panel.
  - The end of a Cisco Aironet power injector labeled *To AP/Bridge*. Connect the other end labeled *To Network* to the 10/100 Ethernet LAN.
- 

**Caution**

The Cisco Aironet Power Injector for the 1100 and 1200 series is designed for use with 1100 series or 1200 series access points only. Using the power injector with other Ethernet-ready devices can damage the equipment.

---

**Caution**

The Cisco Aironet Power Injector for the 1100 and 1200 series is not tested to UL 2043 and should not be placed in a building's environmental air space, such as above suspended ceilings.

---

**Note**

If you use a power supply or power injector to power the access point, you must use the power supply included with your access point and the Cisco Aironet Power Injector for the 1100 and 1200 series access points.

---

## Connecting to an Ethernet Network with Local Power

Follow these steps to connect the access point to an Ethernet LAN when you are using a local power source:

- 
- Step 1** Connect the Ethernet cable to the RJ-45 Ethernet connector labeled *Ethernet* on the access point.
- Step 2** Plug the other end of the Ethernet cable into an unpowered Ethernet port on your network.
- Step 3** Connect the power module's output connector to the 48-VDC power port labeled *48VDC* on the access point.
- Step 4** Plug the other end of the power module into an approved 100- to 240-VAC outlet.
-

## Powering Up the Access Point

When power is applied to the access point, it begins a routine power-up sequence that you can monitor by observing the three LEDs on top of the access point. After you observe all three LEDs turning green to indicate the starting of the IOS operating system, the Status LED blinks green signifying that IOS is operational. When in an operational status, the Ethernet LED is steady green when no traffic is being passed and dark during periods when traffic is being passed. The sequence takes about 1 minute to complete. Refer to [Chapter 21, “Troubleshooting,”](#) for LED descriptions.

When the sequence is complete, you are ready to obtain the access point’s IP address and perform an initial configuration. Refer to [Chapter 3, “Configuring the Access Point for the First Time,”](#) for instructions on assigning basic settings to the access point.





## Configuring the Access Point for the First Time

---

This chapter describes how to configure basic settings on your access point for the first time. The contents of this chapter are similar to the instructions in the quick start guide that shipped with your access point. You can configure all the settings described in this chapter using the CLI, but it might be simplest to browse to the access point's web-browser interface to complete the initial configuration and then use the CLI to enter additional settings for a more detailed configuration.

This chapter contains these sections:

- [Before You Start, page 3-2](#)
- [Obtaining and Assigning an IP Address, page 3-3](#)
- [Connecting to the Access Point Locally, page 3-3](#)
- [Assigning Basic Settings, page 3-4](#)
- [Protecting Your Wireless LAN, page 3-8](#)
- [Using the IP Setup Utility, page 3-8](#)
- [Assigning an IP Address Using the CLI, page 3-11](#)
- [Using a Telnet Session to Access the CLI, page 3-11](#)

## Before You Start

Before you install the access point, make sure you are using a computer connected to the same network as the access point, and obtain the following information:

- The following information from your network system administrator:
  - A system name
  - The case-sensitive wireless service set identifier (SSID) for your radio network
  - If not connected to a DHCP server, a unique IP address for your access point (such as 172.17.255.115)
  - If the access point is not on the same subnet as your PC, a default gateway address and subnet mask
  - A Simple Network Management Protocol (SNMP) community name and the SNMP file attribute (if SNMP is in use)
- If you use IPSU to find or assign the access point IP address, the MAC address from the label on the bottom of the access point (such as 00164625854c)

## Resetting the Access Point to Default Settings

If you need to start over during the initial setup process, follow these steps to reset the access point to factory default settings using the access point MODE button:

- 
- Step 1** Disconnect power (the power jack for external power or the Ethernet cable for in-line power) from the access point.
  - Step 2** Press and hold the MODE button while you reconnect power to the access point.
  - Step 3** Hold the MODE button until the Status LED turns amber (approximately 1 to 2 seconds), and release the button. All access point settings return to factory defaults.
- 

You can also use the web-browser interface to reset the access point to defaults. Follow these steps to return to default settings using the web-browser interface:

- 
- Step 1** Open your Internet browser. You must use Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).
  - Step 2** Enter the access point's IP address in the browser address line and press **Enter**. An Enter Network Password window appears.
  - Step 3** Enter your username in the User Name field. The default username is **Cisco**.
  - Step 4** Enter the access point password in the Password field and press **Enter**. The default password is **Cisco**. The Summary Status page appears.
  - Step 5** Click **System Software** and the System Software screen appears.
  - Step 6** Click **System Configuration** and the System Configuration screen appears.
  - Step 7** Click the **Default** button.





---

**Note** If the access point is configured with a static IP address, the IP address will not be changed.

---

## Obtaining and Assigning an IP Address

To browse to the access point's Express Setup page, you must either obtain or assign the access point's IP address using one of the following methods:

- Use default address 10.0.0.1 when you connect to the access point locally. For detailed instructions, see the “[Connecting to the Access Point Locally](#)” section on page 3-3.
- Use a DHCP server (if available) to automatically assign an IP address. You can find out the DHCP-assigned IP address using one of the following methods:
  - Provide your organization's network administrator with your access point's Media Access Control (MAC) address. Your network administrator will query the DHCP server using the MAC address to identify the IP address. The access point's MAC address is on label attached to the bottom of the access point.
  - Use the Cisco IP Setup Utility (IPSU) to identify the assigned address. You can also use IPSU to assign an IP address to the access point if it did not receive an IP address from the DHCP server. IPSU runs on most Microsoft Windows operating systems: Windows 9x, 2000, Me, NT, and XP.

You can download IPSU from the Software Center on Cisco.com. Click this link to browse to the Software Center: <http://www.cisco.com/public/sw-center/sw-wireless.shtml>

## Connecting to the Access Point Locally

If you need to configure the access point locally (without connecting the access point to a wired LAN), you can connect a PC to its Ethernet port using a Category 5 Ethernet cable. You can use a local connection to the Ethernet port much as you would use a serial port connection.



---

**Note** You do not need a special crossover cable to connect your PC to the access point; you can use either a straight-through cable or a crossover cable.

---

If the access point is configured with default values and not connected to a DHCP server or cannot obtain an IP address, it defaults to IP address 10.0.0.1 and becomes a mini-DHCP server. In that capacity, the access point provides up to twenty IP addresses between 10.0.0.11 and 10.0.0.30 to the following devices:

- An Ethernet-capable PC connected to its Ethernet port
- Wireless client devices configured to use either no SSID or *tsunami* as the SSID, and with all security settings disabled

The mini-DHCP server feature is disabled automatically when you assign a static IP address to the access point.

**Caution**

When an access point with default settings is connected on a wired LAN and does not receive an IP address from a DHCP server, the access point provides an IP address to any DHCP requests it receives.

Follow these steps to connect to the access point locally:

- 
- Step 1** Make sure that the PC you intend to use is configured to obtain an IP address automatically, or manually assign it an IP address from 10.0.0.2 to 10.0.0.10. Connect your PC to the access point using a Category 5 Ethernet cable. You can use either a crossover cable or a straight-through cable.
  - Step 2** Power up the access point.
  - Step 3** Follow the steps in the “[Assigning Basic Settings](#)” section on page 3-4. If you make a mistake and need to start over, follow the steps in the “[Resetting the Access Point to Default Settings](#)” section on page 3-2.
  - Step 4** After configuring the access point, remove the Ethernet cable from your PC and connect the access point to your wired LAN.

**Note**

When you connect your PC to the access point or reconnect your PC to the wired LAN, you might need to release and renew the IP address on the PC. On most PCs, you can perform a release and renew by rebooting your PC or by entering `ipconfig /release` and `ipconfig /renew` commands in a command prompt window. Consult your PC operating instructions for detailed instructions.

## Assigning Basic Settings

After you determine or assign the access point’s IP address, you can browse to the access point’s Express Setup page and perform an initial configuration. Follow these steps:

- 
- Step 1** Open your Internet browser. You must use Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).
  - Step 2** Enter the access point’s IP address in the browser address line and press **Enter**. An Enter Network Password screen appears.
  - Step 3** Press **Tab** to bypass the Username field and advance to the Password field.
  - Step 4** Enter the case-sensitive password *Cisco* and press **Enter**. The Summary Status page appears. [Figure 3-1](#) shows the Summary Status page.

Figure 3-1 Summary Status Page

Close Window

Cisco SYSTEMS

HOME hostname ap ap uptime is 1 hour, 20 minutes

EXPRESS SETUP  
NETWORK MAP  
ASSOCIATION  
NETWORK INTERFACES  
SECURITY  
SERVICES  
SYSTEM SOFTWARE  
EVENT LOG

Home: Summary Status

Association

Clients: 0 Repeaters: 0

Network Interfaces

Device	Transmission Rate	IP Address	MAC Address
FastEthernet	100Mbps	10.91.6.159	0005.9a39.2110
Radio-802.11b	11.0Mbps	10.91.6.159	0007.5045.86d3

Additional Event Log

Time	Severity	Description
00:32:38	Notification	Configured from console by Cisco on vty0 (84.101.192.69)
00:23:52	Information	Interface Dot11 Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:23:43	Information	Interface Dot11 Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid
00:23:41	Information	Interface Dot11 Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:23:38	Information	Interface Dot11 Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid
00:18:14	Information	Interface Dot11 Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:18:11	Information	Interface Dot11 Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid
00:18:11	Notification	Configured from console by Cisco on vty0 (84.101.192.69)
00:17:30	Information	Interface Dot11 Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:17:22	Information	Interface Dot11 Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid

Refresh

Close Window

Copyright (c) 1992-2002 by Cisco Systems, Inc. [License Statement](#)

81192

**Step 5** Click **Express Setup**. The Express Setup screen appears. Figure 3-2 shows the Express Setup page.

Figure 3-2 Express Setup Page

Close Window

Cisco SYSTEMS

HOME hostname ap ap uptime is 2 days, 21 hours, 24 minutes

EXPRESS SETUP  
NETWORK MAP  
ASSOCIATION  
NETWORK INTERFACES  
SECURITY  
SERVICES  
SYSTEM SOFTWARE  
EVENT LOG

Express Set-Up

System Name: ap

MAC Address: 0007.5045.86d3

Configuration Server Protocol:  DHCP  Static IP

IP Address: 10.91.6.159

IP Subnet Mask: 255.255.255.6

Default Gateway: 10.91.6.129

SSID: Ivory-AP

Broadcast SSID in Beacon:  Yes  No

Role in Radio Network:  Access Point (Root)  Repeater (Non-Root)

Optimize Radio Network for:  Throughput  Range  Custom

Aironet Extensions:  Enable  Disable

SNMP Community: defaultCommunity

Read-Only  Read-Write

Apply Cancel

Close Window

Copyright (c) 1992-2002 by Cisco Systems, Inc. [License Statement](#)

81194

**Step 6** Enter the configuration settings you obtained from your system administrator. The configurable settings include:

- **System Name**—The system name, while not an essential setting, helps identify the access point on your network. The system name appears in the titles of the management system pages.
- **Configuration Server Protocol**—Click on the button that matches the network’s method of IP address assignment.
  - **DHCP**—IP addresses are automatically assigned by your network’s DHCP server.
  - **Static IP**—The access point uses a static IP address that you enter in the IP address field.
- **IP Address**—Use this setting to assign or change the access point’s IP address. If DHCP is enabled for your network, leave this field blank.



**Note**

If the access point’s IP address changes while you are configuring the access point using the web-browser interface or a Telnet session over the wired LAN, you lose your connection to the access point. If you lose your connection, reconnect to the access point using its new IP address. Follow the steps in the [“Resetting the Access Point to Default Settings”](#) section on page 3-2 if you need to start over.

- **IP Subnet Mask**—Enter the IP subnet mask provided by your network administrator so the IP address can be recognized on the LAN. If DHCP is enabled, leave this field blank.
- **Default Gateway**—Enter the default gateway IP address provided by your network administrator. If DHCP is enabled, leave this field blank.
- **Radio Service Set ID (SSID)**—Enter the case-sensitive SSID (32 alphanumeric characters maximum) provided by your network administrator. The SSID is a unique identifier that client devices use to associate with the access point.
- **Broadcast SSID in Beacon**—Use this setting to allow devices that do not specify an SSID to associate with the access point.
  - **Yes**—This is the default setting; it allows devices that do not specify an SSID to associate with the access point.
  - **No**—Devices must specify an SSID to associate with the access point. With No selected, the SSID used by the client devices must match exactly the access point’s SSID.
- **Role in Radio Network**—Click on the button that describes the role of the access point on your network. Select **Access Point (Root)** if your access point is connected to the wired LAN. Select **Repeater (Non-Root)** if it is not connected to the wired LAN.
- **Optimize Radio Network for**—Use this setting to select either preconfigured settings for the access point radio or customized settings for the access point radio.
  - **Throughput**—Maximizes the data volume handled by the access point but might reduce its range.
  - **Range**—Maximizes the access point’s range but might reduce throughput.
  - **Custom**—The access point uses settings you enter on the Network Interfaces: Radio-802.11b Settings page. Clicking **Custom** takes you to the Network Interfaces: Radio-802.11b Settings page.
- **Aironet Extensions**—Enable this setting if there are only Cisco Aironet devices on your wireless LAN.

- **SNMP Community**—If your network is using SNMP, enter the SNMP Community name provided by your network administrator and select the attributes of the SNMP data (also provided by your network administrator).

**Step 7** Click **Apply** to save your settings. If you changed the IP address, you lose your connection to the access point. Browse to the new IP address to reconnect to the access point.

Your access point is now running but probably requires additional configuring to conform to your network's operational and security requirements. Consult the chapters in this manual for the information you need to complete the configuration.



**Note** You can restore the access point to its factory defaults by unplugging the power jack and plugging it back in while holding down the Mode button for a few seconds, or until the Status LED turns amber.

## Default Settings on the Express Setup Page

Table 3-1 lists the default settings for the settings on the Express Setup page.

**Table 3-1** Default Settings on the Express Setup Page

Setting	Default
System Name	ap
Configuration Server Protocol	DHCP
IP Address	Assigned by DHCP by default; if DHCP is disabled, the default setting is 10.0.0.1
IP Subnet Mask	Assigned by DHCP by default; if DHCP is disabled, the default setting is 255.0.0.0
Default Gateway	Assigned by DHCP by default; if DHCP is disabled, the default setting is 0.0.0.0
Radio Service Set ID (SSID)	tsunami
Broadcast SSID in Beacon	Yes <sup>1</sup>
Role in Radio Network	Access point (root)
Optimize Radio Network for	Throughput
Aironet Extensions	Enable
SNMP Community	defaultCommunity

1. When you assign multiple SSIDs, this setting no longer appears.

## Protecting Your Wireless LAN

After you assign basic settings to your access point, you need to configure security settings to prevent unauthorized access to your network. Because it is a radio device, the access point can communicate beyond the physical boundaries of your building. Configure some combination of these security features to protect your network from intruders:

- Unique SSIDs that are not broadcast in the access point beacon (see [Chapter 8, “Configuring Multiple SSIDs”](#))
- WEP and additional WEP features, such as TKIP and broadcast key rotation (see [Chapter 9, “Configuring WEP and WEP Features”](#))
- Dynamic WEP and client authentication (see [Chapter 10, “Configuring Authentication Types”](#))

## Using the IP Setup Utility

IPSU enables you to find the access point’s IP address when it has been assigned by a DHCP server. You can also use IPSU to set the access point’s IP address and SSID if they have not been changed from the default settings.



### Note

IPSU can be used only on the following operating systems: Windows 95, 98, NT, 2000, ME, or XP.



### Tip

Another simple way to find the access point’s IP address is to look on the Status screen in the Aironet Client Utility on a client device associated to the access point.

The sections below explain how to install the utility, how to use it to find the access point’s IP address, and how to use it to set the IP address and the SSID.

## Obtaining and Installing IPSU

IPSU is available on the Cisco web site. Follow these steps to obtain and install IPSU:

- Step 1** Use your Internet browser to access the Cisco Software Center at the following URL:  
<http://www.cisco.com/public/sw-center/sw-wireless.shtml>
- Step 2** Click **Cisco Aironet Wireless LAN Client Adapters**.
- Step 3** Scroll down to the Windows Utility section.
- Step 4** Click **Cisco Aironet Client Utility (ACU) for Windows**.
- Step 5** Click the file **IPSUvxxxxx.exe**. The *xxxxxx* identifies the software package version number.
- Step 6** Read and accept the terms and conditions of the Software License Agreement.
- Step 7** Download and save the file to a temporary directory on your hard drive and then exit the Internet browser.
- Step 8** Double-click **IPSUvxxxxxx.exe** in the temporary directory to expand the file.


- Step 9** Double-click **Setup.exe** and follow the steps provided by the installation wizard to install IPSU. The IPSU icon appears on your computer desktop.

## Using IPSU to Find the Access Point's IP Address

If your access point receives an IP address from a DHCP server, you can use IPSU to find its IP address. Because IPSU sends a reverse-ARP request based on the access point MAC address, you must run IPSU from a computer on the same subnet as the access point. Follow these steps to find the access point's IP address:

- Step 1** Double-click the **IPSU** icon on your computer desktop to start the utility. The IPSU screen appears (see [Figure 3-3](#)).

**Figure 3-3** IPSU Get IP Address Screen



- Step 2** When the utility window opens, make sure the *Get IP addr* radio button in the Function box is selected.
- Step 3** Enter the access point's MAC address in the Device MAC ID field. The access point's MAC address is printed on the label on the bottom of the unit. It should contain six pairs of hexadecimal digits. Your access point's MAC address might look like the following example:

000164xxxxxx



**Note** The MAC address field is not case-sensitive.

- Step 4** Click **Get IP Address**.
- Step 5** When the access point's IP address appears in the IP Address field, write it down.

If IPSU reports that the IP address is 10.0.0.1, the default IP address, then the access point did not receive a DHCP-assigned IP address. To change the access point IP address from the default value using IPSU, refer to the [“Using IPSU to Set the Access Point's IP Address and SSID”](#) section on page 3-10.

## Using IPSU to Set the Access Point's IP Address and SSID

If you want to change the default IP address (10.0.0.1) of the access point, you can use IPSU. You can also set the access point's SSID at the same time.


**Note**

The computer you use to assign an IP address to the access point must have an IP address in the same subnet as the access point (10.0.0.x).



**Note**

IPSU can change the access point's IP address and SSID only from their default settings. After the IP address and SSID have been changed, IPSU cannot change them again.

Follow these steps to assign an IP address and an SSID to the access point:

- Step 1** Double-click the **IPSU** icon on your computer desktop to start the utility.
- Step 2** Click the **Set Parameters** radio button in the Function box (see [Figure 3-4](#)).

**Figure 3-4 IPSU Set Parameters Screen**



- Step 3** Enter the access point's MAC address in the Device MAC ID field. The access point's MAC address is printed on the label on the bottom of the unit. It should contain six pairs of hexadecimal digits. Your access point's MAC address might look like this example:

004096xxxxxx


**Note**

The MAC address field is not case-sensitive.

- Step 4** Enter the IP address you want to assign to the access point in the IP Address field.
- Step 5** Enter the SSID you want to assign to the access point in the SSID field.


**Note**

You cannot set the SSID without also setting the IP address. However, you can set the IP address without setting the SSID.



- Step 6** Click **Set Parameters** to change the access point's IP address and SSID settings.
- Step 7** Click **Exit** to exit IPSU.

## Assigning an IP Address Using the CLI


When you connect the access point to the wired LAN, the access point links to the network using a bridge virtual interface (BVI) that it creates automatically. Instead of tracking separate IP addresses for the access point's Ethernet and radio ports, the network uses the BVI.

When you assign an IP address to the access point using the CLI, you must assign the address to the BVI. Beginning in privileged EXEC mode, follow these steps to assign an IP address to the access point's BVI:

	Command	Purpose
<b>Step 1</b>	<b>configure terminal</b>	Enter global configuration mode.
<b>Step 2</b>	<b>interface bvi1</b>	Enter interface configuration mode for the BVI.
<b>Step 3</b>	<b>ip address <i>address</i> <i>mask</i></b>	Assign an IP address and address mask to the BVI. This step automatically saves the running configuration to the startup configuration.  <b>Note</b> You lose your connection to the access point when you assign a new IP address to the BVI. If you need to continue configuring the access point, use the new IP address to open another Telnet session to the access point.

## Using a Telnet Session to Access the CLI

Follow these steps to browse to access the CLI using a Telnet session. These steps are for a PC running Microsoft Windows with a Telnet terminal application. Check your PC operating instructions for detailed instructions for your operating system.

- Step 1** Select **Start > Programs > Accessories > Telnet**.
- If Telnet is not listed in your Accessories menu, select **Start > Run**, type **Telnet** in the entry field, and press **Enter**.
- Step 2** When the Telnet window appears, click **Connect** and select **Remote System**.
-  **Note** In Windows 2000, the Telnet window does not contain drop-down menus. To start the Telnet session in Windows 2000, type **open** followed by the access point's IP address.
- Step 3** In the Host Name field, type the access point's IP address and click **Connect**.





## Using the Web-Browser Interface

---

This chapter describes the web-browser interface that you can use to configure the access point. It contains these sections:

- [Using the Web-Browser Interface for the First Time, page 4-2](#)
- [Using the Management Pages in the Web-Browser Interface, page 4-2](#)
- [Using Online Help, page 4-5](#)

The web-browser interface contains management pages that you use to change access point settings, upgrade firmware, and monitor and configure other wireless devices on the network.



**Note**

---

The access point web-browser interface is fully compatible with Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).

---

## Using the Web-Browser Interface for the First Time

Use the access point's IP address to browse to the management system. See the [“Obtaining and Assigning an IP Address”](#) section on page 3-3 for instructions on assigning an IP address to the access point.

Follow these steps to begin using the web-browser interface:

- 
- Step 1** Start the browser.
- Step 2** Enter the access point's IP address in the browser **Location** field (Netscape Communicator) or **Address** field (Internet Explorer) and press **Enter**. The Summary Status page appears.
- 

## Using the Management Pages in the Web-Browser Interface

The system management pages use consistent techniques to present and save configuration information. A navigation bar is on the left side of the page, and configuration action buttons appear at the bottom. You use the navigation bar to browse to other management pages, and you use the configuration action buttons to save or cancel changes to the configuration.

**Note**

---

It's important to remember that clicking your browser's **Back** button returns you to the previous page without saving any changes you have made. Clicking **Cancel** cancels any changes you made on the page and keeps you on that page. Changes are only applied when you click **Apply**.

---

[Figure 4-1](#) shows the web-browser interface home page.

Figure 4-1 Web-Browser Interface Home Page

Close Window

Cisco SYSTEMS

hostname ap ap uptime is 1 hour, 20 minutes

**HOME** | EXPRESS SET-UP | NETWORK MAP | ASSOCIATION | NETWORK INTERFACES | SECURITY | SERVICES | SYSTEM SOFTWARE | EVENT LOG

**Home: Summary Status**

[Association](#)

Clients: 0 Repeaters: 0

[Network Interfaces](#)

Device	Transmission Rate	IP Address	MAC Address
<a href="#">FastEthernet</a>	100Mb/s	10.91.6.159	0005.9a39.2110
<a href="#">Radio-802.11b</a>	11.0Mb/s	10.91.6.159	0007.50d5.86d3

[Additional Event Log](#)

Time	Severity	Description
00:32:38	◆ Notification	Configured from console by Cisco on vty0 (64.101.192.69)
00:23:52	◆ Information	Interface Dot11Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:23:43	◆ Information	Interface Dot11Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid
00:23:41	◆ Information	Interface Dot11Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:23:38	◆ Information	Interface Dot11Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid
00:18:14	◆ Information	Interface Dot11Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:18:11	◆ Information	Interface Dot11Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid
00:18:11	◆ Notification	Configured from console by Cisco on vty0 (64.101.192.69)
00:17:30	◆ Information	Interface Dot11Radio0, Station TOSHIBA7200 0040.9638.8b85 Reassociated
00:17:22	◆ Information	Interface Dot11Radio0, Deauthenticating Station 0040.9638.8b85 Reason: Previous authentication no longer valid

Refresh

Close Window Copyright (c) 1992-2002 by Cisco Systems, Inc. [License Statement](#)

81192

## Using Action Buttons

Table 4-1 lists the page links and buttons that appear on most management pages.

**Table 4-1 Common Buttons on Management Pages**

Button/Link	Description
<b>Navigation Links</b>	
Home	Displays access point status page with information on the number of radio devices associated to the access point, the status of the Ethernet and radio interfaces, and a list of recent access point activity.
Express Setup	Displays the Express Setup page that includes basic settings such as system name, IP address, and SSID.
Network Map	Displays a list of infrastructure devices on your wireless LAN.
Association	Displays a list of all devices on your wireless LAN, listing their system names, network roles, and parent-client relationships.

**Table 4-1 Common Buttons on Management Pages (continued)**

<b>Button/Link</b>	<b>Description</b>
Network Interfaces	Displays status and statistics for the Ethernet and radio interfaces and provides links to configuration pages for each interface.
Security	Displays a summary of security settings and provides links to security configuration pages.
Services	Displays status for several access point features and links to configuration pages for Telnet/SSH, CDP, Domain Name Server, Filters, Proxy Mobile IP, QoS, SNMP, SNTP, and VLANs.
System Software	Displays the version number of the firmware that the access point is running and provides links to configuration pages for upgrading and managing firmware.
Event Log	Displays the access point event log and provides links to configuration pages where you can select events to be included in traps, set event severity levels, and set notification methods.
<b>Configuration Action Buttons</b>	
Apply	Saves changes made on the page and remains on the page.
Refresh	Updates status information or statistics displayed on a page.
Cancel	Discards changes to the page and remains on the page.
Back	Discards any changes made to the page and returns to the previous page.

## Character Restrictions in Entry Fields

Because the 1100 series access point uses Cisco IOS software, there are certain characters that you cannot use in the entry fields on the web-browser interface. [Table 4-2](#) lists the illegal characters and the fields in which you cannot use them.

**Table 4-2** *Illegal Characters for Web-Browser Interface Entry Fields*

Entry Field Type	Illegal Characters
Password entry fields	? “ \$ [ +
All other entry fields	? “ \$ [ +  You also cannot use these three characters as the first character in an entry field:  ! # ;

## Using Online Help

Click the help icon at the top of any page in the web-browser interface to display online help. [Figure 4-2](#) shows the print and help icons.

**Figure 4-2** *Print and Help Icons*



When a help page appears in a new browser window, use the Select a topic drop-down menu to display the help index or instructions for common configuration tasks, such as configuring VLANs.







## Using the Command-Line Interface

---

This chapter describes the IOS command-line interface (CLI) that you can use to configure your access point. It contains these sections:

- [IOS Command Modes, page 5-2](#)
- [Getting Help, page 5-3](#)
- [Abbreviating Commands, page 5-3](#)
- [Using no and default Forms of Commands, page 5-3](#)
- [Understanding CLI Messages, page 5-4](#)
- [Using Command History, page 5-4](#)
- [Using Editing Features, page 5-5](#)
- [Searching and Filtering Output of show and more Commands, page 5-8](#)
- [Accessing the CLI, page 5-8](#)

# IOS Command Modes

The Cisco IOS user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

When you start a session on the access point, you begin in user mode, often called *user EXEC mode*. Only a limited subset of the commands are available in user EXEC mode. For example, most of the user EXEC commands are one-time commands, such as **show** commands, which show the current configuration status, and **clear** commands, which clear counters or interfaces. The user EXEC commands are not saved when the access point reboots.

To have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From this mode, you must enter privileged EXEC mode before you can enter the global configuration mode.

Using the configuration modes (global, interface, and line), you can make changes to the running configuration. If you save the configuration, these commands are stored and used when the access point reboots. To access the various configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and line configuration mode.

[Table 5-1](#) describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode. The examples in the table use the host name *ap*.

**Table 5-1** Command Mode Summary

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your access point.	ap>	Enter <b>logout</b> or <b>quit</b> .	Use this mode to <ul style="list-style-type: none"> <li>• Change terminal settings</li> <li>• Perform basic tests</li> <li>• Display system information.</li> </ul>
Privileged EXEC	While in user EXEC mode, enter the <b>enable</b> command.	ap#	Enter <b>disable</b> to exit.	Use this mode to verify commands. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the <b>configure</b> command.	ap(config)#	To exit to privileged EXEC mode, enter <b>exit</b> or <b>end</b> , or press <b>Ctrl-Z</b> .	Use this mode to configure parameters that apply to the entire access point.
Interface configuration	While in global configuration mode, enter the <b>interface</b> command (with a specific interface).	ap(config-if)#	To exit to global configuration mode, enter <b>exit</b> . To return to privileged EXEC mode, press <b>Ctrl-Z</b> or enter <b>end</b> .	Use this mode to configure parameters for the Ethernet interfaces.

## Getting Help

You can enter a question mark (?) at the system prompt to display a list of commands available for each command mode. You can also obtain a list of associated keywords and arguments for any command, as shown in [Table 5-2](#).

**Table 5-2 Help Summary**

Command	Purpose
<b>help</b>	Obtain a brief description of the help system in any command mode.
<i>abbreviated-command-entry?</i>	Obtain a list of commands that begin with a particular character string. For example: ap# <b>di?</b> dir disable disconnect
<i>abbreviated-command-entry&lt;Tab&gt;</i>	Complete a partial command name. For example: ap# <b>sh conf&lt;tab&gt;</b> ap# show configuration
<b>?</b>	List all commands available for a particular command mode. For example: ap> <b>?</b>
<i>command ?</i>	List the associated keywords for a command. For example: ap> <b>show ?</b>
<i>command keyword ?</i>	List the associated arguments for a keyword. For example: ap(config)# <b>cdp holdtime ?</b> <10-255> Length of time (in sec) that receiver must keep this packet

## Abbreviating Commands

You have to enter only enough characters for the access point to recognize the command as unique. This example shows how to enter the **show configuration** privileged EXEC command:

```
ap# show conf
```

## Using no and default Forms of Commands

Most configuration commands also have a **no** form. In general, use the **no** form to disable a feature or function or reverse the action of a command. For example, the **no shutdown** interface configuration command reverses the shutdown of an interface. Use the command without the keyword **no** to re-enable a disabled feature or to enable a feature that is disabled by default.

Configuration commands can also have a **default** form. The **default** form of a command returns the command setting to its default. Most commands are disabled by default, so the **default** form is the same as the **no** form. However, some commands are enabled by default and have variables set to certain default values. In these cases, the **default** command enables the command and sets variables to their default values.

## Understanding CLI Messages

Table 5-3 lists some error messages that you might encounter while using the CLI to configure your access point.

**Table 5-3 Common CLI Error Messages**

Error Message	Meaning	How to Get Help
% Ambiguous command: "show con"	You did not enter enough characters for your access point to recognize the command.	Re-enter the command followed by a question mark (?) with a space between the command and the question mark.  The possible keywords that you can enter with the command are displayed.
% Incomplete command.	You did not enter all the keywords or values required by this command.	Re-enter the command followed by a question mark (?) with a space between the command and the question mark.  The possible keywords that you can enter with the command are displayed.
% Invalid input detected at ^^ marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all the commands that are available in this command mode.  The possible keywords that you can enter with the command are displayed.

## Using Command History

The IOS provides a history or record of commands that you have entered. This feature is particularly useful for recalling long or complex commands or entries, including access lists. You can customize the command history feature to suit your needs as described in these sections:

- [Changing the Command History Buffer Size, page 5-4](#)
- [Recalling Commands, page 5-5](#)
- [Disabling the Command History Feature, page 5-5](#)

## Changing the Command History Buffer Size

By default, the access point records ten command lines in its history buffer. Beginning in privileged EXEC mode, enter this command to change the number of command lines that the access point records during the current terminal session:

```
ap# terminal history [size number-of-lines]
```

The range is from 0 to 256.

Beginning in line configuration mode, enter this command to configure the number of command lines the access point records for all sessions on a particular line:

```
ap(config-line)# history [size number-of-lines]
```

The range is from 0 to 256.

## Recalling Commands

To recall commands from the history buffer, perform one of the actions listed in [Table 5-4](#):

**Table 5-4** Recalling Commands

Action <sup>1</sup>	Result
Press <b>Ctrl-P</b> or the up arrow key.	Recall commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Press <b>Ctrl-N</b> or the down arrow key.	Return to more recent commands in the history buffer after recalling commands with <b>Ctrl-P</b> or the up arrow key. Repeat the key sequence to recall successively more recent commands.
<b>show history</b>	While in privileged EXEC mode, list the last several commands that you just entered. The number of commands that are displayed is determined by the setting of the <b>terminal history</b> global configuration command and <b>history</b> line configuration command.

1. The arrow keys function only on ANSI-compatible terminals such as VT100s.

## Disabling the Command History Feature

The command history feature is automatically enabled.

To disable the feature during the current terminal session, enter the **terminal no history** privileged EXEC command.

To disable command history for the line, enter the **no history** line configuration command.

## Using Editing Features

This section describes the editing features that can help you manipulate the command line. It contains these sections:

- [Enabling and Disabling Editing Features, page 5-5](#)
- [Editing Commands through Keystrokes, page 5-6](#)
- [Editing Command Lines that Wrap, page 5-7](#)

## Enabling and Disabling Editing Features

Although enhanced editing mode is automatically enabled, you can disable it.

To re-enable the enhanced editing mode for the current terminal session, enter this command in privileged EXEC mode:

```
ap# terminal editing
```

To reconfigure a specific line to have enhanced editing mode, enter this command in line configuration mode:

```
ap(config-line)# editing
```

To globally disable enhanced editing mode, enter this command in line configuration mode:

```
ap(config-line)# no editing
```

## Editing Commands through Keystrokes

Table 5-5 shows the keystrokes that you need to edit command lines.

**Table 5-5** Editing Commands through Keystrokes

Capability	Keystroke <sup>1</sup>	Purpose
Move around the command line to make changes or corrections.	<b>Ctrl-B</b> or the left arrow key	Move the cursor back one character.
	<b>Ctrl-F</b> or the right arrow key	Move the cursor forward one character.
	<b>Ctrl-A</b>	Move the cursor to the beginning of the command line.
	<b>Ctrl-E</b>	Move the cursor to the end of the command line.
	<b>Esc B</b>	Move the cursor back one word.
	<b>Esc F</b>	Move the cursor forward one word.
	<b>Ctrl-T</b>	Transpose the character to the left of the cursor with the character located at the cursor.
Recall commands from the buffer and paste them in the command line. The access point provides a buffer with the last ten items that you deleted.	<b>Ctrl-Y</b>	Recall the most recent entry in the buffer.
	<b>Esc Y</b>	Recall the next buffer entry.  The buffer contains only the last 10 items that you have deleted or cut. If you press <b>Esc Y</b> more than ten times, you cycle to the first buffer entry.
Delete entries if you make a mistake or change your mind.	<b>Delete</b> or <b>Backspace</b>	Erase the character to the left of the cursor.
	<b>Ctrl-D</b>	Delete the character at the cursor.
	<b>Ctrl-K</b>	Delete all characters from the cursor to the end of the command line.
	<b>Ctrl-U</b> or <b>Ctrl-X</b>	Delete all characters from the cursor to the beginning of the command line.
	<b>Ctrl-W</b>	Delete the word to the left of the cursor.
	<b>Esc D</b>	Delete from the cursor to the end of the word.
Capitalize or lowercase words or capitalize a set of letters.	<b>Esc C</b>	Capitalize at the cursor.
	<b>Esc L</b>	Change the word at the cursor to lowercase.
	<b>Esc U</b>	Capitalize letters from the cursor to the end of the word.

Table 5-5 Editing Commands through Keystrokes (continued)

Capability	Keystroke <sup>1</sup>	Purpose
Designate a particular keystroke as an executable command, perhaps as a shortcut.	<b>Ctrl-V</b> or <b>Esc Q</b>	
Scroll down a line or screen on displays that are longer than the terminal screen can display.  <b>Note</b> The <code>More</code> prompt appears for output that has more lines than can be displayed on the terminal screen, including <b>show</b> command output. You can use the <b>Return</b> and <b>Space</b> bar keystrokes whenever you see the <code>More</code> prompt.	<b>Return</b>	Scroll down one line.
	<b>Space</b>	Scroll down one screen.
Redisplay the current command line if the access point suddenly sends a message to your screen.	<b>Ctrl-L</b> or <b>Ctrl-R</b>	Redisplay the current command line.

1. The arrow keys function only on ANSI-compatible terminals such as VT100s.

## Editing Command Lines that Wrap

You can use a wraparound feature for commands that extend beyond a single line on the screen. When the cursor reaches the right margin, the command line shifts ten spaces to the left. You cannot see the first ten characters of the line, but you can scroll back and check the syntax at the beginning of the command.

To scroll back to the beginning of the command entry, press **Ctrl-B** or the left arrow key repeatedly. You can also press **Ctrl-A** to immediately move to the beginning of the line.



### Note

The arrow keys function only on ANSI-compatible terminals such as VT100s.

In this example, the **access-list** global configuration command entry extends beyond one line. When the cursor first reaches the end of the line, the line is shifted ten spaces to the left and redisplayed. The dollar sign (\$) shows that the line has been scrolled to the left. Each time the cursor reaches the end of the line, the line is again shifted ten spaces to the left.

```
ap(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1
ap(config)# $ 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.25
ap(config)# $t tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq
ap(config)# $108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq 45
```

After you complete the entry, press **Ctrl-A** to check the complete syntax before pressing the **Return** key to execute the command. The dollar sign (\$) appears at the end of the line to show that the line has been scrolled to the right:

```
ap(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1$
```

The software assumes you have a terminal screen that is 80 columns wide. If you have a width other than that, use the **terminal width** privileged EXEC command to set the width of your terminal.

Use line wrapping with the command history feature to recall and modify previous complex command entries. For information about recalling previous command entries, see the “[Editing Commands through Keystrokes](#)” section on page 5-6.

## Searching and Filtering Output of show and more Commands

You can search and filter the output for **show** and **more** commands. This is useful when you need to sort through large amounts of output or if you want to exclude output that you do not need to see.

To use this functionality, enter a **show** or **more** command followed by the *pipe* character (`|`), one of the keywords **begin**, **include**, or **exclude**, and an expression that you want to search for or filter out:

```
command | {begin | include | exclude} regular-expression
```

Expressions are case sensitive. For example, if you enter `| exclude output`, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

This example shows how to include in the output display only lines where the expression *protocol* appears:

```
ap# show interfaces | include protocol
Vlan1 is up, line protocol is up
Vlan10 is up, line protocol is down
GigabitEthernet0/1 is up, line protocol is down
GigabitEthernet0/2 is up, line protocol is up
```

## Accessing the CLI

You can open the access point’s CLI using Telnet or Secure Shell (SSH).

### Opening the CLI with Telnet

Follow these steps to open the CLI with Telnet. These steps are for a PC running Microsoft Windows with a Telnet terminal application. Check your PC operating instructions for detailed instructions for your operating system.

---

**Step 1** Select **Start > Programs > Accessories > Telnet**.

If Telnet is not listed in your Accessories menu, select **Start > Run**, type **Telnet** in the entry field, and press **Enter**.

**Step 2** When the Telnet window appears, click **Connect** and select **Remote System**.




---

**Note** In Windows 2000, the Telnet window does not contain drop-down menus. To start the Telnet session in Windows 2000, type **open** followed by the access point’s IP address.

---

**Step 3** In the Host Name field, type the access point’s IP address and click **Connect**.



- Step 4** At the username and password prompts, enter your administrator username and password. The default username is **Cisco**, and the default password is **Cisco**. The default enable password is also **Cisco**. Usernames and passwords are case-sensitive.
- 

## Opening the CLI with Secure Shell

Secure Shell Protocol is a protocol that provides a secure, remote connection to networking devices set up to use it. Secure Shell (SSH) is a software package that provides secure login sessions by encrypting the entire session. SSH features strong cryptographic authentication, strong encryption, and integrity protection. For detailed information on SSH, visit the homepage of SSH Communications Security, Ltd. at this URL:

<http://www.ssh.com/>

SSH provides more security for remote connections than Telnet by providing strong encryption when a device is authenticated. See the “[Configuring the Access Point for Secure Shell](#)” section on page 6-13 for detailed instructions on setting up the access point for SSH access.





## Administering the Access Point

---

This chapter describes how to administer your access point. This chapter contains these sections:

- [Preventing Unauthorized Access to Your Access Point, page 6-2](#)
- [Protecting Access to Privileged EXEC Commands, page 6-2](#)
- [Controlling Access Point Access with RADIUS, page 6-7](#)
- [Configuring the Access Point for Local Authentication and Authorization, page 6-12](#)
- [Configuring the Access Point for Secure Shell, page 6-13](#)
- [Managing the System Time and Date, page 6-14](#)
- [Configuring a System Name and Prompt, page 6-29](#)
- [Creating a Banner, page 6-31](#)

## Preventing Unauthorized Access to Your Access Point

You can prevent unauthorized users from reconfiguring your access point and viewing configuration information. Typically, you want network administrators to have access to the access point while you restrict access to users who connect through a terminal or workstation from within the local network.

To prevent unauthorized access to your access point, you should configure one of these security features:

- Username and password pairs, which are locally stored on the access point. These pairs authenticate each user before that user can access the access point. You can also assign a specific privilege level (read only or read/write) to each username and password pair. For more information, see the [“Configuring Username and Password Pairs” section on page 6-5](#). The default username is *Cisco*, and the default password is *Cisco*. Usernames and passwords are case-sensitive.
- Username and password pairs stored centrally in a database on a security server. For more information, see the [“Controlling Access Point Access with RADIUS” section on page 6-7](#).

## Protecting Access to Privileged EXEC Commands

A simple way of providing terminal access control in your network is to use passwords and assign privilege levels. Password protection restricts access to a network or network device. Privilege levels define what commands users can issue after they have logged into a network device.



### Note

For complete syntax and usage information for the commands used in this section, refer to the *Cisco IOS Security Command Reference for Release 12.1*.

This section describes how to control access to the configuration file and privileged EXEC commands. It contains this configuration information:

- [Default Password and Privilege Level Configuration, page 6-2](#)
- [Setting or Changing a Static Enable Password, page 6-3](#)
- [Protecting Enable and Enable Secret Passwords with Encryption, page 6-4](#)
- [Configuring Username and Password Pairs, page 6-5](#)
- [Configuring Multiple Privilege Levels, page 6-6](#)

## Default Password and Privilege Level Configuration

[Table 6-1](#) shows the default password and privilege level configuration.

**Table 6-1** Default Password and Privilege Levels

Feature	Default Setting
Username and password	Default username is <i>Cisco</i> and the default password is <i>Cisco</i> .
Enable password and privilege level	Default password is <i>Cisco</i> . The default is level 15 (privileged EXEC level). The password is encrypted in the configuration file.

Table 6-1 Default Password and Privilege Levels (continued)

Feature	Default Setting
Enable secret password and privilege level	The default enable password is <i>Cisco</i> . The default is level 15 (privileged EXEC level). The password is encrypted before it is written to the configuration file.
Line password	Default password is <i>Cisco</i> . The password is encrypted in the configuration file.

## Setting or Changing a Static Enable Password

The enable password controls access to the privileged EXEC mode. Beginning in privileged EXEC mode, follow these steps to set or change a static enable password:

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>enable password password</code>	<p>Define a new password or change an existing password for access to privileged EXEC mode.</p> <p>The default password is <i>Cisco</i>.</p> <p>For <i>password</i>, specify a string from 1 to 25 alphanumeric characters. The string cannot start with a number, is case sensitive, and allows spaces but ignores leading spaces. It can contain the question mark (?) character if you precede the question mark with the key combination Crtl-V when you create the password; for example, to create the password abc?123, do this:</p> <ol style="list-style-type: none"> <li>1. Enter <b>abc</b>.</li> <li>2. Enter <b>Crtl-V</b>.</li> <li>3. Enter <b>?123</b>.</li> </ol> <p>When the system prompts you to enter the enable password, you need not precede the question mark with the Ctrl-V; you can simply enter abc?123 at the password prompt.</p>
Step 3	<code>end</code>	Return to privileged EXEC mode.
Step 4	<code>show running-config</code>	Verify your entries.
Step 5	<code>copy running-config startup-config</code>	<p>(Optional) Save your entries in the configuration file.</p> <p>The enable password is not encrypted and can be read in the access point configuration file.</p>



### Note

The **no enable password** global configuration command removes the enable password, but you should use extreme care when using this command. If you remove the enable password, you are locked out of the EXEC mode.

This example shows how to change the enable password to *11u2c3k4y5*. The password is not encrypted and provides access to level 15 (traditional privileged EXEC mode access):

```
AP(Config)# enable password 11u2c3k4y5
```

## Protecting Enable and Enable Secret Passwords with Encryption

To provide an additional layer of security, particularly for passwords that cross the network or that are stored on a Trivial File Transfer Protocol (TFTP) server, you can use either the **enable password** or **enable secret** global configuration commands. Both commands accomplish the same thing; that is, you can establish an encrypted password that users must enter to access privileged EXEC mode (the default) or any privilege level you specify.

We recommend that you use the **enable secret** command because it uses an improved encryption algorithm.

If you configure the **enable secret** command, it takes precedence over the **enable password** command; the two commands cannot be in effect simultaneously.

Beginning in privileged EXEC mode, follow these steps to configure encryption for enable and enable secret passwords:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>enable password</b> [level <i>level</i> ] { <i>password</i>   <i>encryption-type encrypted-password</i> } or <b>enable secret</b> [level <i>level</i> ] { <i>password</i>   <i>encryption-type encrypted-password</i> }	Define a new password or change an existing password for access to privileged EXEC mode. or Define a secret password, which is saved using a nonreversible encryption method. <ul style="list-style-type: none"> <li>(Optional) For <i>level</i>, the range is from 0 to 15. Level 1 is normal user EXEC mode privileges. The default level is 15 (privileged EXEC mode privileges).</li> <li>For <i>password</i>, specify a string from 1 to 25 alphanumeric characters. The string cannot start with a number, is case sensitive, and allows spaces but ignores leading spaces. By default, no password is defined.</li> <li>(Optional) For <i>encryption-type</i>, only type 5, a Cisco proprietary encryption algorithm, is available. If you specify an encryption type, you must provide an encrypted password—an encrypted password you copy from another access point configuration.</li> </ul> <p><b>Note</b> If you specify an encryption type and then enter a clear text password, you can not re-enter privileged EXEC mode. You cannot recover a lost encrypted password by any method.</p>
Step 3	<b>service password-encryption</b>	(Optional) Encrypt the password when the password is defined or when the configuration is written. Encryption prevents the password from being readable in the configuration file.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

If both the enable and enable secret passwords are defined, users must enter the enable secret password.

Use the **level** keyword to define a password for a specific privilege level. After you specify the level and set a password, give the password only to users who need to have access at this level. Use the **privilege level** global configuration command to specify commands accessible at various levels. For more information, see the “Configuring Multiple Privilege Levels” section on page 6-6.

If you enable password encryption, it applies to all passwords including username passwords, authentication key passwords, the privileged command password, and console and virtual terminal line passwords.

To remove a password and level, use the **no enable password [level level]** or **no enable secret [level level]** global configuration command. To disable password encryption, use the **no service password-encryption** global configuration command.

This example shows how to configure the encrypted password `$1$FaD0$Xyti5Rkls3LoyxzS8` for privilege level 2:

```
AP(config)# enable secret level 2 5 $1$FaD0$Xyti5Rkls3LoyxzS8
```

## Configuring Username and Password Pairs

You can configure username and password pairs, which are locally stored on the access point. These pairs are assigned to lines or interfaces and authenticate each user before that user can access the access point. If you have defined privilege levels, you can also assign a specific privilege level (with associated rights and privileges) to each username and password pair.

Beginning in privileged EXEC mode, follow these steps to establish a username-based authentication system that requests a login username and a password:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>username name [privilege level]</b> { <b>password encryption-type password</b> }	Enter the username, privilege level, and password for each user. <ul style="list-style-type: none"> <li>For <i>name</i>, specify the user ID as one word. Spaces and quotation marks are not allowed.</li> <li>(Optional) For <i>level</i>, specify the privilege level the user has after gaining access. The range is 0 to 15. Level 15 gives privileged EXEC mode access. Level 1 gives user EXEC mode access.</li> <li>For <i>encryption-type</i>, enter 0 to specify that an unencrypted password will follow. Enter 7 to specify that a hidden password will follow.</li> <li>For <i>password</i>, specify the password the user must enter to gain access to the access point. The password must be from 1 to 25 characters, can contain embedded spaces, and must be the last option specified in the <b>username</b> command.</li> </ul>
Step 3	<b>login local</b>	Enable local password checking at login time. Authentication is based on the username specified in Step 2.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your entries.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable username authentication for a specific user, use the **no username *name*** global configuration command.

To disable password checking and allow connections without a password, use the **no login** line configuration command.



**Note** You must have at least one username configured and you must have login local set to open a Telnet session to the access point. If you enter no username for the only username, you can be locked out of the access point.

## Configuring Multiple Privilege Levels

By default, the IOS software has two modes of password security: user EXEC and privileged EXEC. You can configure up to 16 hierarchical levels of commands for each mode. By configuring multiple passwords, you can allow different sets of users to have access to specified commands.

For example, if you want many users to have access to the **clear line** command, you can assign it level 2 security and distribute the level 2 password fairly widely. But if you want more restricted access to the **configure** command, you can assign it level 3 security and distribute that password to a more restricted group of users.

This section includes this configuration information:

- [Setting the Privilege Level for a Command, page 6-6](#)
- [Logging Into and Exiting a Privilege Level, page 6-7](#)

## Setting the Privilege Level for a Command

Beginning in privileged EXEC mode, follow these steps to set the privilege level for a command mode:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>privilege mode level level command</b>	Set the privilege level for a command. <ul style="list-style-type: none"> <li>• For <i>mode</i>, enter <b>configure</b> for global configuration mode, <b>exec</b> for EXEC mode, <b>interface</b> for interface configuration mode, or <b>line</b> for line configuration mode.</li> <li>• For <i>level</i>, the range is from 0 to 15. Level 1 is for normal user EXEC mode privileges. Level 15 is the level of access permitted by the <b>enable</b> password.</li> <li>• For <i>command</i>, specify the command to which you want to restrict access.</li> </ul>
Step 3	<b>enable password level level password</b>	Specify the enable password for the privilege level. <ul style="list-style-type: none"> <li>• For <i>level</i>, the range is from 0 to 15. Level 1 is for normal user EXEC mode privileges.</li> <li>• For <i>password</i>, specify a string from 1 to 25 alphanumeric characters. The string cannot start with a number, is case sensitive, and allows spaces but ignores leading spaces. By default, no password is defined.</li> </ul>



	Command	Purpose
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b> or <b>show privilege</b>	Verify your entries. The first command displays the password and access level configuration. The second command displays the privilege level configuration.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

When you set a command to a privilege level, all commands whose syntax is a subset of that command are also set to that level. For example, if you set the **show ip route** command to level 15, the **show** commands and **show ip** commands are automatically set to privilege level 15 unless you set them individually to different levels.

To return to the default privilege for a given command, use the **no privilege mode level level command** global configuration command.

This example shows how to set the **configure** command to privilege level 14 and define *SecretPswd14* as the password users must enter to use level 14 commands:

```
AP(config)# privilege exec level 14 configure
AP(config)# enable password level 14 SecretPswd14
```

## Logging Into and Exiting a Privilege Level

Beginning in privileged EXEC mode, follow these steps to log in to a specified privilege level and to exit to a specified privilege level:

	Command	Purpose
Step 1	<b>enable level</b>	Log in to a specified privilege level. For <i>level</i> , the range is 0 to 15.
Step 2	<b>disable level</b>	Exit to a specified privilege level. For <i>level</i> , the range is 0 to 15.

## Controlling Access Point Access with RADIUS

This section describes how to control administrator access to the access point using Remote Authentication Dial-In User Service (RADIUS). For complete instructions on configuring the access point to support RADIUS, see [Chapter 11, “Configuring RADIUS Servers.”](#)

RADIUS provides detailed accounting information and flexible administrative control over authentication and authorization processes. RADIUS is facilitated through AAA and can be enabled only through AAA commands.



### Note

For complete syntax and usage information for the commands used in this section, refer to the *Cisco IOS Security Command Reference for Release 12.2*.

These sections describe RADIUS configuration:

- [Default RADIUS Configuration, page 6-8](#)
- [Configuring RADIUS Login Authentication, page 6-8](#) (required)
- [Defining AAA Server Groups, page 6-9](#) (optional)
- [Configuring RADIUS Authorization for User Privileged Access and Network Services, page 6-11](#) (optional)
- [Displaying the RADIUS Configuration, page 6-12](#)

## Default RADIUS Configuration

RADIUS and AAA are disabled by default.

To prevent a lapse in security, you cannot configure RADIUS through a network management application. When enabled, RADIUS can authenticate users accessing the access point through the CLI.

## Configuring RADIUS Login Authentication

To configure AAA authentication, you define a named list of authentication methods and then apply that list to various interfaces. The method list defines the types of authentication to be performed and the sequence in which they are performed; it must be applied to a specific interface before any of the defined authentication methods are performed. The only exception is the default method list (which, by coincidence, is named *default*). The default method list is automatically applied to all interfaces except those that have a named method list explicitly defined.

A method list describes the sequence and authentication methods to be queried to authenticate a user. You can designate one or more security protocols to be used for authentication, thus ensuring a backup system for authentication in case the initial method fails. The software uses the first method listed to authenticate users; if that method fails to respond, the software selects the next authentication method in the method list. This process continues until there is successful communication with a listed authentication method or until all defined methods are exhausted. If authentication fails at any point in this cycle—meaning that the security server or local username database responds by denying the user access—the authentication process stops, and no other authentication methods are attempted.

Beginning in privileged EXEC mode, follow these steps to configure login authentication. This procedure is required.

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>aaa new-model</code>	Enable AAA.

	Command	Purpose
Step 3	<b>aaa authentication login</b> { <b>default</b>   <i>list-name</i> } <i>method1</i> [ <i>method2...</i> ]	<p>Create a login authentication method list.</p> <ul style="list-style-type: none"> <li>To create a default list that is used when a named list is <i>not</i> specified in the <b>login authentication</b> command, use the <b>default</b> keyword followed by the methods that are to be used in default situations. The default method list is automatically applied to all interfaces.</li> <li>For <i>list-name</i>, specify a character string to name the list you are creating.</li> <li>For <i>method1...</i>, specify the actual method the authentication algorithm tries. The additional methods of authentication are used only if the previous method returns an error, not if it fails.</li> </ul> <p>Select one of these methods:</p> <ul style="list-style-type: none"> <li><b>local</b>—Use the local username database for authentication. You must enter username information in the database. Use the <b>username password</b> global configuration command.</li> <li><b>radius</b>—Use RADIUS authentication. You must configure the RADIUS server before you can use this authentication method. For more information, see the <a href="#">“Identifying the RADIUS Server Host” section on page 11-4</a>.</li> </ul>
Step 4	<b>line</b> [ <b>console</b>   <b>tty</b>   <b>vty</b> ] <i>line-number</i> [ <i>ending-line-number</i> ]	Enter line configuration mode, and configure the lines to which you want to apply the authentication list.
Step 5	<b>login authentication</b> { <b>default</b>   <i>list-name</i> }	<p>Apply the authentication list to a line or set of lines.</p> <ul style="list-style-type: none"> <li>If you specify <b>default</b>, use the default list created with the <b>aaa authentication login</b> command.</li> <li>For <i>list-name</i>, specify the list created with the <b>aaa authentication login</b> command.</li> </ul>
Step 6	<b>end</b>	Return to privileged EXEC mode.
Step 7	<b>show running-config</b>	Verify your entries.
Step 8	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable AAA, use the **no aaa new-model** global configuration command. To disable AAA authentication, use the **no aaa authentication login** { **default** | *list-name* } *method1* [*method2...*] global configuration command. To either disable RADIUS authentication for logins or to return to the default value, use the **no login authentication** { **default** | *list-name* } line configuration command.

## Defining AAA Server Groups

You can configure the access point to use AAA server groups to group existing server hosts for authentication. You select a subset of the configured server hosts and use them for a particular service. The server group is used with a global server-host list, which lists the IP addresses of the selected server hosts.

Server groups also can include multiple host entries for the same server if each entry has a unique identifier (the combination of the IP address and UDP port number), allowing different ports to be individually defined as RADIUS hosts providing a specific AAA service. If you configure two different host entries on the same RADIUS server for the same service (such as accounting), the second configured host entry acts as a fail-over backup to the first one.

You use the **server** group server configuration command to associate a particular server with a defined group server. You can either identify the server by its IP address or identify multiple host instances or entries by using the optional **auth-port** and **acct-port** keywords.

Beginning in privileged EXEC mode, follow these steps to define the AAA server group and associate a particular RADIUS server with it:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>aaa new-model</b>	Enable AAA.
Step 3	<b>radius-server host</b> { <i>hostname</i>   <i>ip-address</i> } [ <b>auth-port</b> <i>port-number</i> ] [ <b>acct-port</b> <i>port-number</i> ] [ <b>timeout</b> <i>seconds</i> ] [ <b>retransmit</b> <i>retries</i> ] [ <b>key</b> <i>string</i> ]	<p>Specify the IP address or host name of the remote RADIUS server host.</p> <ul style="list-style-type: none"> <li>• (Optional) For <b>auth-port</b> <i>port-number</i>, specify the UDP destination port for authentication requests.</li> <li>• (Optional) For <b>acct-port</b> <i>port-number</i>, specify the UDP destination port for accounting requests.</li> <li>• (Optional) For <b>timeout</b> <i>seconds</i>, specify the time interval that the access point waits for the RADIUS server to reply before retransmitting. The range is 1 to 1000. This setting overrides the <b>radius-server timeout</b> global configuration command setting. If no timeout is set with the <b>radius-server host</b> command, the setting of the <b>radius-server timeout</b> command is used.</li> <li>• (Optional) For <b>retransmit</b> <i>retries</i>, specify the number of times a RADIUS request is resent to a server if that server is not responding or responding slowly. The range is 1 to 1000. If no retransmit value is set with the <b>radius-server host</b> command, the setting of the <b>radius-server retransmit</b> global configuration command is used.</li> <li>• (Optional) For <b>key</b> <i>string</i>, specify the authentication and encryption key used between the access point and the RADIUS daemon running on the RADIUS server.</li> </ul> <p><b>Note</b> The key is a text string that must match the encryption key used on the RADIUS server. Always configure the key as the last item in the <b>radius-server host</b> command. Leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks are part of the key.</p> <p>To configure the access point to recognize more than one host entry associated with a single IP address, enter this command as many times as necessary, making sure that each UDP port number is different. The access point software searches for hosts in the order in which you specify them. Set the timeout, retransmit, and encryption key values to use with the specific RADIUS host.</p>

	Command	Purpose
Step 4	<code>aaa group server radius group-name</code>	Define the AAA server-group with a group name. This command puts the access point in a server group configuration mode.
Step 5	<code>server ip-address</code>	Associate a particular RADIUS server with the defined server group. Repeat this step for each RADIUS server in the AAA server group. Each server in the group must be previously defined in Step 2.
Step 6	<code>end</code>	Return to privileged EXEC mode.
Step 7	<code>show running-config</code>	Verify your entries.
Step 8	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.
Step 9		Enable RADIUS login authentication. See the <a href="#">“Configuring RADIUS Login Authentication”</a> section on page 6-8.

To remove the specified RADIUS server, use the **no radius-server host** *hostname | ip-address* global configuration command. To remove a server group from the configuration list, use the **no aaa group server radius group-name** global configuration command. To remove the IP address of a RADIUS server, use the **no server ip-address** server group configuration command.

In this example, the access point is configured to recognize two different RADIUS group servers (*group1* and *group2*). Group1 has two different host entries on the same RADIUS server configured for the same services. The second host entry acts as a fail-over backup to the first entry.

```
AP(config)# aaa new-model
AP(config)# radius-server host 172.20.0.1 auth-port 1000 acct-port 1001
AP(config)# radius-server host 172.10.0.1 auth-port 1645 acct-port 1646
AP(config)# aaa group server radius group1
AP(config-sg-radius)# server 172.20.0.1 auth-port 1000 acct-port 1001
AP(config-sg-radius)# exit
AP(config)# aaa group server radius group2
AP(config-sg-radius)# server 172.20.0.1 auth-port 2000 acct-port 2001
AP(config-sg-radius)# exit
```

## Configuring RADIUS Authorization for User Privileged Access and Network Services

AAA authorization limits the services available to a user. When AAA authorization is enabled, the access point uses information retrieved from the user's profile, which is in the local user database or on the security server, to configure the user's session. The user is granted access to a requested service only if the information in the user profile allows it.

You can use the **aaa authorization** global configuration command with the **radius** keyword to set parameters that restrict a user's network access to privileged EXEC mode.

The **aaa authorization exec radius local** command sets these authorization parameters:

- Use RADIUS for privileged EXEC access authorization if authentication was performed by using RADIUS.
- Use the local database if authentication was not performed by using RADIUS.



### Note

Authorization is bypassed for authenticated users who log in through the CLI even if authorization has been configured.

Beginning in privileged EXEC mode, follow these steps to specify RADIUS authorization for privileged EXEC access and network services:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>aaa authorization network radius</b>	Configure the access point for user RADIUS authorization for all network-related service requests.
Step 3	<b>aaa authorization exec radius</b>	Configure the access point for user RADIUS authorization to determine if the user has privileged EXEC access.  The <b>exec</b> keyword might return user profile information (such as <b>autocommand</b> information).
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your entries.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable authorization, use the **no aaa authorization {network | exec} method1** global configuration command.

## Displaying the RADIUS Configuration

To display the RADIUS configuration, use the **show running-config** privileged EXEC command.

# Configuring the Access Point for Local Authentication and Authorization

You can configure AAA to operate without a server by setting the access point to implement AAA in local mode. The access point then handles authentication and authorization. No accounting is available in this configuration.

Beginning in privileged EXEC mode, follow these steps to configure the access point for local AAA:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>aaa new-model</b>	Enable AAA.
Step 3	<b>aaa authentication login default local</b>	Set the login authentication to use the local username database. The <b>default</b> keyword applies the local user database authentication to all interfaces.
Step 4	<b>aaa authorization exec local</b>	Configure user AAA authorization to determine if the user is allowed to run an EXEC shell by checking the local database.
Step 5	<b>aaa authorization network local</b>	Configure user AAA authorization for all network-related service requests.

	Command	Purpose
Step 6	<code>username name [privilege level] {password encryption-type password}</code>	Enter the local database, and establish a username-based authentication system.  Repeat this command for each user. <ul style="list-style-type: none"> <li>For <i>name</i>, specify the user ID as one word. Spaces and quotation marks are not allowed.</li> <li>(Optional) For <i>level</i>, specify the privilege level the user has after gaining access. The range is 0 to 15. Level 15 gives privileged EXEC mode access. Level 0 gives user EXEC mode access.</li> <li>For <i>encryption-type</i>, enter <b>0</b> to specify that an unencrypted password follows. Enter <b>7</b> to specify that a hidden password follows.</li> <li>For <i>password</i>, specify the password the user must enter to gain access to the access point. The password must be from 1 to 25 characters, can contain embedded spaces, and must be the last option specified in the <b>username</b> command.</li> </ul>
Step 7	<code>end</code>	Return to privileged EXEC mode.
Step 8	<code>show running-config</code>	Verify your entries.
Step 9	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

To disable AAA, use the **no aaa new-model** global configuration command. To disable authorization, use the **no aaa authorization {network | exec} method1** global configuration command.

## Configuring the Access Point for Secure Shell

This section describes how to configure the Secure Shell (SSH) feature.



### Note

For complete syntax and usage information for the commands used in this section, refer to the “*Secure Shell Commands*” section in the *Cisco IOS Security Command Reference for Release 12.2*.

## Understanding SSH

SSH is a protocol that provides a secure, remote connection to a Layer 2 or a Layer 3 device. There are two versions of SSH: SSH version 1 and SSH version 2. This software release supports only SSH version 1.

SSH provides more security for remote connections than Telnet by providing strong encryption when a device is authenticated. The SSH feature has an SSH server and an SSH integrated client. The client supports these user authentication methods:

- RADIUS (for more information, see the “[Controlling Access Point Access with RADIUS](#)” section on page 6-7)
- Local authentication and authorization (for more information, see the “[Configuring the Access Point for Local Authentication and Authorization](#)” section on page 6-12)

For more information about SSH, refer to the “*Configuring Secure Shell*” section in the *Cisco IOS Security Configuration Guide for Release 12.2*.

**Note**

The SSH feature in this software release does not support IP Security (IPSec).

## Configuring SSH

Before configuring SSH, download the crypto software image from Cisco.com. For more information, refer to the release notes for this release.

For information about configuring SSH and displaying SSH settings, refer to the “*Configuring Secure Shell*” section in the *Cisco IOS Security Configuration Guide for Release 12.2*.

## Managing the System Time and Date

You can manage the system time and date on your access point automatically, using the Network Time Protocol (NTP), or manually, by setting the time and date on the access point.

**Note**

For complete syntax and usage information for the commands used in this section, refer to the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.2*.

This section contains this configuration information:

- [Understanding the System Clock, page 6-14](#)
- [Understanding Network Time Protocol, page 6-15](#)
- [Configuring NTP, page 6-16](#)
- [Configuring Time and Date Manually, page 6-24](#)

## Understanding the System Clock

The heart of the time service is the system clock. This clock runs from the moment the system starts up and keeps track of the date and time.

The system clock can then be set from these sources:

- Network Time Protocol
- Manual configuration

The system clock can provide time to these services:

- User **show** commands
- Logging and debugging messages

The system clock determines time internally based on Universal Time Coordinated (UTC), also known as Greenwich Mean Time (GMT). You can configure information about the local time zone and summer time (daylight saving time) so that the time is correctly displayed for the local time zone.

The system clock keeps track of whether the time is *authoritative* or not (that is, whether it has been set by a time source considered to be authoritative). If it is not authoritative, the time is available only for display purposes and is not redistributed. For configuration information, see the “[Configuring Time and Date Manually](#)” section on page 6-24.



## Understanding Network Time Protocol

The NTP is designed to time-synchronize a network of devices. NTP runs over User Datagram Protocol (UDP), which runs over IP. NTP is documented in RFC 1305.

An NTP network usually gets its time from an authoritative time source, such as a radio clock or an atomic clock attached to a time server. NTP then distributes this time across the network. NTP is extremely efficient; no more than one packet per minute is necessary to synchronize two devices to within a millisecond of one another.

NTP uses the concept of a *stratum* to describe how many NTP hops away a device is from an authoritative time source. A stratum 1 time server has a radio or atomic clock directly attached, a stratum 2 time server receives its time through NTP from a stratum 1 time server, and so on. A device running NTP automatically chooses as its time source the device with the lowest stratum number with which it communicates through NTP. This strategy effectively builds a self-organizing tree of NTP speakers.

NTP avoids synchronizing to a device whose time might not be accurate by never synchronizing to a device that is not synchronized. NTP also compares the time reported by several devices and does not synchronize to a device whose time is significantly different than the others, even if its stratum is lower.

The communications between devices running NTP (known as *associations*) are usually statically configured; each device is given the IP address of all devices with which it should form associations. Accurate timekeeping is possible by exchanging NTP messages between each pair of devices with an association. However, in a LAN environment, NTP can be configured to use IP broadcast messages instead. This alternative reduces configuration complexity because each device can simply be configured to send or receive broadcast messages. However, in that case, information flow is one-way only.

The time kept on a device is a critical resource; you should use the security features of NTP to avoid the accidental or malicious setting of an incorrect time. Two mechanisms are available: an access-list-based restriction scheme and an encrypted authentication mechanism.


Cisco's implementation of NTP does not support stratum 1 service; it is not possible to connect to a radio or atomic clock. We recommend that the time service for your network be derived from the public NTP servers available on the IP Internet. [Figure 6-1](#) shows a typical network example using NTP.

If the network is isolated from the Internet, Cisco's implementation of NTP allows a device to act as though it is synchronized through NTP, when in fact it has determined the time by using other means. Other devices then synchronize to that device through NTP.

When multiple sources of time are available, NTP is always considered to be more authoritative. NTP time overrides the time set by any other method.

Several manufacturers include NTP software for their host systems, and a publicly available version for systems running UNIX and its various derivatives is also available. This software allows host systems to be time-synchronized as well.

Figure 6-1 Typical NTP Network Configuration



43269

## Configuring NTP

Cisco Aironet 1100 Series Access Points do not have a hardware-supported clock, and they cannot function as an NTP master clock to which peers synchronize themselves when an external NTP source is not available. These access points also have no hardware support for a calendar. As a result, the `ntp update-calendar` and the `ntp master` global configuration commands are not available.

This section contains this configuration information:

- [Default NTP Configuration, page 6-17](#)
- [Configuring NTP Authentication, page 6-17](#)
- [Configuring NTP Associations, page 6-19](#)
- [Configuring NTP Broadcast Service, page 6-20](#)
- [Configuring NTP Access Restrictions, page 6-21](#)
- [Configuring the Source IP Address for NTP Packets, page 6-23](#)
- [Displaying the NTP Configuration, page 6-24](#)

## Default NTP Configuration

Table 6-2 shows the default NTP configuration.

**Table 6-2 Default NTP Configuration**

Feature	Default Setting
NTP authentication	Disabled. No authentication key is specified.
NTP peer or server associations	None configured.
NTP broadcast service	Disabled; no interface sends or receives NTP broadcast packets.
NTP access restrictions	No access control is specified.
NTP packet source IP address	The source address is determined by the outgoing interface.

NTP is disabled by default.

## Configuring NTP Authentication

This procedure must be coordinated with the administrator of the NTP server; the information you configure in this procedure must be matched by the servers used by the access point to synchronize its time to the NTP server.

Beginning in privileged EXEC mode, follow these steps to authenticate the associations (communications between devices running NTP that provide for accurate timekeeping) with other devices for security purposes:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>ntp authenticate</b>	Enable the NTP authentication feature, which is disabled by default.
Step 3	<b>ntp authentication-key <i>number</i> md5 <i>value</i></b>	<p>Define the authentication keys. By default, none are defined.</p> <ul style="list-style-type: none"> <li>For <i>number</i>, specify a key number. The range is 1 to 4294967295.</li> <li><b>md5</b> specifies that message authentication support is provided by using the message digest algorithm 5 (MD5).</li> <li>For <i>value</i>, enter an arbitrary string of up to eight characters for the key.</li> </ul> <p>The access point does not synchronize to a device unless both have one of these authentication keys, and the key number is specified by the <b>ntp trusted-key <i>key-number</i></b> command.</p>

	Command	Purpose
Step 4	<b>ntp trusted-key</b> <i>key-number</i>	Specify one or more key numbers (defined in Step 3) that a peer NTP device must provide in its NTP packets for this access point to synchronize to it.  By default, no trusted keys are defined.  For <i>key-number</i> , specify the key defined in Step 3.  This command provides protection against accidentally synchronizing the access point to a device that is not trusted.
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>show running-config</b>	Verify your entries.
Step 7	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable NTP authentication, use the **no ntp authenticate** global configuration command. To remove an authentication key, use the **no ntp authentication-key** *number* global configuration command. To disable authentication of the identity of a device, use the **no ntp trusted-key** *key-number* global configuration command.

This example shows how to configure the access point to synchronize only to devices providing authentication key 42 in the device's NTP packets:

```
AP(config)# ntp authenticate
AP(config)# ntp authentication-key 42 md5 aNiceKey
AP(config)# ntp trusted-key 42
```

## Configuring NTP Associations

An NTP association can be a peer association (this access point can either synchronize to the other device or allow the other device to synchronize to it), or it can be a server association (meaning that only this access point synchronizes to the other device, and not the other way around).

Beginning in privileged EXEC mode, follow these steps to form an NTP association with another device:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>ntp peer</b> <i>ip-address</i> [ <b>version</b> <i>number</i> ] [ <b>key</b> <i>keyid</i> ] [ <b>source</b> <i>interface</i> ] [ <b>prefer</b> ]	Configure the access point system clock to synchronize a peer or to be synchronized by a peer (peer association).
	or	or
	<b>ntp server</b> <i>ip-address</i> [ <b>version</b> <i>number</i> ] [ <b>key</b> <i>keyid</i> ] [ <b>source</b> <i>interface</i> ] [ <b>prefer</b> ]	Configure the access point system clock to be synchronized by a time server (server association).
		No peer or server associations are defined by default. <ul style="list-style-type: none"> <li>For <i>ip-address</i> in a peer association, specify either the IP address of the peer providing, or being provided, the clock synchronization. For a server association, specify the IP address of the time server providing the clock synchronization.</li> <li>(Optional) For <i>number</i>, specify the NTP version number. The range is 1 to 3. By default, version 3 is selected.</li> <li>(Optional) For <i>keyid</i>, enter the authentication key defined with the <b>ntp authentication-key</b> global configuration command.</li> <li>(Optional) For <i>interface</i>, specify the interface from which to pick the IP source address. By default, the source IP address is taken from the outgoing interface.</li> <li>(Optional) Enter the <b>prefer</b> keyword to make this peer or server the preferred one that provides synchronization. This keyword reduces switching back and forth between peers and servers.</li> </ul>
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

You need to configure only one end of an association; the other device can automatically establish the association. If you are using the default NTP version (version 3) and NTP synchronization does not occur, try using NTP version 2. Many NTP servers on the Internet run version 2.

To remove a peer or server association, use the **no ntp peer** *ip-address* or the **no ntp server** *ip-address* global configuration command.

This example shows how to configure the access point to synchronize its system clock with the clock of the peer at IP address 172.16.22.44 using NTP version 2:

```
AP(config)# ntp server 172.16.22.44 version 2
```

## Configuring NTP Broadcast Service

The communications between devices running NTP (known as *associations*) are usually statically configured; each device is given the IP addresses of all devices with which it should form associations. Accurate timekeeping is possible by exchanging NTP messages between each pair of devices with an association. However, in a LAN environment, NTP can be configured to use IP broadcast messages instead. This alternative reduces configuration complexity because each device can simply be configured to send or receive broadcast messages. However, the information flow is one-way only.

The access point can send or receive NTP broadcast packets on an interface-by-interface basis if there is an NTP broadcast server, such as a router, broadcasting time information on the network. The access point can send NTP broadcast packets to a peer so that the peer can synchronize to it. The access point can also receive NTP broadcast packets to synchronize its own clock. This section provides procedures for both sending and receiving NTP broadcast packets.

Beginning in privileged EXEC mode, follow these steps to configure the access point to send NTP broadcast packets to peers so that they can synchronize their clock to the access point:

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>interface interface-id</code>	Enter interface configuration mode, and specify the interface to send NTP broadcast packets.
Step 3	<code>ntp broadcast [version number] [key keyid] [destination-address]</code>	<p>Enable the interface to send NTP broadcast packets to a peer.</p> <p>By default, this feature is disabled on all interfaces.</p> <ul style="list-style-type: none"> <li>• (Optional) For <i>number</i>, specify the NTP version number. The range is 1 to 3. If you do not specify a version, version 3 is used.</li> <li>• (Optional) For <i>keyid</i>, specify the authentication key to use when sending packets to the peer.</li> <li>• (Optional) For <i>destination-address</i>, specify the IP address of the peer that is synchronizing its clock to this access point.</li> </ul>
Step 4	<code>end</code>	Return to privileged EXEC mode.
Step 5	<code>show running-config</code>	Verify your entries.
Step 6	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.
Step 7		Configure the connected peers to receive NTP broadcast packets as described in the next procedure.

To disable the interface from sending NTP broadcast packets, use the **no ntp broadcast** interface configuration command.

This example shows how to configure an interface to send NTP version 2 packets:

```
AP(config)# interface gigabitethernet0/1
AP(config-if)# ntp broadcast version 2
```

Beginning in privileged EXEC mode, follow these steps to configure the access point to receive NTP broadcast packets from connected peers:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface</b> <i>interface-id</i>	Enter interface configuration mode, and specify the interface to receive NTP broadcast packets.
Step 3	<b>ntp broadcast client</b>	Enable the interface to receive NTP broadcast packets. By default, no interfaces receive NTP broadcast packets.
Step 4	<b>exit</b>	Return to global configuration mode.
Step 5	<b>ntp broadcastdelay</b> <i>microseconds</i>	(Optional) Change the estimated round-trip delay between the access point and the NTP broadcast server. The default is 3000 microseconds; the range is 1 to 999999.
Step 6	<b>end</b>	Return to privileged EXEC mode.
Step 7	<b>show running-config</b>	Verify your entries.
Step 8	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable an interface from receiving NTP broadcast packets, use the **no ntp broadcast client** interface configuration command. To change the estimated round-trip delay to the default, use the **no ntp broadcastdelay** global configuration command.

This example shows how to configure an interface to receive NTP broadcast packets:

```
AP(config)# interface gigabitethernet0/1
AP(config-if)# ntp broadcast client
```

## Configuring NTP Access Restrictions

You can control NTP access on two levels as described in these sections:

- [Creating an Access Group and Assigning a Basic IP Access List, page 6-22](#)
- [Disabling NTP Services on a Specific Interface, page 6-23](#)

## Creating an Access Group and Assigning a Basic IP Access List

Beginning in privileged EXEC mode, follow these steps to control access to NTP services by using access lists:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>ntp access-group { query-only   serve-only   serve   peer } access-list-number</b>	<p>Create an access group, and apply a basic IP access list.</p> <p>The keywords have these meanings:</p> <ul style="list-style-type: none"> <li>• <b>query-only</b>—Allows only NTP control queries.</li> <li>• <b>serve-only</b>—Allows only time requests.</li> <li>• <b>serve</b>—Allows time requests and NTP control queries, but does not allow the access point to synchronize to the remote device.</li> <li>• <b>peer</b>—Allows time requests and NTP control queries and allows the access point to synchronize to the remote device.</li> </ul> <p>For <i>access-list-number</i>, enter a standard IP access list number from 1 to 99.</p>
Step 3	<b>access-list access-list-number permit source [source-wildcard]</b>	<p>Create the access list.</p> <ul style="list-style-type: none"> <li>• For <i>access-list-number</i>, enter the number specified in Step 2.</li> <li>• Enter the <b>permit</b> keyword to permit access if the conditions are matched.</li> <li>• For <i>source</i>, enter the IP address of the device that is permitted access to the access point.</li> <li>• (Optional) For <i>source-wildcard</i>, enter the wildcard bits to be applied to the source.</li> </ul> <p><b>Note</b> When creating an access list, remember that, by default, the end of the access list contains an implicit deny statement for everything if it did not find a match before reaching the end.</p>
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your entries.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

The access group keywords are scanned in this order, from least restrictive to most restrictive:

1. **peer**—Allows time requests and NTP control queries and allows the access point to synchronize itself to a device whose address passes the access list criteria.
2. **serve**—Allows time requests and NTP control queries, but does not allow the access point to synchronize itself to a device whose address passes the access list criteria.
3. **serve-only**—Allows only time requests from a device whose address passes the access list criteria.
4. **query-only**—Allows only NTP control queries from a device whose address passes the access list criteria.



If the source IP address matches the access lists for more than one access type, the first type is granted. If no access groups are specified, all access types are granted to all devices. If any access groups are specified, only the specified access types are granted.

To remove access control to the access point NTP services, use the **no ntp access-group { query-only | serve-only | serve | peer }** global configuration command.

This example shows how to configure the access point to allow itself to synchronize to a peer from access list 99. However, the access point restricts access to allow only time requests from access list 42:

```
AP# configure terminal
AP(config)# ntp access-group peer 99
AP(config)# ntp access-group serve-only 42
AP(config)# access-list 99 permit 172.20.130.5
AP(config)# access list 42 permit 172.20.130.6
```

### Disabling NTP Services on a Specific Interface

NTP services are enabled on all interfaces by default.

Beginning in privileged EXEC mode, follow these steps to disable NTP packets from being received on an interface:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface <i>interface-id</i></b>	Enter interface configuration mode, and specify the interface to disable.
Step 3	<b>ntp disable</b>	Disable NTP packets from being received on the interface. By default, all interfaces receive NTP packets.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your entries.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To re-enable receipt of NTP packets on an interface, use the **no ntp disable** interface configuration command.

### Configuring the Source IP Address for NTP Packets

When the access point sends an NTP packet, the source IP address is normally set to the address of the interface through which the NTP packet is sent. Use the **ntp source** global configuration command when you want to use a particular source IP address for all NTP packets. The address is taken from the specified interface. This command is useful if the address on an interface cannot be used as the destination for reply packets.

Beginning in privileged EXEC mode, follow these steps to configure a specific interface from which the IP source address is to be taken:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>ntp source</b> <i>type number</i>	Specify the interface type and number from which the IP source address is taken.  By default, the source address is determined by the outgoing interface.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

The specified interface is used for the source address for all packets sent to all destinations. If a source address is to be used for a specific association, use the **source** keyword in the **ntp peer** or **ntp server** global configuration command as described in the “[Configuring NTP Associations](#)” section on page 6-19.

## Displaying the NTP Configuration

You can use two privileged EXEC commands to display NTP information:

- **show ntp associations [detail]**
- **show ntp status**

For detailed information about the fields in these displays, refer to the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.1*.

## Configuring Time and Date Manually

If no other source of time is available, you can manually configure the time and date after the system is restarted. The time remains accurate until the next system restart. We recommend that you use manual configuration only as a last resort. If you have an outside source to which the access point can synchronize, you do not need to manually set the system clock.

This section contains this configuration information:

- [Setting the System Clock, page 6-25](#)
- [Displaying the Time and Date Configuration, page 6-25](#)
- [Configuring the Time Zone, page 6-26](#)
- [Configuring Summer Time \(Daylight Saving Time\), page 6-27](#)

## Setting the System Clock

If you have an outside source on the network that provides time services, such as an NTP server, you do not need to manually set the system clock.

Beginning in privileged EXEC mode, follow these steps to set the system clock:

	Command	Purpose
Step 1	<code>clock set hh:mm:ss day month year</code> or <code>clock set hh:mm:ss month day year</code>	Manually set the system clock using one of these formats. <ul style="list-style-type: none"> <li>For <i>hh:mm:ss</i>, specify the time in hours (24-hour format), minutes, and seconds. The time specified is relative to the configured time zone.</li> <li>For <i>day</i>, specify the day by date in the month.</li> <li>For <i>month</i>, specify the month by name.</li> <li>For <i>year</i>, specify the year (no abbreviation).</li> </ul>
Step 2	<code>show running-config</code>	Verify your entries.
Step 3	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

This example shows how to manually set the system clock to 1:32 p.m. on July 23, 2001:

```
AP# clock set 13:32:00 23 July 2001
```

## Displaying the Time and Date Configuration

To display the time and date configuration, use the `show clock [detail]` privileged EXEC command.

The system clock keeps an *authoritative* flag that shows whether the time is authoritative (believed to be accurate). If the system clock has been set by a timing source such as NTP, the flag is set. If the time is not authoritative, it is used only for display purposes. Until the clock is authoritative and the *authoritative* flag is set, the flag prevents peers from synchronizing to the clock when the peers' time is invalid.

The symbol that precedes the `show clock` display has this meaning:

- \*—Time is not authoritative.
- (blank)—Time is authoritative.
- .—Time is authoritative, but NTP is not synchronized.

## Configuring the Time Zone

Beginning in privileged EXEC mode, follow these steps to manually configure the time zone:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>clock timezone</b> <i>zone hours-offset</i> [ <i>minutes-offset</i> ]	Set the time zone.  The access point keeps internal time in universal time coordinated (UTC), so this command is used only for display purposes and when the time is manually set. <ul style="list-style-type: none"> <li>For <i>zone</i>, enter the name of the time zone to be displayed when standard time is in effect. The default is UTC.</li> <li>For <i>hours-offset</i>, enter the hours offset from UTC.</li> <li>(Optional) For <i>minutes-offset</i>, enter the minutes offset from UTC.</li> </ul>
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

The *minutes-offset* variable in the **clock timezone** global configuration command is available for those cases where a local time zone is a percentage of an hour different from UTC. For example, the time zone for some sections of Atlantic Canada (AST) is UTC-3.5, where the 3 means 3 hours and .5 means 50 percent. In this case, the necessary command is **clock timezone AST -3 30**.

To set the time to UTC, use the **no clock timezone** global configuration command.

## Configuring Summer Time (Daylight Saving Time)

Beginning in privileged EXEC mode, follow these steps to configure summer time (daylight saving time) in areas where it starts and ends on a particular day of the week each year:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>clock summer-time zone recurring</b> [ <i>week day month hh:mm week day month</i> <i>hh:mm [offset]</i> ]	Configure summer time to start and end on the specified days every year. Summer time is disabled by default. If you specify <b>clock summer-time zone recurring</b> without parameters, the summer time rules default to the United States rules. <ul style="list-style-type: none"> <li>For <i>zone</i>, specify the name of the time zone (for example, PDT) to be displayed when summer time is in effect.</li> <li>(Optional) For <i>week</i>, specify the week of the month (1 to 5 or <b>last</b>).</li> <li>(Optional) For <i>day</i>, specify the day of the week (Sunday, Monday...).</li> <li>(Optional) For <i>month</i>, specify the month (January, February...).</li> <li>(Optional) For <i>hh:mm</i>, specify the time (24-hour format) in hours and minutes.</li> <li>(Optional) For <i>offset</i>, specify the number of minutes to add during summer time. The default is 60.</li> </ul>
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

The first part of the **clock summer-time** global configuration command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is after the ending month, the system assumes that you are in the southern hemisphere.

This example shows how to specify that summer time starts on the first Sunday in April at 02:00 and ends on the last Sunday in October at 02:00:

```
AP(config)# clock summer-time PDT recurring 1 Sunday April 2:00 last Sunday October 2:00
```

Beginning in privileged EXEC mode, follow these steps if summer time in your area does not follow a recurring pattern (configure the exact date and time of the next summer time events):

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>clock summer-time zone date</b> [ <i>month date year hh:mm month date year hh:mm [offset]</i> ]  or <b>clock summer-time zone date</b> [ <i>date month year hh:mm date month year hh:mm [offset]</i> ]	Configure summer time to start on the first date and end on the second date.  Summer time is disabled by default. <ul style="list-style-type: none"> <li>For <i>zone</i>, specify the name of the time zone (for example, PDT) to be displayed when summer time is in effect.</li> <li>(Optional) For <i>week</i>, specify the week of the month (1 to 5 or <b>last</b>).</li> <li>(Optional) For <i>day</i>, specify the day of the week (Sunday, Monday...).</li> <li>(Optional) For <i>month</i>, specify the month (January, February...).</li> <li>(Optional) For <i>hh:mm</i>, specify the time (24-hour format) in hours and minutes.</li> <li>(Optional) For <i>offset</i>, specify the number of minutes to add during summer time. The default is 60.</li> </ul>
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

The first part of the **clock summer-time** global configuration command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is after the ending month, the system assumes that you are in the southern hemisphere.

To disable summer time, use the **no clock summer-time** global configuration command.

This example shows how to set summer time to start on October 12, 2000, at 02:00, and end on April 26, 2001, at 02:00:

```
AP(config)# clock summer-time pdt date 12 October 2000 2:00 26 April 2001 2:00
```

# Configuring a System Name and Prompt

You configure the system name on the access point to identify it. By default, the system name and prompt are *ap*.

If you have not configured a system prompt, the first 20 characters of the system name are used as the system prompt. A greater-than symbol (>) is appended. The prompt is updated whenever the system name changes, unless you manually configure the prompt by using the **prompt** global configuration command.



## Note

For complete syntax and usage information for the commands used in this section, refer to the *Cisco IOS Configuration Fundamentals Command Reference* and the *Cisco IOS IP and IP Routing Command Reference for Release 12.1*.

This section contains this configuration information:

- [Default System Name and Prompt Configuration, page 6-29](#)
- [Configuring a System Name, page 6-29](#)
- [Understanding DNS, page 6-30](#)

## Default System Name and Prompt Configuration

The default access point system name and prompt is *ap*.

## Configuring a System Name

Beginning in privileged EXEC mode, follow these steps to manually configure a system name:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>hostname <i>name</i></b>	Manually configure a system name.  The default setting is <i>ap</i> .  The name must follow the rules for ARPANET host names. They must start with a letter, end with a letter or digit, and have as interior characters only letters, digits, and hyphens. Names can be up to 63 characters.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

When you set the system name, it is also used as the system prompt.

To return to the default host name, use the **no hostname** global configuration command.

## Understanding DNS

The DNS protocol controls the Domain Name System (DNS), a distributed database with which you can map host names to IP addresses. When you configure DNS on your access point, you can substitute the host name for the IP address with all IP commands, such as **ping**, **telnet**, **connect**, and related Telnet support operations.

IP defines a hierarchical naming scheme that allows a device to be identified by its location or domain. Domain names are pieced together with periods (.) as the delimiting characters. For example, Cisco Systems is a commercial organization that IP identifies by a *com* domain name, so its domain name is *cisco.com*. A specific device in this domain, such as the File Transfer Protocol (FTP) system, is identified as *ftp.cisco.com*.

To keep track of domain names, IP has defined the concept of a domain name server, which holds a cache (or database) of names mapped to IP addresses. To map domain names to IP addresses, you must first identify the host names, specify the name server that is present on your network, and enable the DNS.

This section contains this configuration information:

- [Default DNS Configuration, page 6-30](#)
- [Setting Up DNS, page 6-30](#)
- [Displaying the DNS Configuration, page 6-31](#)

## Default DNS Configuration

Table 6-3 shows the default DNS configuration.

**Table 6-3** Default DNS Configuration

Feature	Default Setting
DNS enable state	Disabled.
DNS default domain name	None configured.
DNS servers	No name server addresses are configured.

## Setting Up DNS

Beginning in privileged EXEC mode, follow these steps to set up your access point to use the DNS:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>ip domain-name</b> <i>name</i>	Define a default domain name that the software uses to complete unqualified host names (names without a dotted-decimal domain name).  Do not include the initial period that separates an unqualified name from the domain name.  At boot time, no domain name is configured; however, if the access point configuration comes from a BOOTP or Dynamic Host Configuration Protocol (DHCP) server, then the default domain name might be set by the BOOTP or DHCP server (if the servers were configured with this information).



	Command	Purpose
Step 3	<b>ip name-server</b> <i>server-address1</i> [ <i>server-address2</i> ... <i>server-address6</i> ]	Specify the address of one or more name servers to use for name and address resolution.  You can specify up to six name servers. Separate each server address with a space. The first server specified is the primary server. The access point sends DNS queries to the primary server first. If that query fails, the backup servers are queried.
Step 4	<b>ip domain-lookup</b>	(Optional) Enable DNS-based host name-to-address translation on your access point. This feature is enabled by default.  If your network devices require connectivity with devices in networks for which you do not control name assignment, you can dynamically assign device names that uniquely identify your devices by using the global Internet naming scheme (DNS).
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>show running-config</b>	Verify your entries.
Step 7	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

If you use the access point IP address as its host name, the IP address is used and no DNS query occurs. If you configure a host name that contains no periods (.), a period followed by the default domain name is appended to the host name before the DNS query is made to map the name to an IP address. The default domain name is the value set by the **ip domain-name** global configuration command. If there is a period (.) in the host name, the IOS software looks up the IP address without appending any default domain name to the host name.

To remove a domain name, use the **no ip domain-name** *name* global configuration command. To remove a name server address, use the **no ip name-server** *server-address* global configuration command. To disable DNS on the access point, use the **no ip domain-lookup** global configuration command.

## Displaying the DNS Configuration

To display the DNS configuration information, use the **show running-config** privileged EXEC command.

## Creating a Banner

You can configure a message-of-the-day (MOTD) and a login banner. The MOTD banner displays on all connected terminals at login and is useful for sending messages that affect all network users (such as impending system shutdowns).

The login banner also displays on all connected terminals. It is displayed after the MOTD banner and before the login prompts.



### Note

For complete syntax and usage information for the commands used in this section, refer to the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.1*.

This section contains this configuration information:

- [Default Banner Configuration, page 6-32](#)
- [Configuring a Message-of-the-Day Login Banner, page 6-32](#)
- [Configuring a Login Banner, page 6-33](#)

## Default Banner Configuration

The MOTD and login banners are not configured.

## Configuring a Message-of-the-Day Login Banner

You can create a single or multiline message banner that appears on the screen when someone logs into the access point.

Beginning in privileged EXEC mode, follow these steps to configure a MOTD login banner:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>banner motd</b> <i>c message c</i>	Specify the message of the day.  For <i>c</i> , enter the delimiting character of your choice, such as a pound sign (#), and press the <b>Return</b> key. The delimiting character signifies the beginning and end of the banner text. Characters after the ending delimiter are discarded.  For <i>message</i> , enter a banner message up to 255 characters. You cannot use the delimiting character in the message.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To delete the MOTD banner, use the **no banner motd** global configuration command.

This example shows how to configure a MOTD banner for the access point using the pound sign (#) symbol as the beginning and ending delimiter:

```
AP(config)# banner motd #
This is a secure site. Only authorized users are allowed.
For access, contact technical support.
#
AP(config)#
```

This example shows the banner displayed from the previous configuration:

```
Unix> telnet 172.2.5.4
Trying 172.2.5.4...
Connected to 172.2.5.4.
Escape character is '^]'.
```

```
This is a secure site. Only authorized users are allowed.
For access, contact technical support.
```

```
User Access Verification
```

```
Password:
```

## Configuring a Login Banner

You can configure a login banner to be displayed on all connected terminals. This banner is displayed after the MOTD banner and before the login prompt.

Beginning in privileged EXEC mode, follow these steps to configure a login banner:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>banner login c message c</b>	Specify the login message.  For <i>c</i> , enter the delimiting character of your choice, such as a pound sign (#), and press the <b>Return</b> key. The delimiting character signifies the beginning and end of the banner text. Characters after the ending delimiter are discarded.  For <i>message</i> , enter a login message up to 255 characters. You cannot use the delimiting character in the message.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To delete the login banner, use the **no banner login** global configuration command.

This example shows how to configure a login banner for the access point using the dollar sign (\$) symbol as the beginning and ending delimiter:

```
AP(config)# banner login $
Access for authorized users only. Please enter your username and password.
$
AP(config)#
```





## Configuring Radio Settings

---

This chapter describes how to configure radio settings for your access point. This chapter includes these sections:

- [Disabling and Enabling the Radio Interface, page 7-2](#)
- [Configuring the Role in Radio Network, page 7-2](#)
- [Configuring Radio Data Rates, page 7-3](#)
- [Configuring Radio Transmit Power, page 7-5](#)
- [Configuring Radio Channel Settings, page 7-6](#)
- [Enabling and Disabling World-Mode, page 7-7](#)
- [Disabling and Enabling Short Radio Preambles, page 7-7](#)
- [Configuring Transmit and Receive Antennas, page 7-8](#)
- [Disabling and Enabling Aironet Extensions, page 7-9](#)
- [Configuring the Ethernet Encapsulation Transformation Method, page 7-10](#)
- [Enabling and Disabling Reliable Multicast to Workgroup Bridges, page 7-10](#)
- [Enabling and Disabling Public Secure Packet Forwarding, page 7-11](#)
- [Configuring the Beacon Period and the DTIM, page 7-12](#)
- [Configure RTS Threshold and Retries, page 7-12](#)
- [Configuring the Maximum Data Retries, page 7-13](#)
- [Configuring the Fragmentation Threshold, page 7-13](#)

## Disabling and Enabling the Radio Interface

The access point radio is enabled by default. Beginning in privileged EXEC mode, follow these steps to disable the access point radio:


	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>interface dot11radio 0</code>	Enter interface configuration mode for the radio interface.
Step 3	<code>shutdown</code>	Disable the radio port.
Step 4	<code>end</code>	Return to privileged EXEC mode.
Step 5	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

Use the `no` form of the shutdown command to enable the radio port.

## Configuring the Role in Radio Network

You can configure your access point as a root device that is connected to the wired LAN or as a repeater (non-root) device that is not connected to the wired LAN. [Figure 7-1](#) shows a root access point and a repeater access point.

**Figure 7-1** Root and Repeater Access Points



86302

See [Chapter 18, “Configuring Repeater and Standby Access Points,”](#) for detailed instructions on setting up repeaters.

You can also configure a fallback role for the access point radio. The access point automatically assumes the fallback role when its Ethernet port is disabled or disconnected from the wired LAN. There are two possible fallback roles:

- Repeater—When the Ethernet port is disabled, the access point becomes a repeater and associates to a nearby root access point.
- Shutdown—The access point shuts down its radio and disassociates all client devices.

Beginning in privileged EXEC mode, follow these steps to set the access point’s radio network role and fallback role:

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>interface dot11radio 0</code>	Enter interface configuration mode for the radio interface.
Step 3	<code>station role repeater   root [ fallback { shutdown   repeater } ]</code>	Set the access point role. <ul style="list-style-type: none"> <li>• Set the role to repeater or root.</li> <li>• (Optional) Select the radio’s fallback role. If the access point’s Ethernet port is disabled or disconnected from the wired LAN, the access point can either shut down its radio port or become a repeater access point associated to a nearby root access point.</li> </ul>
Step 4	<code>end</code>	Return to privileged EXEC mode.
Step 5	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

## Configuring Radio Data Rates

You use the data rate settings to choose the data rates the access point uses for data transmission. The rates are expressed in megabits per second. The access point always attempts to transmit at the highest data rate set to **Basic**, also called **Require** on the browser-based interface. If there are obstacles or interference, the access point steps down to the highest rate that allows data transmission. You can set each data rate (1, 2, 5.5, and 11 megabits per second) to one of three states:

- Basic (this is the default state for all data rates)—Allows transmission at this rate for all packets, both unicast and multicast. At least one of the access point's data rates must be set to Basic.
- Enabled—The access point transmits only unicast packets at this rate; multicast packets are sent at one of the data rates set to Basic.
- Disabled—The access point does not transmit data at this rate.



### Note

At least one data rate must be set to **basic**.

You can use the Data Rate settings to set up an access point to serve client devices operating at specific data rates. For example, to set up the access point for 11 megabits per second (Mbps) service only, set the 11-Mbps rate to **Basic** and set the other data rates to **Enabled**. To set up the access point to serve only client devices operating at 1 and 2 Mbps, set 1 and 2 to **Basic** and set the rest of the data rates to **Enabled**.

You can also configure the access point to set the data rates automatically to optimize either range or throughput. When you enter **range** for the data rate setting, the access point sets the 1 Mbps rate to basic and the other rates to **enabled**. When you enter throughput for the data rate setting, the access point sets all four data rates to **basic**.

Beginning in privileged EXEC mode, follow these steps to set the access point's radio network role and fallback role:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>speed</b> { [1.0] [11.0] [2.0] [5.5] [basic-1.0] [basic-11.0] [basic-2.0] [basic-5.5]   <b>range</b>   <b>throughput</b> }	Set each data rate to <b>basic</b> or <b>enabled</b> , or enter <b>range</b> to optimize access point range or <b>throughput</b> to optimize throughput. <ul style="list-style-type: none"> <li>• (Optional) Enter <b>1.0</b>, <b>2.0</b>, <b>5.5</b>, and <b>11.0</b> to set these data rates to <b>enabled</b>.</li> <li>• (Optional) Enter <b>basic-1.0</b>, <b>basic-2.0</b>, <b>basic-5.5</b>, and <b>basic-11.0</b> to set these data rates to <b>basic</b>.</li> <li>• (Optional) Enter <b>range</b> or <b>throughput</b> to automatically optimize radio range or throughput. When you enter <b>range</b>, The access point sets the 1 Mbps rate to basic and the other rates to <b>enabled</b>. When you enter <b>throughput</b>, the access point sets all four data rates to <b>basic</b>.</li> </ul>
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the **speed** command to disable data rates. When you use the no form of the command, all data rates are disabled except the rates you name in the command. This example shows how to disable data rate 1.0:

```
ap1100# configure terminal
ap1100(config)# interface dot11radio 0
ap1100(config-if)# no speed basic-2.0 basic-5.5 basic-11.0
ap1100(config-if)# end
```

Data rate 1 is disabled, and the rest of the rates are set to basic.

This example shows how to set up the access point for 11 Mbps service only:

```
ap1100# configure terminal
ap1100(config)# interface dot11radio 0
ap1100(config-if)# speed basic-11.0 1.0 2.0 5.5
ap1100(config-if)# end
```

Data rate 11 is set to basic, and the rest of the data rates are set to enabled.



# Configuring Radio Transmit Power

Beginning in privileged EXEC mode, follow these steps to set the transmit power on your access point radio:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>power local</b> { 1   5   20   30   50   100   maximum }	Set the transmit power to one of the power levels allowed in your regulatory domain. All settings are in mW. <b>Note</b> The settings allowed in your regulatory domain might differ from the settings listed here.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the power command to return the power setting to **maximum**, the default setting.

## Limiting the Power Level for Associated Client Devices

You can also limit the power level on client devices that associate to the access point. When a client device associates to the access point, the access point sends the maximum power level setting to the client.

Beginning in privileged EXEC mode, follow these steps to specify a maximum allowed power setting on all client devices that associate to the access point:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>power client</b> { 1   5   20   30   50   100 }	Set the maximum power level allowed on client devices that associate to the access point. All settings are in mW. <b>Note</b> The settings allowed in your regulatory domain might differ from the settings listed here.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the client power command to disable the maximum power level for associated clients.



### Note

Aironet extensions must be enabled to limit the power level on associated client devices. Aironet extensions are enabled by default.

# Configuring Radio Channel Settings

The factory setting for Cisco wireless LAN systems is Radio Channel 6 transmitting at 2437 MHz. To overcome an interference problem, other channel settings are available. The channel settings on your access point correspond to the frequencies available in your regulatory domain. See [Appendix C, “Channels and Antenna Settings,”](#) for the frequencies allowed in your domain.

Each channel covers 22 MHz. The bandwidth for channels 1, 6, and 11 does not overlap, so you can set up multiple access points in the same vicinity without causing interference.



## Note

Too many access points in the same vicinity creates radio congestion that can reduce throughput. A careful site survey can determine the best placement of access points for maximum radio coverage and throughput.

Rather than setting a static default channel, you can configure the access point to select the least-congested channel each time it boots. For most consistent performance after a site survey, however, we recommend that you assign a static channel setting for each access point.

Beginning in privileged EXEC mode, follow these steps to set the access point’s radio network role and fallback role:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>channel frequency   least-congested</b>	<p>Set the default channel for the access point radio. To search for the least-congested channel on startup, enter <b>least-congested</b>.</p> <p>These are the available frequencies (in MHz):</p> <ul style="list-style-type: none"> <li>channel 1—<b>2412</b> (Americas, EMEA, Japan, and China)</li> <li>channel 2—<b>2417</b> (Americas, EMEA, Japan, and China)</li> <li>channel 3—<b>2422</b> (Americas, EMEA, Japan, Israel, and China)</li> <li>channel 4—<b>2427</b> (Americas, EMEA, Japan, Israel, and China)</li> <li>channel 5—<b>2432</b> (Americas, EMEA, Japan, Israel, and China)</li> <li>channel 6—<b>2437</b> (Americas, EMEA, Japan, Israel, and China)</li> <li>channel 7—<b>2442</b> (Americas, EMEA, Japan, Israel, and China)</li> <li>channel 8—<b>2447</b> (Americas, EMEA, Japan, Israel, and China)</li> <li>channel 9—<b>2452</b> (Americas, EMEA, Japan, Israel, and China)</li> <li>channel 10—<b>2457</b> (Americas, EMEA, Japan, and China)</li> <li>channel 11—<b>2462</b> (Americas, EMEA, Japan, and China)</li> <li>channel 12—<b>2467</b> (EMEA and Japan only)</li> <li>channel 13—<b>2472</b> (EMEA and Japan only)</li> <li>channel 14—<b>2484</b> (Japan only)</li> </ul> <p><b>Note</b> The frequencies allowed in your regulatory domain might differ from the frequencies listed here.</p>

	Command	Purpose
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

## Enabling and Disabling World-Mode

When you enable world mode, the access point adds channel carrier set information to its beacon. Client devices with world mode enabled receive the carrier set information and adjust their settings automatically. For example, a client device used primarily in Japan could rely on world mode to adjust its channel and power settings automatically when it travels to Italy and joins a network there. World mode is disabled by default.

Beginning in privileged EXEC mode, follow these steps to enable world mode:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>world-mode</b>	Enable world mode.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the command to disable world mode.



### Note

Aironet extensions must be enabled for world mode operation. Aironet extensions are enabled by default.

## Disabling and Enabling Short Radio Preambles

The radio preamble (sometimes called a *header*) is a section of data at the head of a packet that contains information that the access point and client devices need when sending and receiving packets. You can set the radio preamble to long or short:

- **Short**—A short preamble improves throughput performance. Cisco Aironet Wireless LAN Client Adapters support short preambles. Early models of Cisco Aironet's Wireless LAN Adapter (PC4800 and PC4800A) require long preambles.
- **Long**—A long preamble ensures compatibility between the access point and all early models of Cisco Aironet Wireless LAN Adapters (PC4800 and PC4800A). If these client devices do not associate to your access points, you should use short preambles.

Short preambles are enabled by default.

Beginning in privileged EXEC mode, follow these steps to disable short radio preambles:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>no preamble-short</b>	Disable short preambles and enable long preambles.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **preamble-short** command to enable short preambles if they are disabled.

## Configuring Transmit and Receive Antennas

You can select the antenna the access point uses to receive and transmit data. There are three options for both the receive and the transmit antenna:

- **Diversity**—This default setting tells the access point to use the antenna that receives the best signal. If your access point has two fixed (non-removeable) antennas, you should use this setting for both receive and transmit.



**Note** The 1100 series access point has an integrated antenna body that houses two antennas. For best performance, leave the receive and transmit antenna settings at **diversity**, the default setting.

- **Right**—If your access point has removeable antennas and you install a high-gain antenna on the access point's right connector, you should use this setting for both receive and transmit. When you look at the access point's back panel, the right antenna is on the right.
- **Left**—If your access point has removeable antennas and you install a high-gain antenna on the access point's left connector, you should use this setting for both receive and transmit. When you look at the access point's back panel, the left antenna is on the left.

Beginning in privileged EXEC mode, follow these steps to select the antennas the access point uses to receive and transmit data:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>antenna receive</b> { <b>diversity</b>   <b>left</b>   <b>right</b> }	Set the receive antenna to diversity, left, or right. <b>Note</b> For best performance, leave the receive antenna setting at the default setting, diversity.
Step 4	<b>antenna transmit</b> { <b>diversity</b>   <b>left</b>   <b>right</b> }	Set the transmit antenna to diversity, left, or right. <b>Note</b> For best performance, leave the transmit antenna setting at the default setting, diversity.

	Command	Purpose
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

## Disabling and Enabling Aironet Extensions

By default, the access point uses Cisco Aironet 802.11 extensions to detect the capabilities of Cisco Aironet client devices and to support features that require specific interaction between the access point and associated client devices. Aironet extensions must be enabled to support these features:

- Load balancing—The access point uses Aironet extensions to direct client devices to an access point that provides the best connection to the network based on factors such as number of users, bit error rates, and signal strength.
- Message Integrity Check (MIC)—MIC is an additional WEP security feature that prevents attacks on encrypted packets called bit-flip attacks. The MIC, implemented on both the access point and all associated client devices, adds a few bytes to each packet to make the packets tamper-proof.
- Temporal Key Integrity Protocol (TKIP)—TKIP, also known as WEP key hashing, is an additional WEP security feature that defends against an attack on WEP in which the intruder uses an unencrypted segment called the initialization vector (IV) in encrypted packets to calculate the WEP key.
- Repeater mode—Aironet extensions must be enabled on repeater access points and on the root access points to which they associate.
- World mode—Client devices with world mode enabled receive carrier set information from the access point and adjust their settings automatically.
- Limiting the power level on associated client devices—When a client device associates to the access point, the access point sends the maximum allowed power level setting to the client.

Disabling Aironet extensions disables the features listed above, but it sometimes improves the ability of non-Cisco client devices to associate to the access point.

Aironet extensions are enabled by default. Beginning in privileged EXEC mode, follow these steps to disable Aironet extensions:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>no dot11 extension aironet</b>	Disable Aironet extensions.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **dot11 extension aironet** command to enable Aironet extensions if they are disabled.

## Configuring the Ethernet Encapsulation Transformation Method

When the access point receives data packets that are not 802.3 packets, the access point must format the packets to 802.3 using an encapsulation transformation method. These are the two transformation methods:

- 802.1H—This method provides optimum performance for Cisco Aironet wireless products. This is the default setting.
- RFC1042—Use this setting to ensure interoperability with non-Cisco Aironet wireless equipment. RFC1042 does not provide the interoperability advantages of 802.1H but is used by other manufacturers of wireless equipment.

Beginning in privileged EXEC mode, follow these steps to configure the encapsulation transformation method:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>payload-encapsulation snap   dot1h</b>	Set the encapsulation transformation method to RFC1042 ( <b>snap</b> ) or 802.1h ( <b>dot1h</b> , the default setting).
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

## Enabling and Disabling Reliable Multicast to Workgroup Bridges

Reliable multicast messages from the access point to workgroup bridges allows approximately 20 Cisco Aironet Workgroup Bridges to associate to the access point. The default setting, disabled, allows more than 20 workgroup bridges to associate to the access point.

Access points and bridges normally treat workgroup bridges not as client devices but as infrastructure devices, like access points or bridges. Treating a workgroup bridge as an infrastructure device means that the access point reliably delivers multicast packets, including Address Resolution Protocol (ARP) packets, to the workgroup bridge.

The performance cost of reliable multicast delivery—duplication of each multicast packet sent to each workgroup bridge—limits the number of infrastructure devices, including workgroup bridges, that can associate to the access point. To increase beyond 20 the number of workgroup bridges that can associate to the access point, the access point must reduce the delivery reliability of multicast packets to workgroup bridges. With reduced reliability, the access point cannot confirm whether multicast packets reach the intended workgroup bridge, so workgroup bridges at the edge of the access point's coverage area might lose IP connectivity. When you treat workgroup bridges as client devices, you increase performance but reduce reliability.



### Note

This feature is best suited for use with stationary workgroup bridges. Mobile workgroup bridges might encounter spots in the access point's coverage area where they do not receive multicast packets and lose communication with the access point even though they are still associated to it.

A Cisco Aironet Workgroup Bridge provides a wireless LAN connection for up to eight Ethernet-enabled devices.

Beginning in privileged EXEC mode, follow these steps to configure the encapsulation transformation method:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3		Enable reliable multicast messages to workgroup bridges.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the command to disable reliable multicast messages to workgroup bridges.

## Enabling and Disabling Public Secure Packet Forwarding

Public Secure Packet Forwarding (PSPF) prevents client devices associated to an access point from inadvertently sharing files with other client devices on the wireless network. It provides Internet access to client devices without providing other capabilities of a LAN. With PSPF enabled, client devices cannot communicate with other client devices on the wireless network. This feature is useful for public wireless networks like those installed in airports or on college campuses.

To enable and disable PSPF using IOS commands, you use bridge groups. You can find a detailed explanation of bridge groups and instructions for implementing them in this document:

- *Cisco IOS Bridging and IBM Networking Configuration Guide, Release 12.2*. Click this link to browse to the Configuring Transparent Bridging chapter:  
[http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fibm\\_c/bcfpart1/bcfib.htm](http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fibm_c/bcfpart1/bcfib.htm)

You can also enable and disable PSPF using the web-browser interface. The PSPF setting is on the Radio-802.11b Settings page.

PSPF is disabled by default. Beginning in privileged EXEC mode, follow these steps to enable PSPF:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>bridge-group <i>group</i> port-protected</b>	Enable PSPF.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the command to disable PSPF.

## Configuring the Beacon Period and the DTIM

The beacon period is the amount of time between access point beacons in Kilomicroseconds. One Kμsec equals 1,024 microseconds. The Data Beacon Rate, always a multiple of the beacon period, determines how often the beacon contains a delivery traffic indication message (DTIM). The DTIM tells power-save client devices that a packet is waiting for them.

For example, if the beacon period is set at 100, its default setting, and the data beacon rate is set at 2, its default setting, then the access point sends a beacon containing a DTIM every 200 Kμsecs. One Kμsec equals 1,024 microseconds.

The default beacon period is 100, and the default DTIM is 2. Beginning in privileged EXEC mode, follow these steps to configure the beacon period and the DTIM:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>beacon period</b> <i>value</i>	Set the beacon period. Enter a value in Kilomicroseconds.
Step 4	<b>beacon dtim-period</b> <i>value</i>	Set the DTIM. Enter a value in Kilomicroseconds.
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

## Configure RTS Threshold and Retries

The RTS threshold determines the packet size at which the access point issues a request to send (RTS) before sending the packet. A low RTS Threshold setting can be useful in areas where many client devices are associating with the access point, or in areas where the clients are far apart and can detect only the access point and not each other. You can enter a setting ranging from 0 to 2339 bytes.

Maximum RTS Retries is the maximum number of times the access point issues an RTS before stopping the attempt to send the packet over the radio. Enter a value from 1 to 128.

The default RTS threshold is 2312, and the default maximum RTS retries setting is 32. Beginning in privileged EXEC mode, follow these steps to configure the RTS threshold and maximum RTS retries:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>rts</b> <b>threshold</b> <i>value</i>	Set the RTS threshold. Enter an RTS threshold from 0 to 2339.
Step 4	<b>rts</b> <b>retries</b> <i>value</i>	Set the maximum RTS retries. Enter a setting from 1 to 128.
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the command to reset the RTS settings to defaults.



## Configuring the Maximum Data Retries

The maximum data retries setting determines the number of attempts the access point makes to send a packet before giving up and dropping the packet.

The default setting is 32. Beginning in privileged EXEC mode, follow these steps to configure the maximum data retries:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>packet retries</b> <i>value</i>	Set the maximum data retries. Enter a setting from 1 to 128.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the command to reset the setting to defaults.

## Configuring the Fragmentation Threshold

The fragmentation threshold determines the size at which packets are fragmented (sent as several pieces instead of as one block). Use a low setting in areas where communication is poor or where there is a great deal of radio interference.

The default setting is 2338 bytes. Beginning in privileged EXEC mode, follow these steps to configure the fragmentation threshold:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>fragment-threshold</b> <i>value</i>	Set the fragmentation threshold. Enter a setting from 256 to 2338 bytes.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the command to reset the setting to defaults.





## Configuring Multiple SSIDs

---

This chapter describes how to configure and manage multiple service set identifiers (SSIDs) on the access point. This chapter contains these sections:

- [Understanding Multiple SSIDs, page 8-2](#)
- [Configuring Multiple SSIDs, page 8-2](#)

# Understanding Multiple SSIDs

The SSID is a unique identifier that wireless networking devices use to establish and maintain wireless connectivity. Multiple access points on a network or sub-network can use the same SSIDs. SSIDs are case sensitive and can contain up to 32 alphanumeric characters.

You can configure up to 16 SSIDs on your 1100 series access point and assign different configuration settings to each SSID. All the SSIDs are active at the same time; that is, client devices can associate to the access point using any of the SSIDs. These are the settings you can assign to each SSID:

- VLAN
- Client authentication method



---

**Note** For detailed information on client authentication types, see [Chapter 10, “Configuring Authentication Types.”](#)

---

- Maximum number of client associations using the SSID
- Proxy mobile IP
- RADIUS accounting for traffic using the SSID
- Guest mode
- Repeater mode, including authentication username and password

If you want the access point to allow associations from client devices that do not specify an SSID in their configurations, you can set up a guest SSID. The access point includes the guest SSID in its beacon. The access point’s default SSID, tsunami, is set to guest mode. However, to keep your network secure, you should disable the guest mode SSID on most access points.

If your access point will be a repeater or will be a root access point that acts as a parent for a repeater, you can set up an SSID for use in repeater mode. You can assign an authentication username and password to the repeater-mode SSID to allow the repeater to authenticate to your network like a client device.

If your network uses VLANs, you can assign an SSID to a VLAN, and client devices using the SSID are grouped in that VLAN.

# Configuring Multiple SSIDs

These sections contain configuration information for multiple SSIDs:

- [Default SSID Configuration, page 8-3](#)
- [Creating an SSID, page 8-3](#)
- [Using a RADIUS Server to Restrict SSIDs, page 8-4](#)

## Default SSID Configuration

Table 8-1 shows the default SSID configuration:

**Table 8-1 Default SSID Configuration**

Feature	Default Setting
SSID	tsunami
Guest Mode SSID	tsunami (The access point broadcasts this SSID in its beacon and allows client devices with no SSID to associate.)

## Creating an SSID

Beginning in privileged EXEC mode, follow these steps to create an SSID:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>ssid <i>ssid-string</i></b>	Create an SSID and enter SSID configuration mode for the new SSID. The SSID can consist of up to 32 alphanumeric characters. SSIDs are case-sensitive.
Step 4	<b>authentication client</b> <b>username <i>username</i></b> <b>password <i>password</i></b>	(Optional) Set an authentication username and password that the access point uses to authenticate to the network when in repeater mode. Set the username and password on the SSID that the repeater access point uses to associate to a root access point, or with another repeater.
Step 5	<b>accounting <i>list-name</i></b>	(Optional) Enable RADIUS accounting for this SSID. For <i>list-name</i> , specify the accounting method list. Click this link for more information on method lists: <a href="http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fsecur_c/fsaaa/scfacct.htm#xtocid2">http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fsecur_c/fsaaa/scfacct.htm#xtocid2</a>
Step 6	<b>vlan <i>vlan-id</i></b>	(Optional) Assign the SSID to a VLAN on your network. Client devices that associate using the SSID are grouped into this VLAN.
Step 7	<b>guest-mode</b>	(Optional) Designate the SSID as your access point's guest-mode SSID. The access point includes the SSID in its beacon and allows associations from client devices that do not specify an SSID.
Step 8	<b>infrastructure-ssid [optional]</b>	(Optional) Designate the SSID as the SSID that other access points and workgroup bridges use to associate to this access point. If you do not designate an SSID as the infrastructure SSID, infrastructure devices can associate to the access point using any SSID. If you designate an SSID as the infrastructure SSID, infrastructure devices must associate to the access point using that SSID unless you also enter the <b>optional</b> keyword.

	Command	Purpose
Step 9	<b>end</b>	Return to privileged EXEC mode.
Step 10	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

**Note**

You use the **ssid** command's authentication options to configure an authentication type for each SSID. See [Chapter 10, "Configuring Authentication Types,"](#) for instructions on configuring authentication types.

Use the **no** form of the command to disable the SSID or to disable SSID features.

This example shows how to:

- Name an SSID
- Configure the SSID for RADIUS accounting
- Set the maximum number of client devices that can associate using this SSID to 15
- Assign the SSID to a VLAN

```
ap1100# configure terminal
ap1100(config)# configure interface dot11radio 0
ap1100(config-if)# ssid batman
ap1100(config-ssid)# accounting accounting-method-list
ap1100(config-ssid)# max-associations 15
ap1100(config-ssid)# vlan 3762
ap1100(config-ssid)# end
```

## Using a RADIUS Server to Restrict SSIDs

To prevent client devices from associating to the access point using an unauthorized SSID, you can create a list of authorized SSIDs that clients must use on your RADIUS authentication server.

The SSID authorization process consists of these steps:

1. A client device associates to the access point using any SSID configured on the access point.
2. The client begins RADIUS authentication.
3. The RADIUS server returns a list of SSIDs that the client is allowed to use. The access point checks the list for a match of the SSID used by the client. There are three possible outcomes:
  - a. If the SSID that the client used to associate to the access point matches an entry in the allowed list returned by the RADIUS server, the client is allowed network access after completing all authentication requirements.
  - b. If the access point does not find a match for the client in the allowed list of SSIDs, the access point disassociates the client.
  - c. If the RADIUS server does not return any SSIDs (no list) for the client, then the administrator has not configured the list, and the client is allowed to associate and attempt to authenticate.

The allowed list of SSIDs from the RADIUS server are in the form of Cisco VSAs. The Internet Engineering Task Force (IETF) draft standard specifies a method for communicating vendor-specific information between the access point and the RADIUS server by using the vendor-specific attribute (attribute 26). Vendor-specific attributes (VSAs) allow vendors to support their own extended attributes not suitable for general use. The Cisco RADIUS implementation supports one vendor-specific option by

using the format recommended in the specification. Cisco's vendor-ID is 9, and the supported option has vendor-type 1, which is named *cisco-avpair*. The Radius server is allowed to have zero or more SSID VSAs per client.

In this example, the following AV pair adds the SSID *batman* to the list of allowed SSIDs for a user:

```
cisco-avpair= "ssid=batman"
```

For instructions on configuring the access point to recognize and use VSAs, see the [“Configuring the Access Point to Use Vendor-Specific RADIUS Attributes”](#) section on page 11-13.







## Configuring WEP and WEP Features

---

This chapter describes how to configure Wired Equivalent Privacy (WEP), Message Integrity Check (MIC), Temporal Key Integrity Protocol (TKIP), and broadcast key rotation. This chapter contains these sections:

- [Understanding WEP, page 9-2](#)
- [Configuring WEP and WEP Features, page 9-2](#)

# Understanding WEP

Just as anyone within range of a radio station can tune to the station's frequency and listen to the signal, any wireless networking device within range of an access point can receive the access point's radio transmissions. Because WEP is the first line of defense against intruders, Cisco recommends that you use full encryption on your wireless network.

WEP encryption scrambles the communication between the access point and client devices to keep the communication private. Both the access point and client devices use the same WEP key to encrypt and unencrypt radio signals. WEP keys encrypt both unicast and multicast messages. Unicast messages are addressed to just one device on the network. Multicast messages are addressed to multiple devices on the network.

Extensible Authentication Protocol (EAP) authentication provides dynamic WEP keys to wireless users. Dynamic WEP keys are more secure than static, or unchanging, WEP keys. If an intruder passively receives enough packets encrypted by the same WEP key, the intruder can perform a calculation to learn the key and use it to join your network. Because they change frequently, dynamic WEP keys prevent intruders from performing the calculation and learning the key. See [Chapter 10, “Configuring Authentication Types,”](#) for detailed information on EAP and other authentication types.

Three additional security features defend your wireless network's WEP keys:

- Message Integrity Check (MIC)—MIC prevents attacks on encrypted packets called *bit-flip attacks*. During a bit-flip attack, an intruder intercepts an encrypted message, alters it slightly, and retransmits it, and the receiver accepts the retransmitted message as legitimate. The MIC, implemented on both the access point and all associated client devices, adds a few bytes to each packet to make the packets tamper proof.
- TKIP (Temporal Key Integrity Protocol, also known as *WEP key hashing*)—This feature defends against an attack on WEP in which the intruder uses the unencrypted initialization vector (IV) in encrypted packets to calculate the WEP key. TKIP removes the predictability that an intruder relies on to determine the WEP key by exploiting IVs.
- Broadcast key rotation—EAP authentication provides dynamic unicast WEP keys for client devices but uses static broadcast keys. When you enable broadcast WEP key rotation, the access point provides a dynamic broadcast WEP key and changes it at the interval you select. Broadcast key rotation is an excellent alternative to TKIP if your wireless LAN supports wireless client devices that are not Cisco devices or that cannot be upgraded to the latest firmware for Cisco client devices.

## Configuring WEP and WEP Features

These sections describe how to configure WEP and additional WEP features such as MIC, TKIP, and broadcast key rotation:

- [Creating WEP Keys, page 9-3](#)
- [Enabling and Disabling WEP and Enabling TKIP and MIC, page 9-3](#)
- [Enabling and Disabling Broadcast Key Rotation, page 9-4](#)

WEP, TKIP, MIC, and broadcast key rotation are disabled by default.

## Creating WEP Keys

Beginning in privileged EXEC mode, follow these steps to create a WEP key and set the key properties:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>encryption</b> [vlan <i>vlan-id</i> ] <b>key 1-4</b> <b>size { 40   128 } encryption-key</b> [ <b>transmit-key</b> ]	Create a WEP key and set up its properties. <ul style="list-style-type: none"> <li>(Optional) Select the VLAN for which you want to create a key.</li> <li>Name the key slot in which this WEP key resides. You can assign up to 4 WEP keys for each VLAN.</li> <li>Enter the key and set the size of the key, either 40-bit or 128-bit. 40-bit keys contain 10 hexadecimal digits; 128-bit keys contain 26 hexadecimal digits.</li> <li>(Optional) Set this key as the transmit key. The key in slot 1 is the transmit key by default, but you can set any key as the transmit key.</li> </ul>
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

This example shows how to create a 128-bit WEP key in slot 1 for VLAN 22 and sets the key as the transmit key:

```
ap1100# configure terminal
ap1100(config)# configure interface dot11radio 0
ap1100(config-if)# encryption vlan 22 key 1 size 128 12345678901234567890123456
transmit-key
ap1100(config-ssid)# end
```

## Enabling and Disabling WEP and Enabling TKIP and MIC

Beginning in privileged EXEC mode, follow these steps to enable WEP, TKIP, and MIC:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.

	Command	Purpose
Step 3	<b>encryption</b> [vlan <i>vlan-id</i> ] <b>mode wep</b> { <b>optional</b> [key-hash]   <b>mandatory</b> [mic] [key-hash] }	Enable WEP, MIC, and TKIP. <ul style="list-style-type: none"> <li>(Optional) Select the VLAN for which you want to enable WEP and WEP features.</li> <li>Set the WEP level and enable TKIP and MIC. If you enter <b>optional</b>, client devices can associate to the access point with or without WEP enabled. You can enable TKIP with WEP set to optional but you cannot enable MIC. If you enter <b>mandatory</b>, client devices must have WEP enabled to associate to the access point. You can enable both TKIP and MIC with WEP set to mandatory.</li> </ul>
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the encryption command to disable WEP or to disable WEP features.

This example sets WEP to mandatory for VLAN 22 and enables MIC and TKIP.

```
ap1100# configure terminal
ap1100(config)# configure interface dot11radio 0
ap1100(config-if)# encryption vlan 22 mode wep mandatory mic key-hash
ap1100(config-ssid)# end
```

## Enabling and Disabling Broadcast Key Rotation

Broadcast key rotation is disabled by default. Beginning in privileged EXEC mode, follow these steps to enable broadcast key rotation:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>broadcast-key</b> <b>change seconds</b> [vlan <i>vlan-id</i> ]	Enable broadcast key rotation. <ul style="list-style-type: none"> <li>Enter the number of seconds between each rotation of the broadcast key.</li> <li>(Optional) Enter a VLAN for which you want to enable broadcast key rotation.</li> </ul>
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the encryption command to disable broadcast key rotation.

This example enables broadcast key rotation on VLAN 22 and sets the rotation interval to 300 seconds:

```
ap1100# configure terminal
ap1100(config)# configure interface dot11radio 0
ap1100(config-if)# broadcast-key vlan 22 change 300
ap1100(config-ssid)# end
```



## Configuring Authentication Types

---

This chapter describes how to configure authentication types on the access point. This chapter contains these sections:

- [Understanding Authentication Types, page 10-2](#)
- [Configuring Authentication Types, page 10-6](#)
- [Matching Access Point and Client Device Authentication Types, page 10-9](#)

# Understanding Authentication Types

This section describes the authentication types that you can configure on the access point. The authentication types are tied to the SSIDs that you configure for the access point. If you want to serve different types of client devices with the same access point, you can configure multiple SSIDs. See [Chapter 8, “Configuring Multiple SSIDs,”](#) for complete instructions on configuring multiple SSIDs.

Before a wireless client device can communicate on your network through the access point, it must authenticate to the access point using open or shared-key authentication. For maximum security, client devices should also authenticate to your network using MAC-address or EAP authentication, authentication types that rely on an authentication server on your network.

The access point uses four authentication mechanisms or types and can use more than one at the same time. These sections explain each authentication type:


- [Open Authentication to the Access Point, page 10-2](#)
- [Shared Key Authentication to the Access Point, page 10-2](#)
- [EAP Authentication to the Network, page 10-3](#)
- [MAC Address Authentication to the Network, page 10-5](#)
- [Combining MAC-Based, EAP, and Open Authentication, page 10-5](#)

## Open Authentication to the Access Point

Open authentication allows any device to authenticate and then attempt to communicate with the access point. Using open authentication, any wireless device can authenticate with the access point, but the device can communicate only if its WEP keys match the access point's. Devices not using WEP do not attempt to authenticate with an access point that is using WEP. Open authentication does not rely on a RADIUS server on your network.

[Figure 10-1](#) shows the authentication sequence between a device trying to authenticate and an access point using open authentication. In this example, the device's WEP key does not match the access point's key, so it can authenticate but not pass data.

**Figure 10-1** Sequence for Open Authentication



## Shared Key Authentication to the Access Point


Cisco provides shared key authentication to comply with the IEEE 802.11b standard. However, because of shared key's security flaws, we recommend that you avoid using it.

During shared key authentication, the access point sends an unencrypted challenge text string to any device attempting to communicate with the access point. The device requesting authentication encrypts the challenge text and sends it back to the access point. If the challenge text is encrypted correctly, the

access point allows the requesting device to authenticate. Both the unencrypted challenge and the encrypted challenge can be monitored, however, which leaves the access point open to attack from an intruder who calculates the WEP key by comparing the unencrypted and encrypted text strings. Because of this weakness, shared key authentication can be less secure than open authentication. Like open authentication, shared key authentication does not rely on a RADIUS server on your network.

Figure 10-2 shows the authentication sequence between a device trying to authenticate and an access point using shared key authentication. In this example the device's WEP key matches the access point's key, so it can authenticate and communicate.

**Figure 10-2 Sequence for Shared Key Authentication**




## EAP Authentication to the Network

This authentication type provides the highest level of security for your wireless network. By using the Extensible Authentication Protocol (EAP) to interact with an EAP-compatible RADIUS server, the access point helps a wireless client device and the RADIUS server to perform mutual authentication and derive a dynamic unicast WEP key. The RADIUS server sends the WEP key to the access point, which uses it for all unicast data signals that it sends to or receives from the client. The access point also encrypts its broadcast WEP key (entered in the access point's WEP key slot 1) with the client's unicast key and sends it to the client.

When you enable EAP on your access points and client devices, authentication to the network occurs in the steps shown in Figure 10-3:

Figure 10-3 Sequence for EAP Authentication



In Steps 1 through 9 in [Figure 10-3](#), a wireless client device and a RADIUS server on the wired LAN use 802.1x and EAP to perform a mutual authentication through the access point. The RADIUS server sends an authentication challenge to the client. The client uses a one-way encryption of the user-supplied password to generate a response to the challenge and sends that response to the RADIUS server. Using information from its user database, the RADIUS server creates its own response and compares that to the response from the client. When the RADIUS server authenticates the client, the process repeats in reverse, and the client authenticates the RADIUS server.

When mutual authentication is complete, the RADIUS server and the client determine a WEP key that is unique to the client and provides the client with the appropriate level of network access, thereby approximating the level of security in a wired switched segment to an individual desktop. The client loads this key and prepares to use it for the logon session.

During the logon session, the RADIUS server encrypts and sends the WEP key, called a *session key*, over the wired LAN to the access point. The access point encrypts its broadcast key with the session key and sends the encrypted broadcast key to the client, which uses the session key to decrypt it. The client and access point activate WEP and use the session and broadcast WEP keys for all communications during the remainder of the session.

There is more than one type of EAP authentication, but the access point behaves the same way for each type: it relays authentication messages from the wireless client device to the RADIUS server and from the RADIUS server to the wireless client device. See the [“Assigning Authentication Types to an SSID”](#) section on [page 10-6](#) for instructions on setting up EAP on the access point.

**Note**

If you use EAP authentication, you can select open or shared key authentication, but you don't have to. EAP authentication controls authentication both to your access point and to your network.




## MAC Address Authentication to the Network

The access point relays the wireless client device's MAC address to a RADIUS server on your network, and the server checks the address against a list of allowed MAC addresses. If you don't have a RADIUS server on your network, you can create the list of allowed MAC addresses on the access point's Address Filters page. Devices with MAC addresses not on the list are not allowed to authenticate. Intruders can create counterfeit MAC addresses, so MAC-based authentication is less secure than EAP authentication. However, MAC-based authentication provides an alternate authentication method for client devices that do not have EAP capability. See the [“Assigning Authentication Types to an SSID”](#) section on page 10-6 for instructions on enabling MAC-based authentication.

Figure 10-4 shows the authentication sequence for MAC-based authentication.

**Figure 10-4** Sequence for MAC-Based Authentication



## Combining MAC-Based, EAP, and Open Authentication

You can set up the access point to authenticate client devices using a combination of MAC-based and EAP authentication. When you enable this feature, client devices that associate to the access point using 802.11 open authentication first attempt MAC authentication; if MAC authentication succeeds, the client device joins the network. If MAC authentication fails, the access point waits for the client device to attempt EAP authentication. See the [“Assigning Authentication Types to an SSID”](#) section on page 10-6 for instructions on setting up this combination of authentications.

# Configuring Authentication Types

This section describes how to configure authentication types. You attach configuration types to the access point's SSIDs. See [Chapter 8, “Configuring Multiple SSIDs,”](#) for details on setting up multiple SSIDs. This section contains these topics:

- [Default Authentication Settings, page 10-6](#)
- [Assigning Authentication Types to an SSID, page 10-6](#)
- [Configuring Authentication Holdoffs, Timeouts, and Intervals, page 10-8](#)

## Default Authentication Settings

The default SSID on the access point is tsunami. [Table 10-1](#) shows the default authentication settings for the default SSID:

**Table 10-1 Default Authentication Configuration**

Feature	Default Setting
SSID	tsunami
Guest Mode SSID	tsunami (The access point broadcasts this SSID in its beacon and allows client devices with no SSID to associate.)
Authentication type assigned to tsunami	open

## Assigning Authentication Types to an SSID

Beginning in privileged EXEC mode, follow these steps to configure authentication types for SSIDs:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>ssid <i>ssid-string</i></b>	Create an SSID and enter SSID configuration mode for the new SSID. The SSID can consist of up to 32 alphanumeric characters. SSIDs are case sensitive.

Command	Purpose
<p><b>Step 4</b></p> <p><b>authentication open</b>  [<b>mac-address</b> <i>list-name</i> [<b>alternate</b>]]  [<b>eap</b> <i>list-name</i>]</p>	<p>(Optional) Set the authentication type to open for this SSID. Open authentication allows any device to authenticate and then attempt to communicate with the access point.</p> <ul style="list-style-type: none"> <li>(Optional) Set the SSID's authentication type to open with MAC address authentication. The access point forces all client devices to perform MAC-address authentication before they are allowed to join the network. For <i>list-name</i>, specify the authentication method list. Click this link for more information on method lists:  <a href="http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fsecur_c/fsaaa/scfathen.htm#xtocid2">http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fsecur_c/fsaaa/scfathen.htm#xtocid2</a></li> </ul> <p>Use the <b>alternate</b> keyword to allow client devices to join the network using either MAC or EAP authentication; clients that successfully complete either authentication are allowed to join the network.</p> <ul style="list-style-type: none"> <li>(Optional) Set the SSID's authentication type to open with EAP authentication. The access point forces all client devices to perform EAP authentication before they are allowed to join the network. For <i>list-name</i>, specify the authentication method list.</li> </ul> <p><b>Note</b> An access point configured for EAP authentication forces all client devices that associate to perform EAP authentication. Client devices that do not use EAP cannot use the access point.</p>
<p><b>Step 5</b></p> <p><b>authentication shared</b>  [<b>mac-address</b> <i>list-name</i>]  [<b>eap</b> <i>list-name</i>]</p>	<p>(Optional) Set the authentication type for the SSID to shared key.</p> <p><b>Note</b> Because of shared key's security flaws, Cisco recommends that you avoid using it.</p> <p><b>Note</b> You can assign shared key authentication to only one SSID.</p> <ul style="list-style-type: none"> <li>(Optional) Set the SSID's authentication type to shared key with MAC address authentication. For <i>list-name</i>, specify the authentication method list.</li> <li>(Optional) Set the SSID's authentication type to shared key with EAP authentication. For <i>list-name</i>, specify the authentication method list.</li> </ul>

	Command	Purpose
Step 6	<b>authentication network-eap</b> <i>list-name</i> [ <i>mac-address list-name</i> ]	(Optional) Set the authentication type for the SSID to Network-EAP. Using the Extensible Authentication Protocol (EAP) to interact with an EAP-compatible RADIUS server, the access point helps a wireless client device and the RADIUS server to perform mutual authentication and derive a dynamic unicast WEP key. However, the access point does not force all client devices to perform EAP authentication. <ul style="list-style-type: none"> <li>(Optional) Set the SSID's authentication type to Network-EAP with MAC address authentication. All client devices that associate to the access point are required to perform MAC-address authentication. For <i>list-name</i>, specify the authentication method list.</li> </ul>
Step 7	<b>end</b>	Return to privileged EXEC mode.
Step 8	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the no form of the SSID commands to disable the SSID or to disable SSID features.

This example sets the authentication type for the SSID *batman* to open with a combination of MAC-address and EAP authentication. Client devices using the *batman* SSID first attempt MAC-address authentication using a server named *adam*. If MAC authentication succeeds, they join the network, but if it fails, they attempt EAP authentication using the same server.

```
ap1100# configure terminal
ap1100(config)# configure interface dot11radio 0
ap1100(config-if)# ssid batman
ap1100(config-ssid)# authentication open mac adam alternate eap adam
ap1100(config-ssid)# end
```

## Configuring Authentication Holdoffs, Timeouts, and Intervals

Beginning in privileged EXEC mode, follow these steps to configure holdoff times, reauthentication periods, and authentication timeouts for client devices authenticating through your access point:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>dot11 holdoff-time</b> <i>seconds</i>	Enter the number of seconds a client device must wait before it can reattempt to authenticate following a failed authentication. Enter a value from 1 to 65555 seconds.
Step 3	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 4	<b>dot1x client-timeout</b> <i>seconds</i>	Enter the number of seconds the access point should wait for a reply from a client attempting to authenticate before the authentication fails. Enter a value from 1 to 65555 seconds.

	Command	Purpose
Step 5	<code>dot1x reauth-period seconds [server]</code>	Enter the interval in seconds that the access point waits before forcing an authenticated client to reauthenticate. <ul style="list-style-type: none"> <li>(Optional) Enter the <b>server</b> keyword to configure the access point to use the reauthentication period specified by the authentication server. If you use this option, configure your authentication server with RADIUS attribute 27, Session-Timeout. This attribute sets the maximum number of seconds of service to be provided to the client before termination of the session or prompt. The server sends this attribute to the access point when a client device performs EAP authentication.</li> </ul>
Step 6	<code>end</code>	Return to privileged EXEC mode.
Step 7	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

Use the no form of these commands to reset the values to default settings.

## Matching Access Point and Client Device Authentication Types

To use the authentication types described in this section, the access point authentication settings must match the authentication settings on the client adapters that associate to the access point. Refer to the *Cisco Aironet Wireless LAN Client Adapters Installation and Configuration Guide for Windows* for instructions on setting authentication types on wireless client adapters. Refer to [Chapter 9, “Configuring WEP and WEP Features,”](#) for instructions on configuring WEP on the access point.

[Table 10-2](#) lists the client and access point settings required for each authentication type.

**Table 10-2 Client and Access Point Security Settings**

Security Feature	Client Setting	Access Point Setting
Static WEP with open authentication	Create a WEP key and enable Use Static WEP Keys and Open Authentication	Set up and enable WEP and enable Open Authentication
Static WEP with shared key authentication	Create a WEP key and enable Use Static WEP Keys and Shared Key Authentication	Set up and enable WEP and enable Shared Key Authentication
LEAP authentication	Enable LEAP	Set up and enable WEP and enable EAP and Open authentication

Table 10-2 Client and Access Point Security Settings (continued)

Security Feature	Client Setting	Access Point Setting
EAP-TLS authentication		
If using ACU to configure card	Enable Host Based EAP and Use Dynamic WEP Keys in ACU and select Enable network access control using IEEE 802.1X and Smart Card or Other Certificate as the EAP Type in Windows 2000 (with Service Pack 3) or Windows XP	Set up and enable WEP and enable EAP and Open authentication
If using Windows XP to configure card	Select Enable network access control using IEEE 802.1X and Smart Card or other Certificate as the EAP Type	Set up and enable WEP and enable EAP and Open Authentication
EAP-MD5 authentication		
If using ACU to configure card	Create a WEP key, enable Host Based EAP, and enable Use Static WEP Keys in ACU and select Enable network access control using IEEE 802.1X and MD5-Challenge as the EAP Type in Windows 2000 (with Service Pack 3) or Windows XP	Set up and enable WEP and enable EAP and Open authentication
If using Windows XP to configure card	Select Enable network access control using IEEE 802.1X and MD5-Challenge as the EAP Type	Set up and enable WEP and enable EAP and Open Authentication
PEAP authentication		
If using ACU to configure card	Enable Host Based EAP and Use Dynamic WEP Keys in ACU and select Enable network access control using IEEE 802.1X and PEAP as the EAP Type in Windows 2000 (with Service Pack 3) or Windows XP	Set up and enable WEP and enable EAP and Open authentication
If using Windows XP to configure card	Select Enable network access control using IEEE 802.1X and PEAP as the EAP Type	Set up and enable WEP and enable Require EAP and Open Authentication

**Table 10-2 Client and Access Point Security Settings (continued)**

<b>Security Feature</b>	<b>Client Setting</b>	<b>Access Point Setting</b>
EAP-SIM authentication		
If using ACU to configure card	Enable Host Based EAP and Use Dynamic WEP Keys in ACU and select Enable network access control using IEEE 802.1X and SIM Authentication as the EAP Type in Windows 2000 (with Service Pack 3) or Windows XP	Set up and enable WEP with full encryption and enable EAP and Open authentication
If using Windows XP to configure card	Select Enable network access control using IEEE 802.1X and SIM Authentication as the EAP Type	Set up and enable WEP with full encryption and enable Require EAP and Open Authentication







## Configuring RADIUS Servers

---

This chapter describes how to enable and configure the Remote Authentication Dial-In User Service (RADIUS), which provides detailed accounting information and flexible administrative control over authentication and authorization processes. RADIUS is facilitated through AAA and can be enabled only through AAA commands.



**Note**

---

For complete syntax and usage information for the commands used in this section, refer to the *Cisco IOS Security Command Reference for Release 12.2*.

---

This section contains this configuration information:

- [Understanding RADIUS, page 11-2](#)
- [RADIUS Operation, page 11-2](#)
- [Configuring RADIUS, page 11-4](#)
- [Displaying the RADIUS Configuration, page 11-15](#)

# Understanding RADIUS

RADIUS is a distributed client/server system that secures networks against unauthorized access. RADIUS clients run on supported Cisco devices and send authentication requests to a central RADIUS server, which contains all user authentication and network service access information. The RADIUS host is normally a multiuser system running RADIUS server software from Cisco (Cisco Secure Access Control Server version 3.0), Livingston, Merit, Microsoft, or another software provider. For more information, refer to the RADIUS server documentation.

Use RADIUS in these network environments, which require access security:

- Networks with multiple-vendor access servers, each supporting RADIUS. For example, access servers from several vendors use a single RADIUS server-based security database. In an IP-based network with multiple vendors' access servers, dial-in users are authenticated through a RADIUS server that is customized to work with the Kerberos security system.
- Turnkey network security environments in which applications support the RADIUS protocol, such as in an access environment that uses a *smart card* access control system. In one case, RADIUS has been used with Enigma's security cards to validate users and to grant access to network resources.
- Networks already using RADIUS. You can add a Cisco access point containing a RADIUS client to the network.
- Networks that require resource accounting. You can use RADIUS accounting independently of RADIUS authentication or authorization. The RADIUS accounting functions allow data to be sent at the start and end of services, showing the amount of resources (such as time, packets, bytes, and so forth) used during the session. An Internet service provider might use a freeware-based version of RADIUS access control and accounting software to meet special security and billing needs.


RADIUS is not suitable in these network security situations:

- Multiprotocol access environments. RADIUS does not support AppleTalk Remote Access (ARA), NetBIOS Frame Control Protocol (NBFCP), NetWare Asynchronous Services Interface (NASI), or X.25 PAD connections.
- Switch-to-switch or router-to-router situations. RADIUS does not provide two-way authentication. RADIUS can be used to authenticate from one device to a non-Cisco device if the non-Cisco device requires authentication.
- Networks using a variety of services. RADIUS generally binds a user to one service model.

## RADIUS Operation

When a wireless user attempts to log in and authenticate to an access point that is access controlled by a RADIUS server, authentication to the network occurs in the steps shown in [Figure 11-1](#):

Figure 11-1 Sequence for EAP Authentication



In steps 1 through 9 in [Figure 11-1](#), a wireless client device and a RADIUS server on the wired LAN use 802.1x and EAP to perform a mutual authentication through the access point. The RADIUS server sends an authentication challenge to the client. The client uses a one-way encryption of the user-supplied password to generate a response to the challenge and sends that response to the RADIUS server. Using information from its user database, the RADIUS server creates its own response and compares that to the response from the client. When the RADIUS server authenticates the client, the process repeats in reverse, and the client authenticates the RADIUS server.

When mutual authentication is complete, the RADIUS server and the client determine a WEP key that is unique to the client and provides the client with the appropriate level of network access, thereby approximating the level of security in a wired switched segment to an individual desktop. The client loads this key and prepares to use it for the logon session.

During the logon session, the RADIUS server encrypts and sends the WEP key, called a *session key*, over the wired LAN to the access point. The access point encrypts its broadcast key with the session key and sends the encrypted broadcast key to the client, which uses the session key to decrypt it. The client and access point activate WEP and use the session and broadcast WEP keys for all communications during the remainder of the session.

There is more than one type of EAP authentication, but the access point behaves the same way for each type: it relays authentication messages from the wireless client device to the RADIUS server and from the RADIUS server to the wireless client device. See the [“Assigning Authentication Types to an SSID” section on page 10-6](#) for instructions on setting up client authentication using a RADIUS server.

# Configuring RADIUS

This section describes how to configure your access point to support RADIUS. At a minimum, you must identify the host or hosts that run the RADIUS server software and define the method lists for RADIUS authentication. You can optionally define method lists for RADIUS authorization and accounting.

A method list defines the sequence and methods to be used to authenticate, to authorize, or to keep accounts on a user. You can use method lists to designate one or more security protocols to be used, thus ensuring a backup system if the initial method fails. The software uses the first method listed to authenticate, to authorize, or to keep accounts on users; if that method does not respond, the software selects the next method in the list. This process continues until there is successful communication with a listed method or the method list is exhausted.

You should have access to and should configure a RADIUS server before configuring RADIUS features on your access point.

This section contains this configuration information:

- [Default RADIUS Configuration, page 11-4](#)
- [Identifying the RADIUS Server Host, page 11-4](#) (required)
- [Configuring RADIUS Login Authentication, page 11-7](#) (required)
- [Defining AAA Server Groups, page 11-9](#) (optional)
- [Configuring RADIUS Authorization for User Privileged Access and Network Services, page 11-11](#) (optional)
- [Starting RADIUS Accounting, page 11-12](#) (optional)
- [Configuring Settings for All RADIUS Servers, page 11-13](#) (optional)
- [Configuring the Access Point to Use Vendor-Specific RADIUS Attributes, page 11-13](#) (optional)
- [Configuring the Access Point for Vendor-Proprietary RADIUS Server Communication, page 11-14](#) (optional)

**Note**

---

The RADIUS server CLI commands are disabled until you enter the **aaa new-model** command.

---

## Default RADIUS Configuration

RADIUS and AAA are disabled by default.

To prevent a lapse in security, you cannot configure RADIUS through a network management application. When enabled, RADIUS can authenticate users accessing the access point through the CLI.

## Identifying the RADIUS Server Host

Access point-to-RADIUS-server communication involves several components:

- Host name or IP address
- Authentication destination port
- Accounting destination port
- Key string

- Timeout period
- Retransmission value

You identify RADIUS security servers by their host name or IP address, host name and specific UDP port numbers, or their IP address and specific UDP port numbers. The combination of the IP address and the UDP port number creates a unique identifier allowing different ports to be individually defined as RADIUS hosts providing a specific AAA service. This unique identifier enables RADIUS requests to be sent to multiple UDP ports on a server at the same IP address.

If two different host entries on the same RADIUS server are configured for the same service—such as accounting—the second host entry configured acts as a fail-over backup to the first one. Using this example, if the first host entry fails to provide accounting services, the access point tries the second host entry configured on the same device for accounting services. (The RADIUS host entries are tried in the order that they are configured.)

A RADIUS server and the access point use a shared secret text string to encrypt passwords and exchange responses. To configure RADIUS to use the AAA security commands, you must specify the host running the RADIUS server daemon and a secret text (key) string that it shares with the access point.

The timeout, retransmission, and encryption key values can be configured globally per server for all RADIUS servers, or in some combination of global and per-server settings. To apply these settings globally to all RADIUS servers communicating with the access point, use the three unique global configuration commands: **radius-server timeout**, **radius-server retransmit**, and **radius-server key**. To apply these values on a specific RADIUS server, use the **radius-server host** global configuration command.


**Note**

If you configure both global and per-server functions (timeout, retransmission, and key commands) on the access point, the per-server timer, retransmission, and key value commands override global timer, retransmission, and key value commands. For information on configuring these settings on all RADIUS servers, see the [“Configuring Settings for All RADIUS Servers”](#) section on page 11-13.

You can configure the access point to use AAA server groups to group existing server hosts for authentication. For more information, see the [“Defining AAA Server Groups”](#) section on page 11-9.

Beginning in privileged EXEC mode, follow these steps to configure per-server RADIUS server communication. This procedure is required.

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>aaa new-model</b>	Enable AAA.

Command	Purpose
<b>Step 3</b> <b>radius-server host</b> { <i>hostname</i>   <i>ip-address</i> } [ <b>auth-port</b> <i>port-number</i> ] [ <b>acct-port</b> <i>port-number</i> ] [ <b>timeout</b> <i>seconds</i> ] [ <b>retransmit</b> <i>retries</i> ] [ <b>key</b> <i>string</i> ]	<p>Specify the IP address or host name of the remote RADIUS server host.</p> <ul style="list-style-type: none"> <li>• (Optional) For <b>auth-port</b> <i>port-number</i>, specify the UDP destination port for authentication requests.</li> <li>• (Optional) For <b>acct-port</b> <i>port-number</i>, specify the UDP destination port for accounting requests.</li> <li>• (Optional) For <b>timeout</b> <i>seconds</i>, specify the time interval that the access point waits for the RADIUS server to reply before retransmitting. The range is 1 to 1000. This setting overrides the <b>radius-server timeout</b> global configuration command setting. If no timeout is set with the <b>radius-server host</b> command, the setting of the <b>radius-server timeout</b> command is used.</li> <li>• (Optional) For <b>retransmit</b> <i>retries</i>, specify the number of times a RADIUS request is resent to a server if that server is not responding or responding slowly. The range is 1 to 1000. If no retransmit value is set with the <b>radius-server host</b> command, the setting of the <b>radius-server retransmit</b> global configuration command is used.</li> <li>• (Optional) For <b>key</b> <i>string</i>, specify the authentication and encryption key used between the switch and the RADIUS daemon running on the RADIUS server.</li> </ul> <p><b>Note</b> The key is a text string that must match the encryption key used on the RADIUS server. Always configure the key as the last item in the <b>radius-server host</b> command. Leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks are part of the key.</p> <p>To configure the access point to recognize more than one host entry associated with a single IP address, enter this command as many times as necessary, making sure that each UDP port number is different. The access point software searches for hosts in the order in which you specify them. Set the timeout, retransmit, and encryption key values to use with the specific RADIUS host.</p>
<b>Step 4</b> <b>end</b>	Return to privileged EXEC mode.
<b>Step 5</b> <b>show running-config</b>	Verify your entries.
<b>Step 6</b> <b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To remove the specified RADIUS server, use the **no radius-server host** *hostname* | *ip-address* global configuration command.

This example shows how to configure one RADIUS server to be used for authentication and another to be used for accounting:

```
AP(config)# radius-server host 172.29.36.49 auth-port 1612 key rad1
AP(config)# radius-server host 172.20.36.50 acct-port 1618 key rad2
```

This example shows how to configure *host1* as the RADIUS server and to use the default ports for both authentication and accounting:

```
AP(config)# radius-server host host1
```


**Note**

You also need to configure some settings on the RADIUS server. These settings include the IP address of the access point and the key string to be shared by both the server and the access point. For more information, refer to the RADIUS server documentation.

## Configuring RADIUS Login Authentication

To configure AAA authentication, you define a named list of authentication methods and then apply that list to various interfaces. The method list defines the types of authentication to be performed and the sequence in which they are performed; it must be applied to a specific interface before any of the defined authentication methods are performed. The only exception is the default method list (which, by coincidence, is named *default*). The default method list is automatically applied to all interfaces except those that have a named method list explicitly defined.

A method list describes the sequence and authentication methods to be queried to authenticate a user. You can designate one or more security protocols to be used for authentication, thus ensuring a backup system for authentication in case the initial method fails. The software uses the first method listed to authenticate users; if that method fails to respond, the software selects the next authentication method in the method list. This process continues until there is successful communication with a listed authentication method or until all defined methods are exhausted. If authentication fails at any point in this cycle—meaning that the security server or local username database responds by denying the user access—the authentication process stops, and no other authentication methods are attempted.

Beginning in privileged EXEC mode, follow these steps to configure login authentication. This procedure is required.

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>aaa new-model</code>	Enable AAA.

	Command	Purpose
Step 3	<b>aaa authentication login</b> { <b>default</b>   <i>list-name</i> } <i>method1</i> [ <i>method2</i> ...]	<p>Create a login authentication method list.</p> <ul style="list-style-type: none"> <li>To create a default list that is used when a named list is <i>not</i> specified in the <b>login authentication</b> command, use the <b>default</b> keyword followed by the methods that are to be used in default situations. The default method list is automatically applied to all interfaces. For more information on list names, click this link: <a href="http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgr/fsecur_c/fsaaa/scfathen.htm#xtocid2">http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgr/fsecur_c/fsaaa/scfathen.htm#xtocid2</a></li> <li>For <i>method1</i>..., specify the actual method the authentication algorithm tries. The additional methods of authentication are used only if the previous method returns an error, not if it fails.</li> </ul> <p>Select one of these methods:</p> <ul style="list-style-type: none"> <li><b>line</b>—Use the line password for authentication. You must define a line password before you can use this authentication method. Use the <b>password</b> <i>password</i> line configuration command.</li> <li><b>local</b>—Use the local username database for authentication. You must enter username information in the database. Use the <b>username</b> <i>password</i> global configuration command.</li> <li><b>radius</b>—Use RADIUS authentication. You must configure the RADIUS server before you can use this authentication method. For more information, see the “Identifying the RADIUS Server Host” section on page 11-4.</li> </ul>
Step 4	<b>line</b> [ <b>console</b>   <b>tty</b>   <b>vty</b> ] <i>line-number</i> [ <i>ending-line-number</i> ]	Enter line configuration mode, and configure the lines to which you want to apply the authentication list.
Step 5	<b>login authentication</b> { <b>default</b>   <i>list-name</i> }	<p>Apply the authentication list to a line or set of lines.</p> <ul style="list-style-type: none"> <li>If you specify <b>default</b>, use the default list created with the <b>aaa authentication login</b> command.</li> <li>For <i>list-name</i>, specify the list created with the <b>aaa authentication login</b> command.</li> </ul>
Step 6	<b>radius-server attribute 32 include-in-access-req format %h</b>	Configure the access point to send its system name in the NAS_ID attribute for authentication.
Step 7	<b>end</b>	Return to privileged EXEC mode.
Step 8	<b>show running-config</b>	Verify your entries.
Step 9	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable AAA, use the **no aaa new-model** global configuration command. To disable AAA authentication, use the **no aaa authentication login** { **default** | *list-name* } *method1* [*method2*...] global configuration command. To either disable RADIUS authentication for logins or to return to the default value, use the **no login authentication** { **default** | *list-name* } line configuration command.



## Defining AAA Server Groups

You can configure the access point to use AAA server groups to group existing server hosts for authentication. You select a subset of the configured server hosts and use them for a particular service. The server group is used with a global server-host list, which lists the IP addresses of the selected server hosts.

Server groups also can include multiple host entries for the same server if each entry has a unique identifier (the combination of the IP address and UDP port number), allowing different ports to be individually defined as RADIUS hosts providing a specific AAA service. If you configure two different host entries on the same RADIUS server for the same service (such as accounting), the second configured host entry acts as a fail-over backup to the first one.

You use the **server** group server configuration command to associate a particular server with a defined group server. You can either identify the server by its IP address or identify multiple host instances or entries by using the optional **auth-port** and **acct-port** keywords.

Beginning in privileged EXEC mode, follow these steps to define the AAA server group and associate a particular RADIUS server with it:

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	<b>configure terminal</b>	Enter global configuration mode.
<b>Step 2</b>	<b>aaa new-model</b>	Enable AAA.

Command	Purpose
<b>Step 3</b> <b>radius-server host</b> { <i>hostname</i>   <i>ip-address</i> } [ <b>auth-port</b> <i>port-number</i> ] [ <b>acct-port</b> <i>port-number</i> ] [ <b>timeout</b> <i>seconds</i> ] [ <b>retransmit</b> <i>retries</i> ] [ <b>key</b> <i>string</i> ]	<p>Specify the IP address or host name of the remote RADIUS server host.</p> <ul style="list-style-type: none"> <li>• (Optional) For <b>auth-port</b> <i>port-number</i>, specify the UDP destination port for authentication requests.</li> <li>• (Optional) For <b>acct-port</b> <i>port-number</i>, specify the UDP destination port for accounting requests.</li> <li>• (Optional) For <b>timeout</b> <i>seconds</i>, specify the time interval that the access point waits for the RADIUS server to reply before retransmitting. The range is 1 to 1000. This setting overrides the <b>radius-server timeout</b> global configuration command setting. If no timeout is set with the <b>radius-server host</b> command, the setting of the <b>radius-server timeout</b> command is used.</li> <li>• (Optional) For <b>retransmit</b> <i>retries</i>, specify the number of times a RADIUS request is resent to a server if that server is not responding or responding slowly. The range is 1 to 1000. If no retransmit value is set with the <b>radius-server host</b> command, the setting of the <b>radius-server retransmit</b> global configuration command is used.</li> <li>• (Optional) For <b>key</b> <i>string</i>, specify the authentication and encryption key used between the access point and the RADIUS daemon running on the RADIUS server.</li> </ul> <p><b>Note</b> The key is a text string that must match the encryption key used on the RADIUS server. Always configure the key as the last item in the <b>radius-server host</b> command. Leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks are part of the key.</p> <p>To configure the access point to recognize more than one host entry associated with a single IP address, enter this command as many times as necessary, making sure that each UDP port number is different. The access point software searches for hosts in the order in which you specify them. Set the timeout, retransmit, and encryption key values to use with the specific RADIUS host.</p>
<b>Step 4</b> <b>aaa group server radius</b> <i>group-name</i>	<p>Define the AAA server-group with a group name.</p> <p>This command puts the access point in a server group configuration mode.</p>
<b>Step 5</b> <b>server</b> <i>ip-address</i>	<p>Associate a particular RADIUS server with the defined server group. Repeat this step for each RADIUS server in the AAA server group.</p> <p>Each server in the group must be previously defined in Step 2.</p>
<b>Step 6</b> <b>end</b>	<p>Return to privileged EXEC mode.</p>
<b>Step 7</b> <b>show running-config</b>	<p>Verify your entries.</p>
<b>Step 8</b> <b>copy running-config startup-config</b>	<p>(Optional) Save your entries in the configuration file.</p>
<b>Step 9</b>	<p>Enable RADIUS login authentication. See the “<a href="#">Configuring RADIUS Login Authentication</a>” section on page 11-7.</p>

To remove the specified RADIUS server, use the **no radius-server host** *hostname | ip-address* global configuration command. To remove a server group from the configuration list, use the **no aaa group server radius** *group-name* global configuration command. To remove the IP address of a RADIUS server, use the **no server ip-address** server group configuration command.

In this example, the access point is configured to recognize two different RADIUS group servers (*group1* and *group2*). Group1 has two different host entries on the same RADIUS server configured for the same services. The second host entry acts as a fail-over backup to the first entry.

```
AP(config)# aaa new-model
AP(config)# radius-server host 172.20.0.1 auth-port 1000 acct-port 1001
AP(config)# radius-server host 172.10.0.1 auth-port 1645 acct-port 1646
AP(config)# aaa group server radius group1
AP(config-sg-radius)# server 172.20.0.1 auth-port 1000 acct-port 1001
AP(config-sg-radius)# exit
AP(config)# aaa group server radius group2
AP(config-sg-radius)# server 172.20.0.1 auth-port 2000 acct-port 2001
AP(config-sg-radius)# exit
```

## Configuring RADIUS Authorization for User Privileged Access and Network Services

AAA authorization limits the services available to a user. When AAA authorization is enabled, the access point uses information retrieved from the user's profile, which is in the local user database or on the security server, to configure the user's session. The user is granted access to a requested service only if the information in the user profile allows it.



### Note

This section describes setting up authorization for access point administrators, not for wireless client devices.

You can use the **aaa authorization** global configuration command with the **radius** keyword to set parameters that restrict a user's network access to privileged EXEC mode.

The **aaa authorization exec radius local** command sets these authorization parameters:

- Use RADIUS for privileged EXEC access authorization if authentication was performed by using RADIUS.
- Use the local database if authentication was not performed by using RADIUS.



### Note

Authorization is bypassed for authenticated users who log in through the CLI even if authorization has been configured.

Beginning in privileged EXEC mode, follow these steps to specify RADIUS authorization for privileged EXEC access and network services:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>aaa authorization network radius</b>	Configure the access point for user RADIUS authorization for all network-related service requests.
Step 3	<b>aaa authorization exec radius</b>	Configure the access point for user RADIUS authorization to determine if the user has privileged EXEC access.  The <b>exec</b> keyword might return user profile information (such as <b>autocommand</b> information).
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your entries.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable authorization, use the **no aaa authorization {network | exec} method1** global configuration command.

## Starting RADIUS Accounting

The AAA accounting feature tracks the services that users are accessing and the amount of network resources that they are consuming. When AAA accounting is enabled, the access point reports user activity to the RADIUS security server in the form of accounting records. Each accounting record contains accounting attribute-value (AV) pairs and is stored on the security server. This data can then be analyzed for network management, client billing, or auditing.

Beginning in privileged EXEC mode, follow these steps to enable RADIUS accounting for each Cisco IOS privilege level and for network services:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>aaa accounting network start-stop radius</b>	Enable RADIUS accounting for all network-related service requests.
Step 3	<b>ip radius source-interface bvi1</b>	Configure the access point to send its BVI IP address in the NAS_IP_ADDRESS attribute for accounting records.
Step 4	<b>aaa accounting update periodic minutes</b>	Enter an accounting update interval in minutes.
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>show running-config</b>	Verify your entries.
Step 7	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable accounting, use the **no aaa accounting {network | exec} {start-stop} method1...** global configuration command.

## Configuring Settings for All RADIUS Servers

Beginning in privileged EXEC mode, follow these steps to configure global communication settings between the access point and all RADIUS servers:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>radius-server key</b> <i>string</i>	Specify the shared secret text string used between the access point and all RADIUS servers.  <b>Note</b> The key is a text string that must match the encryption key used on the RADIUS server. Leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks are part of the key.
Step 3	<b>radius-server retransmit</b> <i>retries</i>	Specify the number of times the access point sends each RADIUS request to the server before giving up. The default is 3; the range 1 to 1000.
Step 4	<b>radius-server timeout</b> <i>seconds</i>	Specify the number of seconds an access point waits for a reply to a RADIUS request before resending the request. The default is 5 seconds; the range is 1 to 1000.
Step 5	<b>radius-server deadtime</b> <i>minutes</i>	Specify the number of minutes the access point waits for a response from a RADIUS server before skipping to the next server, thus avoiding the wait for the request to timeout before trying the next configured server. The default is 0; the range is 1 to 1440 minutes.  <b>Note</b> If you set up more than one RADIUS server, you must configure the RADIUS server deadtime for optimal performance.
Step 6	<b>radius-server attribute 32 include-in-access-req format %h</b>	Configure the access point to send its system name in the NAS_ID attribute for authentication.
Step 7	<b>end</b>	Return to privileged EXEC mode.
Step 8	<b>show running-config</b>	Verify your settings.
Step 9	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To return to the default setting for the retransmit, timeout, and deadtime, use the **no** forms of these commands.

## Configuring the Access Point to Use Vendor-Specific RADIUS Attributes

The Internet Engineering Task Force (IETF) draft standard specifies a method for communicating vendor-specific information between the access point and the RADIUS server by using the vendor-specific attribute (attribute 26). Vendor-specific attributes (VSAs) allow vendors to support their own extended attributes not suitable for general use. The Cisco RADIUS implementation supports one vendor-specific option by using the format recommended in the specification. Cisco's vendor-ID is 9, and the supported option has vendor-type 1, which is named *cisco-avpair*. The value is a string with this format:

```
protocol : attribute sep value *
```

*Protocol* is a value of the Cisco protocol attribute for a particular type of authorization. *Attribute* and *value* are an appropriate AV pair defined in the Cisco TACACS+ specification, and *sep* is = for mandatory attributes and \* for optional attributes. This allows the full set of features available for TACACS+ authorization to also be used for RADIUS.

For example, the following AV pair activates Cisco's *multiple named ip address pools* feature during IP authorization (during PPP's IPCP address assignment):

```
cisco-avpair= "ip:addr-pool=first"
```

The following example shows how to provide a user logging in from an access point with immediate access to privileged EXEC commands:

```
cisco-avpair= "shell:priv-lvl=15"
```

Other vendors have their own unique vendor-IDs, options, and associated VSAs. For more information about vendor-IDs and VSAs, refer to RFC 2138, "Remote Authentication Dial-In User Service (RADIUS)."

Beginning in privileged EXEC mode, follow these steps to configure the access point to recognize and use VSAs:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>radius-server vsa send [accounting   authentication]</b>	Enable the access point to recognize and use VSAs as defined by RADIUS IETF attribute 26. <ul style="list-style-type: none"> <li>(Optional) Use the <b>accounting</b> keyword to limit the set of recognized vendor-specific attributes to only accounting attributes.</li> <li>(Optional) Use the <b>authentication</b> keyword to limit the set of recognized vendor-specific attributes to only authentication attributes.</li> </ul> If you enter this command without keywords, both accounting and authentication vendor-specific attributes are used.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your settings.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

For a complete list of RADIUS attributes or more information about VSA 26, refer to the "RADIUS Attributes" appendix in the *Cisco IOS Security Configuration Guide for Release 12.2*.

## Configuring the Access Point for Vendor-Proprietary RADIUS Server Communication

Although an IETF draft standard for RADIUS specifies a method for communicating vendor-proprietary information between the access point and the RADIUS server, some vendors have extended the RADIUS attribute set in a unique way. Cisco IOS software supports a subset of vendor-proprietary RADIUS attributes.

As mentioned earlier, to configure RADIUS (whether vendor-proprietary or IETF draft-compliant), you must specify the host running the RADIUS server daemon and the secret text string it shares with the access point. You specify the RADIUS host and secret text string by using the **radius-server** global configuration commands.

Beginning in privileged EXEC mode, follow these steps to specify a vendor-proprietary RADIUS server host and a shared secret text string:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>radius-server host</b> { <i>hostname</i>   <i>ip-address</i> } <b>non-standard</b>	Specify the IP address or host name of the remote RADIUS server host and identify that it is using a vendor-proprietary implementation of RADIUS.
Step 3	<b>radius-server key</b> <i>string</i>	Specify the shared secret text string used between the access point and the vendor-proprietary RADIUS server. The access point and the RADIUS server use this text string to encrypt passwords and exchange responses.  <b>Note</b> The key is a text string that must match the encryption key used on the RADIUS server. Leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks are part of the key.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your settings.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To delete the vendor-proprietary RADIUS host, use the **no radius-server host** {*hostname* | *ip-address*} **non-standard** global configuration command. To disable the key, use the **no radius-server key** global configuration command.

This example shows how to specify a vendor-proprietary RADIUS host and to use a secret key of *rad124* between the access point and the server:

```
AP(config)# radius-server host 172.20.30.15 nonstandard
AP(config)# radius-server key rad124
```

## Displaying the RADIUS Configuration

To display the RADIUS configuration, use the **show running-config** privileged EXEC command.







## Configuring VLANs

---

This chapter describes how to configure your access point to operate with the VLANs set up on your wired LAN. These sections describe how to configure your access point to support VLANs:

- [Understanding VLANs, page 12-2](#)
- [Configuring VLANs, page 12-4](#)
- [VLAN Configuration Example, page 12-7](#)

# Understanding VLANs

A VLAN is a switched network that is logically segmented, by functions, project teams, or applications rather than on a physical or geographical basis. For example, all workstations and servers used by a particular workgroup team can be connected to the same VLAN, regardless of their physical connections to the network or the fact that they might be intermingled with other teams. You use VLANs to reconfigure the network through software rather than physically unplugging and moving devices or wires.

A VLAN can be thought of as a broadcast domain that exists within a defined set of switches. A VLAN consists of a number of end systems, either hosts or network equipment (such as bridges and routers), connected by a single bridging domain. The bridging domain is supported on various pieces of network equipment such as LAN switches that operate bridging protocols between them with a separate group for each VLAN.


VLANs provide the segmentation services traditionally provided by routers in LAN configurations. VLANs address scalability, security, and network management. You should consider several key issues when designing and building switched LAN networks:

- LAN segmentation
- Security
- Broadcast control
- Performance
- Network management
- Communication between VLANs

You extend VLANs into a wireless LAN by adding IEEE 802.11Q tag awareness to the access point. Frames destined for different VLANs are transmitted by the access point wirelessly on different SSIDs with different WEP keys. Only the clients associated with that VLAN receive those packets. Conversely, packets coming from a client associated with a certain VLAN are 802.11Q tagged before they are forwarded onto the wired network.

[Figure 12-1](#) shows the difference between traditional physical LAN segmentation and logical VLAN segmentation with wireless devices connected.

Figure 12-1 LAN and VLAN Segmentation with Wireless Devices



81652

## Related Documents

These documents provide more detailed information pertaining to VLAN design and configuration:

- *Cisco IOS Switching Services Configuration Guide*. Click this link to browse to this document: [http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fswtch\\_c/index.htm](http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fswtch_c/index.htm)
- *Cisco Internetwork Design Guide*. Click this link to browse to this document: <http://www.cisco.com/univercd/cc/td/doc/cisintwk/idg4/index.htm>
- *Cisco Internetworking Technology Handbook*. Click this link to browse to this document: [http://www.cisco.com/univercd/cc/td/doc/cisintwk/ito\\_doc/index.htm](http://www.cisco.com/univercd/cc/td/doc/cisintwk/ito_doc/index.htm)
- *Cisco Internetworking Troubleshooting Guide*. Click this link to browse to this document: [http://www.cisco.com/univercd/cc/td/doc/cisintwk/itg\\_v1/index.htm](http://www.cisco.com/univercd/cc/td/doc/cisintwk/itg_v1/index.htm)

## Incorporating Wireless Devices Into VLANs

The basic wireless components of a VLAN consist of an access point and a client associated to it using wireless technology. The access point is physically connected through a trunk port to the network VLAN switch on which the VLAN is configured. The physical connection to the VLAN switch is through the access point's Ethernet port.

In fundamental terms, the key to configuring an access point to connect to a specific VLAN is by configuring its SSID to recognize that VLAN. Since VLANs are identified by a VLAN ID, it follows that if the SSID on an access point is configured to recognize a specific VLAN ID, a connection to the VLAN is established. When this connection is made, associated wireless client devices having the same SSID can access the VLAN through the access point. The VLAN processes data to and from the clients the same way that it processes data to and from wired connections. You can configure up to 16 SSIDs on your access point, so you can support up to 16 VLANs.

You can use the VLAN feature to deploy wireless devices with greater efficiency and flexibility. For example, one access point can now handle the specific requirements of multiple users having widely varied network access and permissions. Without VLAN capability, multiple access points would have to be employed to serve classes of users based on the access and permissions they were assigned.

These are two common strategies for deploying wireless VLANs:

- **Segmentation by user groups:** You can segment your wireless LAN user community and enforce a different security policy for each user group. For example, you can create three wired and wireless VLANs in an enterprise environment for full-time and part-time employees and also provide guest access.
- **Segmentation by device types:** You can segment your wireless LAN to allow different devices with different security capabilities to join the network. For example, some wireless users might have handheld devices that support only static WEP, and some wireless users might have more sophisticated devices using dynamic WEP. You can group and isolate these devices into separate VLANs.

## Configuring VLANs

These sections describe how to configure VLANs on your access point:

- [Configuring a VLAN, page 12-4](#)
- [Using a RADIUS Server to Assign Users to VLANs, page 12-6](#)
- [Viewing VLANs Configured on the Access Point, page 12-6](#)

## Configuring a VLAN

Configuring your access point to support VLANs is a three-step process:

1. Assign SSIDs to VLANs.
2. Assign authentication settings to SSIDs.
3. Enable the VLAN on the radio and Ethernet ports.

This section describes how to assign SSIDs to VLANs and how to enable a VLAN on the access point radio and Ethernet ports. For detailed instructions on assigning authentication types to SSIDs, see [Chapter 10, "Configuring Authentication Types."](#) For instructions on assigning other settings to SSIDs, see [Chapter 8, "Configuring Multiple SSIDs."](#)

You can configure up to 16 SSIDs on the access point, so you can support up to 16 VLANs that are configured on your LAN.

Beginning in privileged EXEC mode, follow these steps to assign an SSID to a VLAN and enable the VLAN on the access point radio and Ethernet ports:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>ssid <i>ssid-string</i></b>	Create an SSID and enter SSID configuration mode for the new SSID. The SSID can consist of up to 32 alphanumeric characters. SSIDs are case sensitive.  <b>Note</b> You use the <b>ssid</b> command's authentication options to configure an authentication type for each SSID. See <a href="#">Chapter 10, "Configuring Authentication Types,"</a> for instructions on configuring authentication types.
Step 4	<b>vlan <i>vlan-id</i></b>	(Optional) Assign the SSID to a VLAN on your network. Client devices that associate using the SSID are grouped into this VLAN. Enter a VLAN ID from 1 to 4095.
Step 5	<b>exit</b>	Return to interface configuration mode for the radio interface.
Step 6	<b>interface dot11radio0.x</b>	Enter interface configuration mode for the radio VLAN sub interface.
Step 7	<b>encapsulation dot1q <i>vlan-id</i> [native]</b>	Enable a VLAN on the radio interface.  (Optional) Designate the VLAN as the native VLAN. On many networks, the native VLAN is VLAN 1.
Step 8	<b>exit</b>	Return to global configuration mode.
Step 9	<b>interface fastEthernet0.x</b>	Enter interface configuration mode for the Ethernet VLAN subinterface.
Step 10	<b>encapsulation dot1q <i>vlan-id</i> [native]</b>	Enable a VLAN on the Ethernet interface.  (Optional) Designate the VLAN as the native VLAN. On many networks, the native VLAN is VLAN 1.
Step 11	<b>end</b>	Return to privileged EXEC mode.
Step 12	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

This example shows how to:

- Name an SSID
- Assign the SSID to a VLAN
- Enable the VLAN on the radio and Ethernet ports as the native VLAN

```
ap1100# configure terminal
ap1100(config)# interface dot11radio0
ap1100(config-if)# ssid batman
ap1100(config-ssid)# vlan 1
ap1100(config-ssid)# exit
ap1100(config)# interface dot11radio0.1
ap1100(config-subif)# encapsulation dot1q 1 native
ap1100(config-subif)# exit
```

```

ap1100(config)# interface fastEthernet0.1
ap1100(config-subif)# encapsulation dot1q 1 native
ap1100(config-subif)# exit
ap1100(config)# end

```

## Using a RADIUS Server to Assign Users to VLANs

You can configure your RADIUS authentication server to assign users or groups of users to a specific VLAN when they authenticate to the network.

The VLAN-mapping process consists of these steps:

1. A client device associates to the access point using any SSID configured on the access point.
2. The client begins RADIUS authentication.
3. When the client authenticates successfully, the RADIUS server maps the client to a specific VLAN, regardless of the VLAN mapping defined for the SSID the client is using on the access point. If the server does not return any VLAN attribute for the client, the client is assigned to the VLAN specified by the SSID mapped locally on the access point.

These are the RADIUS user attributes used for vlan-id assignment. Each attribute must have a common Tag value to identify the grouped relationship.

- IETF 64 (Tunnel Type): Set this attribute to **VLAN**
- IETF 65 (Tunnel Medium Type): Set this attribute to **802**
- IETF 81 (Tunnel Private Group ID): Set this attribute to *vlan-id*

## Viewing VLANs Configured on the Access Point

In privileged EXEC mode, use the **show vlan** command to view the VLANs that the access point supports. This is sample output from a **show vlan** command:

```

Virtual LAN ID: 1 (IEEE 802.1Q Encapsulation)

    vLAN Trunk Interfaces: Dot11Radio0
FastEthernet0
Virtual-Dot11Radio0

    This is configured as native Vlan for the following interface(s) :
Dot11Radio0
FastEthernet0
Virtual-Dot11Radio0

    Protocols Configured:  Address:          Received:      Transmitted:
    Bridging              Bridge Group 1    201688        0
    Bridging              Bridge Group 1    201688        0
    Bridging              Bridge Group 1    201688        0

Virtual LAN ID: 2 (IEEE 802.1Q Encapsulation)

    vLAN Trunk Interfaces: Dot11Radio0.2
FastEthernet0.2
Virtual-Dot11Radio0.2

    Protocols Configured:  Address:          Received:      Transmitted:

```

# VLAN Configuration Example

This example shows how to use VLANs to manage wireless devices on a college campus. In this example, three levels of access are available through VLANs configured on the wired network:

- **Management access**—Highest level of access; users can access all internal drives and files, departmental databases, top-level financial information, and other sensitive information. Management users are required to authenticate using Cisco LEAP.
- **Faculty access**—Medium level of access; users can access school's Intranet and Internet, access internal files, access student databases, and view internal information such as human resources, payroll, and other faculty-related material. Faculty users are required to authenticate using Cisco LEAP.
- **Student access**—Lowest level of access; users can access school's Intranet and the Internet, obtain class schedules, view grades, make appointments, and perform other student-related activities. Students are allowed to join the network using static WEP.

In this scenario, a minimum of three VLAN connections are required, one for each level of access. Because the access point can handle up to 16 SSIDs, you can use the basic design shown in [Table 12-1](#).

**Table 12-1 Access Level SSID and VLAN Assignment**

Level of Access	SSID	VLAN ID
Management	boss	01
Faculty	teach	02
Student	learn	03

Managers configure their wireless client adapters to use SSID boss, faculty members configure their clients to use SSID teach, and students configure their wireless client adapters to use SSID learn. When these clients associate to the access point, they automatically belong to the correct VLAN.

You would complete these steps to support the VLANs in this example:

1. Configure or confirm the configuration of these VLANs on one of the switches on your LAN.
2. On the access point, assign an SSID to each VLAN.
3. Assign authentication types to each SSID.
4. Configure VLAN 1, the Management VLAN, on both the fastethernet and dot11radio interfaces on the access point. You should make this VLAN the native VLAN.
5. Configure VLANs 2 and 3 on both the fastethernet and dot11radio interfaces on the access point.
6. Configure the client devices.

Table 12-2 shows the commands needed to configure the three VLANs in this example.

**Table 12-2 Configuration Commands for VLAN Example**

Configuring VLAN 1	Configuring VLAN 2	Configuring VLAN 3
<pre>ap1100# configure terminal ap1100(config)# interface dot11radio 0 ap1100(config-if)# ssid boss ap1100(config-ssid)# vlan 01 ap1100(config-ssid)# end</pre>	<pre>ap1100# configure terminal ap1100(config)# interface dot11radio 0 ap1100(config-if)# ssid teach ap1100(config-ssid)# vlan 02 ap1100(config-ssid)# end</pre>	<pre>ap1100# configure terminal ap1100(config)# interface dot11radio 0 ap1100(config-if)# ssid learn ap1100(config-ssid)# vlan 03 ap1100(config-ssid)# end</pre>
<pre>ap1100 configure terminal ap1100(config) interface FastEthernet0.1 ap1100(config-subif) encapsulation dot1Q 1 native ap1100(config-subif) exit</pre>	<pre>ap1100(config) interface FastEthernet0.2 ap1100(config-subif) encapsulation dot1Q 2 ap1100(config-subif) bridge-group 2 ap1100(config-subif) exit</pre>	<pre>ap1100(config) interface FastEthernet0.3 ap1100(config-subif) encapsulation dot1Q 3 ap1100(config-subif) bridge-group 3 ap1100(config-subif) exit</pre>
<pre>ap1100(config)# interface Dot11Radio0.1 ap1100(config-subif)# encapsulation dot1Q 1 native ap1100(config-subif)# exit</pre> <p><b>Note</b> You do not need to configure a bridge group on the subinterface that you set up as the native VLAN. This bridge group is moved to the native subinterface automatically to maintain the link to bridge virtual interface (BVI) 1, which represents both the radio and Ethernet interfaces.</p>	<pre>ap1100(config) interface Dot11Radio0.2 ap1100(config-subif) encapsulation dot1Q 2 ap1100(config-subif) bridge-group 2 ap1100(config-subif) exit</pre>	<pre>ap1100(config) interface Dot11Radio0.3 ap1100(config-subif) encapsulation dot1Q 3 ap1100(config-subif) bridge-group 3 ap1100(config-subif) exit</pre>



Table 12-3 shows the results of the configuration commands in Table 12-2. Use the **show running** command to display the running configuration on the access point.

**Table 12-3 Results of Example Configuration Commands**

VLAN 1 Interfaces	VLAN 2 Interfaces	VLAN 3 Interfaces
<pre>interface Dot11Radio0.1 encapsulation dot1Q 1 native no ip route-cache no cdp enable bridge-group 1 bridge-group 1 subscriber-loop-control bridge-group 1 block-unknown-source no bridge-group 1 source-learning no bridge-group 1 unicast-flooding bridge-group 1 spanning-disabled</pre>	<pre>interface Dot11Radio0.2 encapsulation dot1Q 2 no ip route-cache no cdp enable bridge-group 2 bridge-group 2 subscriber-loop-control bridge-group 2 block-unknown-source no bridge-group 2 source-learning no bridge-group 2 unicast-flooding bridge-group 2 spanning-disabled</pre>	<pre>interface Dot11Radio0.3 encapsulation dot1Q 3 no ip route-cache bridge-group 3 bridge-group 3 subscriber-loop-control bridge-group 3 block-unknown-source no bridge-group 3 source-learning no bridge-group 3 unicast-flooding bridge-group 3 spanning-disabled</pre>
<pre>interface FastEthernet0.1 encapsulation dot1Q 1 native no ip route-cache bridge-group 1 no bridge-group 1 source-learning bridge-group 1 spanning-disabled</pre>	<pre>interface FastEthernet0.2 encapsulation dot1Q 2 no ip route-cache bridge-group 2 no bridge-group 2 source-learning bridge-group 2 spanning-disabled</pre>	<pre>interface FastEthernet0.3 encapsulation dot1Q 3 no ip route-cache bridge-group 3 no bridge-group 3 source-learning bridge-group 3 spanning-disabled</pre>

Notice that when you configure a bridge group on the radio interface, these commands are set automatically:

```
bridge-group 2 subscriber-loop-control
bridge-group 2 block-unknown-source
no bridge-group 2 source-learning
no bridge-group 2 unicast-flooding
bridge-group 2 spanning-disabled
```

When you configure a bridge group on the FastEthernet interface, these commands are set automatically:

```
no bridge-group 2 source-learning
bridge-group 2 spanning-disabled
```





## Configuring QoS

---

This chapter describes how to configure quality of service (QoS) on your access point. With this feature, you can provide preferential treatment to certain traffic at the expense of others. Without QoS, the access point offers best-effort service to each packet, regardless of the packet contents or size. It sends the packets without any assurance of reliability, delay bounds, or throughput.



**Note**

---

For complete syntax and usage information for the commands used in this chapter, refer to the *Cisco Aironet 1100 Series Access Point Command Reference* for this release.

---

This chapter consists of these sections:

- [Understanding QoS for Wireless LANs, page 13-2](#)
- [Configuring QoS, page 13-3](#)
- [QoS Configuration Examples, page 13-10](#)

# Understanding QoS for Wireless LANs

Typically, networks operate on a best-effort delivery basis, which means that all traffic has equal priority and an equal chance of being delivered in a timely manner. When congestion occurs, all traffic has an equal chance of being dropped.

When you configure QoS on the access point, you can select specific network traffic, prioritize it, and use congestion-management and congestion-avoidance techniques to provide preferential treatment. Implementing QoS in your wireless LAN makes network performance more predictable and bandwidth utilization more effective.

When you configure QoS, you create QoS policies and apply the policies to the VLANs configured on your access point. If you do not use VLANs on your network, you can apply your QoS policies to the access point's Ethernet and radio ports.

## QoS for Wireless LANs Versus QoS on Wired LANs

The QoS implementation for wireless LANs differs from QoS implementations on other Cisco devices. With QoS enabled, access points perform the following:

- They do not classify packets; they prioritize packets based on DSCP value, client type (such as a wireless phone), or the priority value in the 802.1q or 802.1p tag.
- They do not match packets using ACL; they use only MQC class-map for matching clauses.
- They do not construct internal DSCP values; they only support mapping by assigning IP DSCP, Precedence, or Protocol values to L2 COS values.
- They carry out EDCF like queuing on the radio egress port only.
- They do only FIFO queueing on the Ethernet egress port.
- They support only 802.1Q/P tagged packets. Access points do not support ISL.
- They support only MQC policy-map **set cos** action.
- They prioritize the traffic from voice clients (such as Symbol phones) over traffic from other clients when the QoS Element for Wireless Phones feature is enabled.
- They support Spectralink phones using the class-map IP protocol clause with the protocol value set to 119.

To contrast the wireless LAN QoS implementation with the QoS implementation on other Cisco network devices, see the *Cisco IOS Quality of Service Solutions Configuration Guide* at this URL:

[http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fqos\\_c/index.htm](http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/fqos_c/index.htm)


## Impact of QoS on a Wireless LAN

Wireless LAN QoS features are a subset of the proposed 802.11e draft. QoS on wireless LANs provides prioritization of traffic from the access point over the WLAN based on traffic classification.

Just as in other media, you might not notice the effects of QoS on a lightly loaded wireless LAN. The benefits of QoS become more obvious as the load on the wireless LAN increases, keeping the latency, jitter, and loss for selected traffic types within an acceptable range.

QoS on the wireless LAN focuses on downstream prioritization from the access point. [Figure 13-1](#) shows the upstream and downstream traffic flow.

Figure 13-1 Upstream and Downstream Traffic Flow



- The radio downstream flow is traffic transmitted out the access point radio to a wireless client device. This traffic is the main focus for QoS on a wireless LAN.
- The radio upstream flow is traffic transmitted out the wireless client device to the access point. QoS for wireless LANs does not affect this traffic.
- The Ethernet downstream flow is traffic sent from a switch or a router to the Ethernet port on the access point. If QoS is enabled on the switch or router, the switch or router might prioritize and rate-limit traffic to the access point.
- The Ethernet upstream flow is traffic sent from the access point Ethernet port to a switch or router on the wired LAN. The access point does not prioritize traffic that it sends to the wired LAN based on traffic classification.

## Precedence of QoS Settings

When you enable QoS, the access point queues packets based on the L2 class of service value for each packet. The access point applies QoS policies in this order:

1. Packets already classified—When the access point receives packets from a QoS-enabled switch or router that has already classified the packets with non-zero 802.1Q/P user\_priority values, the access point uses that classification and does not apply other QoS policy rules to the packets. An existing classification takes precedence over all other policies on the access point.
2. *QoS Element for Wireless Phones* setting—If you enable the *QoS Element for Wireless Phones* setting, traffic from voice clients takes priority over other traffic regardless of other policy settings. The *QoS Element for Wireless Phones* setting takes precedence over other policies, second only to previously assigned packet classifications.
3. Policies you create on the access point—QoS Policies that you create and apply to VLANs or to the access point interfaces are third in precedence after previously classified packets and the *QoS Element for Wireless Phones* setting.
4. Default classification for all packets on VLAN—If you set a default classification for all packets on a VLAN, that policy is fourth in the precedence list.

## Configuring QoS

QoS is disabled by default. This section describes how to configure QoS on your access point. It contains this configuration information:

- [Configuration Guidelines, page 13-4](#)
- [Configuring QoS Using the Web-Browser Interface, page 13-4](#)
- [Adjusting Radio Traffic Class Definitions, page 13-8](#)

## Configuration Guidelines

Before configuring QoS on your access point, you should be aware of this information:

- The most important guideline in QoS deployment is to be familiar with the traffic on your wireless LAN. If you know the applications used by wireless client devices, the applications' sensitivity to delay, and the amount of traffic associated with the applications, you can configure QoS to improve performance.
- QoS does not create additional bandwidth for your wireless LAN; it helps control the allocation of bandwidth. If you have plenty of bandwidth on your wireless LAN, you might not need to configure QoS.

## Configuring QoS Using the Web-Browser Interface

This section describes configuring QoS using the web-browser interface.

For a list of IOS commands for configuring QoS using the CLI, consult the *Cisco Aironet 1100 Series Access Point Command Reference*. Follow these steps to browse to the command reference:

1. Click this link to browse to the Cisco Aironet documentation home page:  
<http://www.cisco.com/univercd/cc/td/doc/product/wireless/index.htm>
2. Follow this path to the product, document, and chapter:  
**Aironet 1100 Series Wireless LAN Products > Cisco Aironet 1100 Series Access Points > Cisco Aironet 1100 Series Access Point Command Reference**

Follow these steps to configure QoS:

- 
- Step 1** If you use VLANs on your wireless LAN, make sure the necessary VLANs are configured on your access point before configuring QoS.
- Step 2** Click **Services** in the task menu on the left side of any page in the web-browser interface. When the list of Services expands, click **QoS**. The QoS Policies page appears. [Figure 13-2](#) shows the QoS Policies page.

Figure 13-2 QoS Policies Page

Close Window

CISCO SYSTEMS

Cisco 1100 Access Point

QoS POLICIES RADIO TRAFFIC CLASSES ADVANCED

Hostname AP1100 AP1100 uptime is 7 hours, 31 minutes

Services: QoS Policies

Create/ Edit Policies

Create/ Edit Policy: <NEW >

Policy Name:

Classifications:

Delete Classification

Match Classifications

IP Precedence: Routine (0)

IP DSCP: Best Effort

IP Protocol 119

Default classification for packets on the VLAN

Apply Class of Service

Best Effort (0) Add

Best Effort (0) Add

Best Effort (0) Add

Best Effort (0) Add

Apply Delete Cancel

Apply Policies to Interface/ VLANs

VLAN 77	FastEthernet	802.11b Radio
Incoming	<NONE >	<NONE >
Outgoing	<NONE >	<NONE >
VLAN 87	FastEthernet	802.11b Radio
Incoming	<NONE >	<NONE >
Outgoing	<NONE >	<NONE >

Apply Cancel

Close Window Copyright (c) 1992-2002 by Cisco Systems, Inc. 81948

- Step 3** With <NEW> selected in the Create/Edit Policy field, type a name for the QoS policy in the Policy Name entry field. The name can contain up to 25 alphanumeric characters. Do not include spaces in the policy name.
- Step 4** If the packets that you need to prioritize contain IP precedence information in the IP header TOS field, select an IP precedence classification from the IP Precedence drop-down menu. Menu selections include:
- Routine (0)

- Priority (1)
- Immediate (2)
- Flash (3)
- Flash Override (4)
- Critic/CCP (5)
- Internet Control (6)
- Network Control (7)

**Step 5** Use the Apply Class of Service drop-down menu to select the class of service that the access point will apply to packets of the type that you selected from the IP Precedence menu. The access point matches your IP Precedence selection with your class of service selection. Settings in the Apply Class of Service menu include:

- Best Effort (0)
- Background (1)
- Spare (2)
- Excellent (3)
- Control Lead (4)
- Video <100ms Latency (5)
- Voice <100ms Latency (6)
- Network Control (7)

**Step 6** Click the **Add** button beside the Class of Service menu for IP Precedence. The classification appears in the Classifications field. To delete a classification, select it and click the **Delete** button beside the Classifications field.


**Step 7** If the packets that you need to prioritize contain IP DSCP precedence information in the IP header TOS field, select an IP DSCP classification from the IP DSCP drop-down menu. Menu selections include:

- Best Effort
- Assured Forwarding — Class 1 Low
- Assured Forwarding — Class 1 Medium
- Assured Forwarding — Class 1 High
- Assured Forwarding — Class 2 Low
- Assured Forwarding — Class 2 Medium
- Assured Forwarding — Class 2 High
- Assured Forwarding — Class 3 Low
- Assured Forwarding — Class 3 Medium
- Assured Forwarding — Class 3 High
- Assured Forwarding — Class 4 Low
- Assured Forwarding — Class 4 Medium
- Assured Forwarding — Class 4 High
- Class Selector 1
- Class Selector 2



- Class Selector 3
  - Class Selector 4
  - Class Selector 5
  - Class Selector 6
  - Class Selector 7
  - Expedited Forwarding
- Step 8** Use the Apply Class of Service drop-down menu to select the class of service that the access point will apply to packets of the type that you selected from the IP DSCP menu. The access point matches your IP DSCP selection with your class of service selection.
- Step 9** Click the **Add** button beside the Class of Service menu for IP DSCP. The classification appears in the Classifications field.
- Step 10** If you need to prioritize the packets from Spectralink phones (IP Protocol 119) on your wireless LAN, use the Apply Class of Service drop-down menu to select the class of service that the access point will apply to Spectralink phone packets. The access point matches Spectralink phone packets with your class of service selection.
- Step 11** Click the **Add** button beside the Class of Service menu for IP Protocol 119. The classification appears in the Classifications field.
- Step 12** If you want to set a default classification for all packets on a VLAN, use the Apply Class of Service drop-down menu to select the class of service that the access point will apply to all packets on a VLAN. The access point matches all packets with your class of service selection.
- Step 13** Click the **Add** button beside the Class of Service menu for *Default classification for packets on the VLAN*. The classification appears in the Classifications field.
- Step 14** When you finish adding classifications to the policy, click the **Apply** button under the Apply Class of Service drop-down menus. To cancel the policy and reset all fields to defaults, click the **Cancel** button under the Apply Class of Service drop-down menus. To delete the entire policy, click the **Delete** button under the Apply Class of Service drop-down menus.
- Step 15** Use the Apply Policies to Interface/VLANs drop-down menus to apply policies to the access point Ethernet and radio ports. If VLANs are configured on the access point, drop-down menus for each VLAN's virtual ports appear in this section. If VLANs are not configured on the access point, drop-down menus for each interface appear.
- Step 16** Click the **Apply** button at the bottom of the page to apply the policies to the access point ports.
- Step 17** If you want the access point to give priority to all voice packets regardless of VLAN, click the **Advanced** tab. [Figure 13-3](#) shows the QoS Policies - Advanced page.

Figure 13-3 QoS Policies - Advanced Page



Select **Enable** and click **Apply** to give top priority to all voice packets.

## Adjusting Radio Traffic Class Definitions

The access point uses the radio traffic class definitions to calculate backoff times for each packet. As a rule, high-priority packets have short backoff times.

The default values in the Min and Max Contention Window fields and in the Slot Time fields are based on settings recommended in IEEE Draft Standard 802.11e. For detailed information on these values, consult that standard.

We strongly recommend that you use the default settings on the Radio Traffic Classes page. Changing these values can lead to unexpected blockages of traffic on your wireless LAN, and the blockages might be difficult to diagnose. If you change these values and find that you need to reset them to defaults, use the default settings listed in [Table 13-1](#).

The values listed in [Table 13-1](#) are to the power of 2. The access point computes Contention Window values with this equation:

$$CW = 2^{**} X \text{ minus } 1$$

where X is the value from [Table 13-1](#).

Table 13-1 Default QoS Radio Traffic Class Definitions

Class of Service	Min Contention Window	Max Contention Window	Fixed Slot Time
Best Effort	5	10	2
Background	6	10	3
Spare	5	10	3
Excellent Effort	5	10	2
Controlled Load	4	10	2
Video <100ms Latency	4	8	2
Voice <100ms Latency	2	8	2
Network Control	3	8	2

Figure 13-4 shows the Radio Traffic Classes page.

Figure 13-4 Radio Traffic Classes Page

Close Window

CISCO SYSTEMS

**Cisco 1100 Access Point**

QoS POLICIES RADIO TRAFFIC CLASSES ADVANCED

Hostname AP1100 AP1100 uptime is 8 hours, 46 minutes

Services: QoS Policies - Traffic Class Definition

Class of Service	Min Contention Window (2 <sup>2</sup> ; x can be 0-10)	Max Contention Window (2 <sup>2</sup> ; x can be 0-10)	Fixed Slot Time (2-20)
Best Effort	5	10	2
Background	6	10	3
Spare	5	10	3
Excellent Effort	5	10	2
Controlled Load	4	10	2
Video <100ms Latency	4	8	2
Voice <100ms Latency	2	8	2
Network Control	3	8	2

Apply Cancel

Close Window Copyright (c) 1992-2002 by Cisco Systems, Inc.

# QoS Configuration Examples

These sections describes two common uses for QoS:

- [Prioritizing for Voice Traffic, page 13-10](#)
- [Prioritizing for Video Traffic, page 13-12](#)

## Prioritizing for Voice Traffic

This section demonstrates how you can apply a QoS policy to your wireless network's voice VLAN to give priority to wireless phone traffic.

In this example, the network administrator creates a policy named *voice\_policy* that applies voice class of service to traffic from Spectralink phones (protocol 119 packets). The user applies the *voice\_policy* to the incoming and outgoing radio ports and to the outgoing Ethernet port for VLAN 77. [Figure 13-5](#) shows the administrator's QoS Policies page.

Figure 13-5 QoS Policies Page for Voice Example

The screenshot displays the Cisco 1100 Access Point configuration interface for QoS Policies. The main configuration area is titled 'Services: QoS Policies' and includes the following sections:

- Create/ Edit Policies:** A dropdown menu for 'Create/ Edit Policy' is set to 'voice\_policy'. The 'Policy Name' field contains 'voice\_policy'. The 'Classifications' field contains 'IP Protocol 119 - COS Voice <100ms Latency (6)'. A 'Delete Classification' button is present.
- Match Classifications:**
  - IP Precedence: Routine (0)
  - IP DSCP: Best Effort
  - IP Protocol 119: (empty)
  - Default classification for packets on the VLAN: (empty)
- Apply Class of Service:**
  - Best Effort (0) [Add]
  - Best Effort (0) [Add]
  - Voice <100ms Latency (6) [Add]
  - Best Effort (0) [Add]

At the bottom, the 'Apply Policies to Interface/ VLANs' section contains a table for applying policies to VLANs 77 and 87:

VLAN	FastEthernet	802.11b Radio
VLAN 77	Incoming: < NONE >	Outgoing: voice_policy
	Incoming: voice_policy	Outgoing: voice_policy
VLAN 87	Incoming: < NONE >	Outgoing: < NONE >
	Incoming: < NONE >	Outgoing: < NONE >

Buttons for 'Apply', 'Delete', and 'Cancel' are located at the bottom right of the configuration area.

The network administrator also enables the *QoS element for wireless phones* setting on the QoS Policies - Advanced page. This setting gives priority to all voice traffic regardless of VLAN.

# Prioritizing for Video Traffic

This section demonstrates how you could apply a QoS policy to a VLAN on your network dedicated to video traffic.

In this example, the network administrator creates a policy named *video\_policy* that applies video class of service to video traffic. The user applies the *video\_policy* to the incoming and outgoing radio ports and to the outgoing Ethernet port for VLAN 87. Figure 13-6 shows the administrator's QoS Policies page.

Figure 13-6 QoS Policies Page for Video Example

The screenshot displays the Cisco 1100 Access Point configuration interface for QoS Policies. The main configuration area is titled "Create/ Edit Policies" and shows the following details:

- Hostname:** AP1100
- AP1100 uptime:** 9 hours, 37 minutes
- Services:** QoS Policies
- Create/ Edit Policy:** video\_policy
- Policy Name:** video\_policy
- Classifications:** Precedence Priority - COS Video <100ms Latency (5), DSCP Class Selector 7 - COS Video <100ms Latency (5)
- Match Classifications:**
  - IP Precedence: Routine (0)
  - IP DSCP: Best Effort
  - IP Protocol 119
- Apply Class of Service:**
  - Best Effort (0) (Add)
  - Best Effort (0) (Add)
  - Best Effort (0) (Add)
  - Best Effort (0) (Add)
- Default classification for packets on the VLAN:** Best Effort (0) (Add)

At the bottom, the "Apply Policies to Interface/ VLANs" section shows the policy application for two VLANs:

VLAN	FastEthernet	802.11b Radio
VLAN 77	Incoming: < NONE >	Outgoing: voice_policy
	Outgoing: voice_policy	Incoming: < NONE >
VLAN 87	Incoming: < NONE >	Outgoing: video_policy
	Outgoing: video_policy	Incoming: < NONE >



## Configuring Proxy Mobile IP

---

This chapter describes how to configure your access point's proxy mobile IP feature. This chapter contains these sections:

- [Understanding Proxy Mobile IP, page 14-2](#)
- [Configuring Proxy Mobile IP, page 14-6](#)

# Understanding Proxy Mobile IP

These sections explain how access points conduct proxy mobile IP:

- [Overview, page 14-2](#)
- [Components of a Proxy Mobile IP Network, page 14-2](#)
- [How Proxy Mobile IP Works, page 14-3](#)
- [Proxy Mobile IP Security, page 14-6](#)

## Overview

The access point's proxy mobile IP feature works in conjunction with the Mobile IP feature in IOS. When you enable proxy mobile IP on your access point and on your wired network, the access point helps client devices from other networks remain connected to their home networks. The visiting client devices do not need special software; the access point provides proxy Mobile IP services on their behalf. Any wireless client can participate.

Mobile IP provides users the freedom to roam beyond their home subnets while maintaining their home IP addresses. This enables transparent routing of IP datagrams to mobile users during their movement, so that data sessions can be initiated to them while they roam. For example, a client device with an IP address of 192.95.5.2 could associate to an access point on a network whose IP addresses are in the 209.165.200.x range. The guest client device keeps its 192.95.5.2 IP address, and the access point forwards its packets through a Mobile-IP enabled router across the Internet to a router on the client's home network.

Access points with proxy mobile IP enabled attempt to provide proxy service for any client device that associates and does not perform the following:

- Does not issue a DHCP request to get a new IP address.
- Does not support a Mobile IP stack. If a device supports a Mobile IP stack, the access point assumes that the device will perform its own Mobile IP functions.

You enable proxy mobile IP for specific SSIDs on the access point, providing support only for clients that use those SSIDs. Proxy Mobile IP does not support VLANs. You can pause proxy mobile IP support without losing your proxy mobile IP configuration.

Proxy mobile IP is disabled by default.

**Note**

---

Guest client devices do not receive broadcast and multicast packets.

---

## Components of a Proxy Mobile IP Network

Five devices participate in proxy mobile IP:


- A visiting client device. The visiting client device is any device such as a personal digital assistant or a laptop that can associate to a wireless access point. It does not need any special proxy mobile IP software.
- An access point with proxy mobile IP enabled. The access point proxies on behalf of the visiting client device, performing all mobile IP services for the device.



- An authoritative access point on your network supporting proxy mobile IP. The authoritative access point uses a subnet map to keep track of the home agent information for all visiting client devices.
- A home agent. The home agent is a router on the visiting client's home network that serves as the anchor point for communication with the access point and the visiting client. The home agent tunnels packets from a correspondent node on the Internet to the visiting client device.
- A foreign agent. The foreign agent is a router on your network that serves as the point of attachment for the visiting client device when it is on your network, delivering packets from the home agent to the visiting client.

Figure 14-1 shows the five participating devices.

**Figure 14-1 Participating Devices in Proxy Mobile IP**



## How Proxy Mobile IP Works

The proxy mobile IP process has four main phases. These sections describe each phase:

- [Agent Discovery, page 14-3](#)
- [Subnet Map Exchange, page 14-4](#)
- [Registration, page 14-5](#)
- [Tunneling, page 14-5](#)

### Agent Discovery

During the agent discovery phase, the home agent and the foreign agent advertise their services on the network by using the ICMP Router Discovery Protocol (IRDP). The access point listens to these advertisements.

The IRDP advertisements carry Mobile IP extensions that specify whether an agent is a home agent, foreign agent, or both; its care-of address; the types of services it provides, such as reverse tunneling and generic routing encapsulation (GRE); and the allowed registration lifetime or roaming period for visiting client devices. Rather than waiting for agent advertisements, an access point can send out an agent solicitation. This solicitation forces any agents on the network to immediately send an agent advertisement.

When an access point determines that a client device is connected to a foreign network, it acquires a care-of address for the visiting client. The care-of address is an IP address of a foreign agent that has an interface on the network being visited by a client device. An access point can share this address among many visiting client devices.

When the visiting client associates to an access point, the access point compares the client's IP address with that of its own IP network information and detects that the client is a visitor from another network. The access point then begins the registration. However, before the access point can begin the registration process on behalf of the visiting client, it needs to know the home agent IP address of the visiting client. It gets the home agent's IP address by looking it up on a subnet map table.

## Subnet Map Exchange

Each access point with proxy mobile IP enabled maintains a subnet map table. The subnet map table consists of a list of home agent IP addresses and their subnet masks. [Table 14-1](#) is an example of a subnet map table.

**Table 14-1 Example of a Subnet Map Table**

Home Agent	Subnet Mask
10.10.10.1	255.255.255.0
10.10.4.2	255.255.255.0
10.3.4.4	255.255.255.248
10.12.1.1	255.255.0.0

Access points use the subnet map table to determine the IP address of the visiting client's home agent. When an access point boots up or when proxy mobile IP is first enabled on an access point, it obtains its own home agent information using the agent discovery mechanism. It sends this information to another access point called an authoritative access point (AAP). The AAP is an access point that is responsible for keeping the latest subnet map table.

When the AAP receives the new information, it replies to the access point with a copy of the latest subnet map table. The new access point now has the latest subnet map table locally and it is ready to perform proxy mobile IP for visiting clients. Having the subnet map table locally helps the access point do a quick lookup for the home agent information. Meanwhile, the AAP adds the new access point to its list of access points and the home agent information to its subnet map table. The AAP then updates all the other access points with this additional piece of information.

You can designate up to three AAPs on your wireless LAN. If an access point fails to reach the first AAP, it tries the next configured AAP. The AAPs compare their subnet map tables periodically to make sure they have the same subnet map table. If the AAP detects that there are no more access points for a particular home agent, it sends a deregistration packet on behalf of the broadcast address of the home agent subnet to see if the home agent is still active. If the home agent responds, the AAP keeps the home agent entry in the subnet map table even though there are no access points in the home agent's subnet. This process supports client devices that have already roamed to foreign networks. If the home agent does not respond, the AAP deletes the home agent entry from the subnet map table.

When a client device associates to an access point and the access point determines that the client is visiting from another network, the access point performs a longest-match lookup on its subnet map table and obtains the home agent address for the visiting client. When the access point has the home agent address, it can proceed to the registration step.

## Registration

The access point is configured with the mobility security association (which includes the shared key) of all potential visiting clients with their corresponding home agents. You can enter the mobility security association information locally on the access point or on a RADIUS server on your network, and access points with proxy mobile IP enabled can access it there.

The access point uses the security association information, the visiting client's IP address, and the information that it learns from the foreign agent advertisements to form a Mobile IP registration request on behalf of the visiting client. It sends the registration request to the visiting client's home agent through the foreign agent. The foreign agent checks the validity of the registration request, which includes checking that the requested lifetime does not exceed its limitations and that the requested tunnel encapsulation is available. If the registration request is valid, the foreign agent relays the request to the home agent.

The home agent checks the validity of the registration request, which includes authentication of the visiting client. If the registration request is valid, the home agent creates a mobility binding (an association of the visiting client with its care-of address), a tunnel to the care-of address, and a routing entry for forwarding packets to the home address through the tunnel.

The home agent then sends a registration reply to the visiting client through the foreign agent (because the registration request was received through the foreign agent). The foreign agent checks the validity of the registration reply, including ensuring that an associated registration request exists in its pending list. If the registration reply is valid, the foreign agent adds the visiting client to its visitor list, establishes a tunnel to the home agent, and creates a routing entry for forwarding packets to the home address. It then relays the registration reply to the visiting client.

Finally, the access point checks the validity of the registration reply. If the registration reply specifies that the registration is accepted, the access point is able to confirm that the mobility agents are aware of the visiting client's roaming. Subsequently, the access point intercepts all packets from the visiting client and sends them to the foreign agent.

The access point re-registers on behalf of the visiting client before its registration lifetime expires. The home agent and foreign agent update their mobility binding and visitor entry, respectively, during re-registration.

A successful Mobile IP registration by the access point on behalf of the visiting client sets up the routing mechanism for transporting packets to and from the visiting client as it roams.

## Tunneling

The visiting client sends packets using its home IP address, effectively maintaining the appearance that it is always on its home network. Even while the visiting client is roaming on foreign networks, its movements are transparent to correspondent nodes (other devices with which the visiting client communicates).

Data packets addressed to the visiting client are routed to its home network, where the home agent intercepts and tunnels them to the care-of address toward the visiting client. Tunneling has two primary functions: encapsulation of the data packet to reach the tunnel endpoint, and decapsulation when the packet is delivered at that endpoint. The tunnel mode that the access point supports is IP Encapsulation within IP Encapsulation.

Typically, the visiting client sends packets as it normally would. The access point intercepts these packets and sends them to the foreign agent, which routes them to their final destination, the correspondent node.

## Proxy Mobile IP Security

Mobile IP uses a strong authentication scheme to protect communications to and from visiting clients. All registration messages between a visiting client and the home agent must contain the Mobile-Home Authentication Extension (MHAE). Proxy mobile IP also implements this requirement in the registration messages sent by the access point on behalf of the visiting clients to the home agent.

The integrity of the registration messages is protected by a shared 128-bit key between the access point (on behalf of the visiting client) and the home agent. You can enter the shared key on the access point or on a RADIUS server.

The keyed message digest algorithm 5 (MD5) in prefix+suffix mode is used to compute the authenticator value in the appended MHAE. Mobile IP and proxy mobile IP also support the hash-based message authentication code (HMAC-MD5). The receiver compares the authenticator value it computes over the message with the value in the extension to verify the authenticity.

Optionally, the Mobile-Foreign Authentication Extension and the Foreign-Home Authentication Extension are appended to protect message exchanges between a visiting client and foreign agent and between a foreign agent and home agent, respectively.

Replay protection uses the identification field in the registration messages as a timestamp and sequence number. The home agent returns its time stamp to synchronize the visiting client for registration. In proxy mobile IP, the visiting clients are not synchronized to their home agents because the access point intercepts all home agent messages.

## Configuring Proxy Mobile IP

These sections describe how to configure proxy mobile IP:

- [Configuration Guidelines, page 14-6](#)
- [Configuring Proxy Mobile IP on Your Wired LAN, page 14-7](#)
- [Configuring Proxy Mobile IP on Your Access Point, page 14-7](#)

## Configuration Guidelines

Before configuring proxy mobile IP, you should consider these guidelines:

- You can enable proxy mobile IP only on root access points (units connected to the wired LAN). You cannot enable proxy mobile IP on repeater access points.
- Access points participating in proxy mobile IP should be configured with gateway addresses. You can configure the gateways manually, or the access points can receive gateways through DHCP.
- The foreign and home agents must reside on the network gateways where you want to support proxy mobile IP.
- If your authoritative access points receive their IP addresses through DHCP, use the access point host names to specify the AAPs in the proxy mobile IP configuration.
- Proxy mobile IP does not support broadcast and multicast traffic for visiting clients.

- To use proxy mobile IP with DHCP-enabled client devices, you must disable Media Sense on the client devices. You can find instructions for disabling Media Sense in *Microsoft Knowledge Base Article Q239924*. Click this URL to browse to this article:  
<http://support.microsoft.com/default.aspx?scid=KB;EN-US;Q239924&>
- Proxy mobile IP does not support VLANs.
- If you disable proxy mobile IP on your access point, the entire proxy mobile IP configuration is cleared. To disable proxy mobile IP without clearing the configuration, use the **ip proxy-mobile pause** command.

## Configuring Proxy Mobile IP on Your Wired LAN

Proxy mobile IP on access points works in conjunction with Mobile IP configured on your network routers. For instructions on configuring mobile IP on a router on your network, refer to the Mobile IP chapter in *12.2 T New Features (Early Deployment Releases)*. Click this link to browse to the Mobile IP chapter:

<http://www.cisco.com/univercd/cc/td/doc/product/software/ios120/120newft/120t/120t1/mobileip.htm>

## Configuring Proxy Mobile IP on Your Access Point

Beginning in privileged EXEC mode, follow these steps to configure proxy mobile IP on your access point:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>ip proxy-mobile enable</b>	Enable proxy mobile IP on the access point.
Step 3	<b>ip proxy-mobile aap</b> <i>ip-address</i> [ <i>ip-address</i> ] [ <i>ip-address</i> ]	Designate the access points that serve as the authoritative access points (the access points with which this access point compares its subnet table).  <b>Note</b> You should specify at least two access points as AAPs in case one AAP fails. If you designate only one AAP and it goes offline, you lose all the information in the subnet map table.
Step 4	<b>ip proxy-mobile secure</b> <b>node</b> <i>address-start address-end</i> <b>spi</b> <i>spi</i> <b>key</b> { <b>hex</b>   <b>ascii</b> } <i>key</i>	Create security association settings for an IP address or for a range of IP addresses. <ul style="list-style-type: none"> <li>• Enter an IP address, or the starting and ending addresses in an IP range.</li> <li>• Enter the security parameter index.</li> <li>• Enter a key for the security parameter. Specify whether the key contains hexadecimal or ASCII characters. If you choose hexadecimal, the key must contain 32 characters. If you choose ASCII, the key can contain up to 16 characters with no minimum length.</li> </ul>
Step 5	<b>interface fastethernet 0</b>	Enter interface configuration mode for the Ethernet port.
Step 6	<b>ip proxy-mobile</b>	Enable proxy mobile IP on the Ethernet port.

	Command	Purpose
Step 7	<b>exit</b>	Return to global config mode.
Step 8	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio port.
Step 9	<b>ip proxy-mobile</b>	Enable proxy mobile IP on the radio port.
Step 10	<b>ssid <i>ssid</i></b>	Enter an SSID for which you want to enable proxy mobile IP. <b>Note</b> Proxy Mobile IP functionality is not supported on SSIDs where VLAN is also enabled.
Step 11	<b>ip proxy-mobile</b>	Enable proxy mobile IP for the SSID.
Step 12	<b>exit</b>	Return to global config mode.
Step 13	<b>interface bvi1</b>	Enter interface configuration mode for the bridge virtual interface (BVI).
Step 14	<b>ip proxy-mobile</b>	Enable proxy mobile IP on the BVI.
Step 15	<b>end</b>	Return to privileged EXEC mode.
Step 16	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Use the **no** form of the ip proxy mobile commands to disable proxy mobile IP. Use the **ip proxy-mobile pause** command to disable proxy mobile IP without losing your proxy mobile IP configuration.

This example shows how to enable proxy mobile IP on an access point for the SSID *tsunami* for IP addresses from 10.91.7.151 to 10.91.7.176:

```
ap1100# configure terminal
ap1100(config)# ip proxy-mobile enable
ap1100(config)# ip proxy-mobile aap 192.168.15.22 192.168.15.24 192.168.15.28
ap1100(config)# ip proxy-mobile secure node 10.91.7.151 10.91.7.176 spi 102 key ascii
0987654
ap1100(config)# interface fastethernet 0
ap1100(config-if)# ip proxy-mobile
ap1100(config-if)# interface dot11radio 0
ap1100(config-if)# ip proxy-mobile
ap1100(config-if)# ssid tsunami
ap1100(config-if-ssid)# ip proxy-mobile
ap1100(config-if-ssid)# exit
ap1100(config-if)# exit
ap1100(config)# interface bvi1
ap1100(config-if)# ip proxy-mobile
ap1100(config-if-ssid)# end
```



## Configuring Filters

---

This chapter describes how to configure and manage MAC address, IP, and Ethertype filters on the access point using the web-browser interface. This chapter contains these sections:

- [Understanding Filters, page 15-2](#)
- [Configuring Filters Using the CLI, page 15-2](#)
- [Configuring Filters Using the Web-Browser Interface, page 15-2](#)

## Understanding Filters

Protocol filters (IP protocol, IP port, and EtherType) prevent or allow the use of specific protocols through the access point's Ethernet and radio ports. You can set up individual protocol filters or sets of filters. You can filter protocols for wireless client devices, users on the wired LAN, or both. For example, an SNMP filter on the access point's radio port prevents wireless client devices from using SNMP with the access point but does not block SNMP access from the wired LAN.

IP address and MAC address filters allow or disallow the forwarding of unicast and multicast packets either sent from or addressed to specific IP or MAC addresses. You can create a filter that passes traffic to all addresses except those you specify, or you can create a filter that blocks traffic to all addresses except those you specify.

You can configure filters using the web-browser interface or by entering commands in the CLI.

## Configuring Filters Using the CLI

To configure filters using IOS commands, you use access control lists (ACLs) and bridge groups. You can find explanations of these concepts and instructions for implementing them in these documents:

- *Cisco IOS Bridging and IBM Networking Configuration Guide, Release 12.2*. Click this link to browse to the “Configuring Transparent Bridging” chapter:  
[http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cger/fibm\\_c/bcfpart1/bcftb.htm](http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cger/fibm_c/bcfpart1/bcftb.htm)
- *Catalyst 4908G-L3 Cisco IOS Release 12.0(10)W5(18e) Software Feature and Configuration Guide*. Click this link to browse to the “Command Reference” chapter:  
[http://www.cisco.com/univercd/cc/td/doc/product/13sw/4908g\\_13/ios\\_12/10w518e/config/cmd\\_ref.htm](http://www.cisco.com/univercd/cc/td/doc/product/13sw/4908g_13/ios_12/10w518e/config/cmd_ref.htm)

## Configuring Filters Using the Web-Browser Interface

This section describes how to configure and enable filters using the web-browser interface. You complete two steps to configure and enable a filter:

1. Name and configure the filter using the filter setup pages.
2. Enable the filter using the Apply Filters page.

These sections describe setting up and enabling three filter types:

- [Configuring and Enabling MAC Address Filters, page 15-2](#)
- [Configuring and Enabling IP Filters, page 15-5](#)
- [Configuring and Enabling EtherType Filters, page 15-8](#)

## Configuring and Enabling MAC Address Filters

MAC address filters allow or disallow the forwarding of unicast and multicast packets either sent from or addressed to specific MAC addresses. You can create a filter that passes traffic to all MAC addresses except those you specify, or you can create a filter that blocks traffic to all MAC addresses except those you specify. You can apply the filters you create to either or both the Ethernet and radio ports and to either or both incoming and outgoing packets.



**Note**

MAC address filters are powerful, and you can lock yourself out of the access point if you make a mistake setting up the filters. If you accidentally lock yourself out of your access point, use the CLI to disable the filters.

Use the MAC Address Filters page to create MAC address filters for the access point. [Figure 15-1](#) shows the MAC Address Filters page.

**Figure 15-1** MAC Address Filters Page

Follow this link path to reach the Address Filters page:

1. Click **Services** in the page navigation bar.
2. In the Services page list, click **Filters**.
3. On the Apply Filters page, click the **MAC Address Filters** tab at the top of the page.

## Creating a MAC Address Filter

Follow these steps to create a MAC address filter:

- Step 1** Follow the link path to the MAC Address Filters page.
- Step 2** If you are creating a new MAC address filter, make sure **<NEW>** (the default) is selected in the Create/Edit Filter Index menu. To edit a filter, select the filter number from the Create/Edit Filter Index menu.
- Step 3** In the Filter Index field, name the filter with a number from 700 to 799. The number you assign creates an access control list (ACL) for the filter.
- Step 4** Enter a MAC address in the Add MAC Address field. Enter the address with periods separating the three groups of four characters (0040.9612.3456, for example).

- Step 5** Use the Mask entry field to indicate how many bits, from left to right, the filter checks against the MAC address. For example, to require an exact match with the MAC address (to check all bits) enter **FFFF.FFFF.FFFF**. To check only the first 4 bytes, enter **FFFF.FFFF.0000**.
- Step 6** Select **Forward** or **Block** from the Action menu.
- Step 7** Click **Add**. The MAC address appears in the Filters Classes field. To remove the MAC address from the Filters Classes list, select it and click **Delete Class**.
- Step 8** Repeat [Step 4](#) through [Step 7](#) to add addresses to the filter.
- Step 9** Select **Forward All** or **Block All** from the Default Action menu. The filter's default action must be the opposite of the action for at least one of the addresses in the filter. For example, if you enter several addresses and you select **Block** as the action for all of them, you must choose **Forward All** as the filter's default action.

**Tip**

You can create a list of allowed MAC addresses on an authentication server on your network. Consult the “[Configuring Authentication Types](#)” section on page 10-6 for instructions on using MAC-based authentication.

- Step 10** Click **Apply**. The filter is saved on the access point, but it is not enabled until you apply it on the Apply Filters page.
- Step 11** Click the **Apply Filters** tab to return to the Apply Filters page. [Figure 15-2](#) shows the Apply Filters page.

**Figure 15-2** Apply Filters Page

		Ethernet		802.11b Radio	
Incoming	MAC	< NONE >	< NONE >	MAC	< NONE >
	EtherType	< NONE >	< NONE >	EtherType	< NONE >
	IP	< NONE >	< NONE >	IP	< NONE >
Outgoing	MAC	< NONE >	< NONE >	MAC	< NONE >
	EtherType	< NONE >	< NONE >	EtherType	< NONE >
	IP	< NONE >	< NONE >	IP	< NONE >

- Step 12** Select the filter number from one of the MAC drop-down menus. You can apply the filter to either or both the Ethernet and radio ports, and to either or both incoming and outgoing packets.
- Step 13** Click **Apply**. The filter is enabled on the selected ports.

If clients are not filtered immediately, click **Reload** on the System Configuration page to restart the access point. To reach the System Configuration page, click **System Software** on the task menu and then click **System Configuration**.

**Note**

Client devices with blocked MAC addresses cannot send or receive data through the access point, but they might remain in the Association Table as unauthenticated client devices. Client devices with blocked MAC addresses disappear from the Association Table when the access point stops monitoring them, when the access point reboots, or when the clients associate with another access point.

## Configuring and Enabling IP Filters

IP filters (IP address, IP protocol, and IP port) prevent or allow the use of specific protocols through the access point's Ethernet and radio ports, and IP address filters allow or prevent the forwarding of unicast and multicast packets either sent from or addressed to specific IP addresses. You can create a filter that passes traffic to all addresses except those you specify, or you can create a filter that blocks traffic to all addresses except those you specify. You can create filters that contain elements of one, two, or all three IP filtering methods. You can apply the filters you create to either or both the Ethernet and radio ports and to either or both incoming and outgoing packets.

Use the IP Filters page to create IP filters for the access point. [Figure 15-3](#) shows the IP Filters page.

Figure 15-3 IP Filters Page

APPLY FILTERS | MAC ADDRESS FILTERS | **IP FILTERS** | ETHERTYPE FILTERS

HOME  
EXPRESS SET-UP  
NETWORK MAP  
ASSOCIATION  
NETWORK INTERFACES  
SECURITY  
SERVICES  
Telnet/SSH  
Hot Standby  
CDP  
DNS  
Filters  
HTTP  
Proxy Mobile IP  
QoS  
SNMP  
NTP  
VLAN  
SYSTEM SOFTWARE  
EVENT LOG

Hostname ap ap uptime is 3 days, 17 hours, 3 minutes

Services: Filters - IP Filters

Create/Edit Filter Name: <NEW >

Filter Name:

Default Action: Forward All

**IP Address**

IP Address:  Mask: 255.255.255.255 Action: Forward Add

**IP Protocol**

IP Protocol:  Authentication Header Protocol (51) Action: Forward Add  
 Custom  (0-255)

**UDP/TCP Port**

TCP Port:  Border Gateway Protocol (179) Action: Forward Add  
 Custom  (0-65535)

UDP Port:  Biff (mail notification, comsat 512) Action: Forward Add  
 Custom  (0-65535)

**Filters Classes**

Delete Class

Apply Delete Cancel

Follow this link path to reach the IP Filters page:

1. Click **Services** in the page navigation bar.
2. In the Services page list, click **Filters**.
3. On the Apply Filters page, click the **IP Filters** tab at the top of the page.

## Creating an IP Filter

Follow these steps to create an IP filter:

- Step 1** Follow the link path to the IP Filters page.
- Step 2** If you are creating a new filter, make sure **<NEW>** (the default) is selected in the Create/Edit Filter Index menu. To edit an existing filter, select the filter name from the Create/Edit Filter Index menu.
- Step 3** Enter a descriptive name for the new filter in the Filter Name field.


- Step 4** Select **Forward all** or **Block all** as the filter's default action from the Default Action menu. The filter's default action must be the opposite of the action for at least one of the addresses in the filter. For example, if you create a filter containing an IP address, an IP protocol, and an IP port and you select **Block** as the action for all of them, you must choose **Forward All** as the filter's default action.
- Step 5** To filter an IP address, enter an address in the IP Address field.
-  **Note** If you plan to block traffic to all IP addresses except those you specify as allowed, put the address of your own PC in the list of allowed addresses to avoid losing connectivity to the access point.
- Step 6** Type the subnet mask for the address in the Mask field. Enter the mask with periods separating the three groups of four characters (1122.3344.5566, for example).
- Step 7** Select **Forward** or **Block** from the Action menu.
- Step 8** Click **Add**. The address appears in the Filters Classes field. To remove the address from the Filters Classes list, select it and click **Delete Class**. Repeat [Step 5](#) through [Step 8](#) to add addresses to the filter. If you do not need to add IP protocol or IP port elements to the filter, skip to [Step 15](#) to save the filter on the access point.
- Step 9** To filter an IP protocol, select one of the common protocols from the IP Protocol drop-down menu, or select the **Custom** radio button and enter the number of an existing ACL in the Custom field. Enter an ACL number from 0 to 255. See [Appendix E, "Protocol Filters,"](#) for a list of IP protocols and their numeric designators.
- Step 10** Select **Forward** or **Block** from the Action menu.
- Step 11** Click **Add**. The protocol appears in the Filters Classes field. To remove the protocol from the Filters Classes list, select it and click **Delete Class**. Repeat [Step 9](#) to [Step 11](#) to add protocols to the filter. If you do not need to add IP port elements to the filter, skip to [Step 15](#) to save the filter on the access point.
- Step 12** To filter a TCP or UDP port protocol, select one of the common port protocols from the TCP Port or UDP Port drop-down menus, or select the **Custom** radio button and enter the number of an existing protocol in one of the Custom fields. Enter a protocol number from 0 to 65535. See [Appendix E, "Protocol Filters,"](#) for a list of IP port protocols and their numeric designators.
- Step 13** Select **Forward** or **Block** from the Action menu.
- Step 14** Click **Add**. The protocol appears in the Filters Classes field. To remove the protocol from the Filters Classes list, select it and click **Delete Class**. Repeat [Step 12](#) to [Step 14](#) to add protocols to the filter.
- Step 15** When the filter is complete, click **Apply**. The filter is saved on the access point, but it is not enabled until you apply it on the Apply Filters page.
- Step 16** Click the **Apply Filters** tab to return to the Apply Filters page. [Figure 15-4](#) shows the Apply Filters page.

Figure 15-4 Apply Filters Page

	Ethernet		802.11b Radio	
Incoming	MAC	< NONE >	MAC	< NONE >
	EtherType	< NONE >	EtherType	< NONE >
	IP	< NONE >	IP	< NONE >
Outgoing	MAC	< NONE >	MAC	< NONE >
	EtherType	< NONE >	EtherType	< NONE >
	IP	< NONE >	IP	< NONE >

- Step 17** Select the filter name from one of the IP drop-down menus. You can apply the filter to either or both the Ethernet and radio ports, and to either or both incoming and outgoing packets.
- Step 18** Click **Apply**. The filter is enabled on the selected ports.

## Configuring and Enabling Ethertype Filters

Ethertype filters prevent or allow the use of specific protocols through the access point's Ethernet and radio ports. You can apply the filters you create to either or both the Ethernet and radio ports and to either or both incoming and outgoing packets.

Use the Ethertype Filters page to create Ethertype filters for the access point. [Figure 15-5](#) shows the Ethertype Filters page.

Figure 15-5 EtherType Filters Page

APPLY FILTERS | MAC ADDRESS FILTERS | IP FILTERS | **ETHERTYPE FILTERS**

HOME | EXPRESS SET-UP | NETWORK MAP | ASSOCIATION | NETWORK INTERFACES | SECURITY | **SERVICES** | Telnet/SSH | Hot Standby | CDP | DNS | **Filters** | HTTP | Proxy Mobile IP | QoS | SNMP | NTP | VLAN | SYSTEM SOFTWARE | EVENT LOG

Hostname ap ap uptime is 3 days, 17 hours, 46 minutes

**Services: Filters - EtherType Filters**

Create/Edit Filter Index: <NEW>

Filter Index: (200-299)

Add EtherType: Mask: FFFF Action: Forward Add

(0-FFFF) (0-FFFF)

Default Action: Block All

Filters Classes:

Delete Class

Apply Delete Cancel

Follow this link path to reach the EtherType Filters page:

1. Click **Services** in the page navigation bar.
2. In the Services page list, click **Filters**.
3. On the Apply Filters page, click the **EtherType Filters** tab at the top of the page.

## Creating an EtherType Filter

Follow these steps to create an EtherType filter:

- Step 1** Follow the link path to the EtherType Filters page.
- Step 2** If you are creating a new filter, make sure <NEW> (the default) is selected in the Create/Edit Filter Index menu. To edit an existing filter, select the filter number from the Create/Edit Filter Index menu.
- Step 3** In the Filter Index field, name the filter with a number from 200 to 299. The number you assign creates an access control list (ACL) for the filter.
- Step 4** Enter an EtherType number in the Add EtherType field. See [Appendix E, “Protocol Filters,”](#) for a list of protocols and their numeric designators.
- Step 5** Enter the mask for the EtherType in the Mask field.
- Step 6** Select **Forward** or **Block** from the Action menu.
- Step 7** Click **Add**. The EtherType appears in the Filters Classes field. To remove the EtherType from the Filters Classes list, select it and click **Delete Class**. Repeat [Step 4](#) through [Step 7](#) to add EtherTypes to the filter.

- Step 8** Select **Forward All** or **Block All** from the Default Action menu. The filter's default action must be the opposite of the action for at least one of the Ethertypes in the filter. For example, if you enter several Ethertypes and you select **Block** as the action for all of them, you must choose **Forward All** as the filter's default action.
- Step 9** Click **Apply**. The filter is saved on the access point, but it is not enabled until you apply it on the Apply Filters page.
- Step 10** Click the **Apply Filters** tab to return to the Apply Filters page. [Figure 15-6](#) shows the Apply Filters page.

**Figure 15-6** Apply Filters Page

		Ethernet		802.11b Radio	
Incoming	MAC	< NONE >	MAC	< NONE >	
	EtherType	< NONE >	EtherType	< NONE >	
	IP	< NONE >	IP	< NONE >	
Outgoing	MAC	< NONE >	MAC	< NONE >	
	EtherType	< NONE >	EtherType	< NONE >	
	IP	< NONE >	IP	< NONE >	

- Step 11** Select the filter number from one of the Ethertype drop-down menus. You can apply the filter to either or both the Ethernet and radio ports, and to either or both incoming and outgoing packets.
- Step 12** Click **Apply**. The filter is enabled on the selected ports.





## Configuring CDP

---

This chapter describes how to configure Cisco Discovery Protocol (CDP) on your access point.



**Note**

---

For complete syntax and usage information for the commands used in this chapter, refer to the *Cisco Aironet 1100 Series Access Point Command Reference* for this release and the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.2*.

---

This chapter contains these sections:

- [Understanding CDP, page 16-2](#)
- [Configuring CDP, page 16-2](#)
- [Monitoring and Maintaining CDP, page 16-4](#)

# Understanding CDP

Cisco Discovery Protocol (CDP) is a device-discovery protocol that runs on all Cisco network equipment. Each device sends identifying messages to a multicast address, and each device monitors the messages sent by other devices. Information in CDP packets is used in network management software such as CiscoWorks2000.

CDP is enabled on the access point's Ethernet port by default. However, CDP is enabled on the access point's radio port only when the radio is associated to another wireless infrastructure device, such as an access point or a bridge.

## Configuring CDP

This section contains CDP configuration information and procedures:

- [Default CDP Configuration, page 16-2](#)
- [Configuring the CDP Characteristics, page 16-2](#)
- [Disabling and Enabling CDP, page 16-3](#)
- [Disabling and Enabling CDP on an Interface, page 16-4](#)

## Default CDP Configuration

Table 16-1 lists the default CDP settings.

**Table 16-1 Default CDP Configuration**

Feature	Default Setting
CDP global state	Enabled
CDP interface state	Enabled
CDP holdtime (packet holdtime in seconds)	180
CDP timer (packets sent every x seconds)	60

## Configuring the CDP Characteristics

You can configure the CDP holdtime (the number of seconds before the access point discards CDP packets) and the CDP timer (the number of seconds between each CDP packets the access point sends).

Beginning in Privileged Exec mode, follow these steps to configure the CDP holdtime and CDP timer.

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>cdp holdtime <i>seconds</i></b>	(Optional) Specify the amount of time a receiving device should hold the information sent by your device before discarding it. The range is from 10 to 255 seconds; the default is 180 seconds.

	Command	Purpose
Step 3	<code>cdp timer seconds</code>	(Optional) Set the transmission frequency of CDP updates in seconds. The range is from 5 to 254; the default is 60 seconds.
Step 4	<code>end</code>	Return to Privileged Exec mode.

Use the **no** form of the CDP commands to return to the default settings.

This example shows how to configure and verify CDP characteristics:

```
AP# configure terminal
AP(config)# cdp holdtime 120
AP(config)# cdp timer 50
AP(config)# end

AP# show cdp

Global CDP information:
  Sending a holdtime value of 120 seconds
  Sending CDP packets every 50 seconds
```

For additional CDP **show** commands, see the [“Monitoring and Maintaining CDP”](#) section on page 16-4.

## Disabling and Enabling CDP

CDP is enabled by default. Beginning in Privileged Exec mode, follow these steps to disable the CDP device discovery capability.

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>no cdp run</code>	Disable CDP.
Step 3	<code>end</code>	Return to Privileged Exec mode.

Beginning in privileged EXEC mode, follow these steps to enable CDP when it has been disabled:

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>cdp run</code>	Enable CDP after disabling it.
Step 3	<code>end</code>	Return to privileged EXEC mode.

This example shows how to enable CDP if it has been disabled.

```
AP# configure terminal
AP(config)# cdp run
AP(config)# end
```

## Disabling and Enabling CDP on an Interface

CDP is enabled by default on all supported interfaces to send and receive CDP information.

Beginning in privileged EXEC mode, follow these steps to disable CDP on an interface:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface</b> <i>interface-id</i>	Enter interface configuration mode, and enter the interface on which you are disabling CDP.
Step 3	<b>no cdp enable</b>	Disable CDP on an interface.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Beginning in privileged EXEC mode, follow these steps to enable CDP on an interface when it has been disabled:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface</b> <i>interface-id</i>	Enter interface configuration mode, and enter the interface on which you are enabling CDP.
Step 3	<b>cdp enable</b>	Enable CDP on an interface after disabling it.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

This example shows how to enable CDP on an interface when it has been disabled.

```
AP# configure terminal
AP(config)# interface x
AP(config-if)# cdp enable
AP(config-if)# end
```

## Monitoring and Maintaining CDP

To monitor and maintain CDP on your device, perform one or more of these tasks, beginning in privileged EXEC mode.

Command	Description
<b>clear cdp counters</b>	Reset the traffic counters to zero.
<b>clear cdp table</b>	Delete the CDP table of information about neighbors.
<b>show cdp</b>	Display global information, such as frequency of transmissions and the holdtime for packets being sent.

Command	Description
<b>show cdp entry</b> <i>entry-name</i> [ <b>protocol</b>   <b>version</b> ]	Display information about a specific neighbor.  You can enter an asterisk (*) to display all CDP neighbors, or you can enter the name of the neighbor about which you want information.  You can also limit the display to information about the protocols enabled on the specified neighbor or information about the version of software running on the device.
<b>show cdp interface</b> [ <i>type number</i> ]	Display information about interfaces where CDP is enabled.  You can limit the display to the type of interface or the number of the interface about which you want information (for example, entering <b>gigabitethernet 0/1</b> displays information only about Gigabit Ethernet port 1).
<b>show cdp neighbors</b> [ <i>type number</i> ] [ <b>detail</b> ]	Display information about neighbors, including device type, interface type and number, holdtime settings, capabilities, platform, and port ID.  You can limit the display to neighbors on a specific type or number of interface or expand the display to provide more detailed information.
<b>show cdp traffic</b>	Display CDP counters, including the number of packets sent and received and checksum errors.

Below are six examples of output from the CDP **show** privileged EXEC commands:

```
AP# show cdp
Global CDP information:
  Sending CDP packets every 50 seconds
  Sending a holdtime value of 120 seconds

AP# show cdp entry *
-----
Device ID: AP
Entry address(es):
  IP address: 10.1.1.66
Platform: cisco WS-C3550-12T, Capabilities: Switch IGMP
Interface: GigabitEthernet0/2, Port ID (outgoing port): GigabitEthernet0/2
Holdtime : 129 sec

Version :
Cisco Internetwork Operating System Software
IOS (tm) C3550 Software (C3550-I5Q3L2-M), Experimental Version 12.1(20010612:021
316) [jang-flamingo 120]
Copyright (c) 1986-2001 by cisco Systems, Inc.
Compiled Fri 06-Jul-01 18:18 by jang

advertisement version: 2
Protocol Hello: OUI=0x00000C, Protocol ID=0x0112; payload len=27, value=0000000
0FFFFFFF010221FF000000000000000024B293A00FF0000
VTP Management Domain: ''
Duplex: full

-----
Device ID: idf2-1-lab-13.cisco.com
Entry address(es):
  IP address: 10.1.1.10
Platform: cisco WS-C3524-XL, Capabilities: Trans-Bridge Switch
Interface: GigabitEthernet0/1, Port ID (outgoing port): FastEthernet0/10
Holdtime : 141 sec
```

```

Version :
Cisco Internetwork Operating System Software
IOS (tm) C3500XL Software (C3500XL-C3H2S-M), Version 12.0(5.1)XP, MAINTENANCE IN
TERIM SOFTWARE
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Fri 10-Dec-99 11:16 by cchang

```

```

advertisement version: 2
Protocol Hello: OUI=0x00000C, Protocol ID=0x0112; payload len=25, value=0000000
0FFFFFFF010101FF000000000000000142EFA400FF
VTP Management Domain: ''

```

AP# **show cdp entry \* protocol**

```

Protocol information for talSwitch14 :
  IP address: 172.20.135.194
Protocol information for tstswitch2 :
  IP address: 172.20.135.204
  IP address: 172.20.135.202
Protocol information for tstswitch2 :
  IP address: 172.20.135.204
  IP address: 172.20.135.202

```

AP# **show cdp interface**

```

GigabitEthernet0/1 is up, line protocol is up
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet0/2 is up, line protocol is down
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet0/3 is administratively down, line protocol is down
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet0/4 is up, line protocol is down
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet0/5 is up, line protocol is up
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet0/6 is up, line protocol is up
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet0/7 is up, line protocol is down
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet0/8 is up, line protocol is down
  Encapsulation ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds

```

AP# **show cdp neighbor**

```

Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater

```

Device ID	Local Infrfce	Holdtme	Capability	Platform	Port ID
Perdido2	Gig 0/6	125	R S I	WS-C3550-1Gig	0/6
Perdido2	Gig 0/5	125	R S I	WS-C3550-1Gig	0/5

```
AP# show cdp traffic
CDP counters :
  Total packets output: 50882, Input: 52510
  Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
  No memory: 0, Invalid packet: 0, Fragmented: 0
  CDP version 1 advertisements output: 0, Input: 0
  CDP version 2 advertisements output: 50882, Input: 52510
```







## Configuring SNMP

---

This chapter describes how to configure the Simple Network Management Protocol (SNMP) on your access point.



**Note**

---

For complete syntax and usage information for the commands used in this chapter, refer to the *Cisco Aironet 1100 Series Access Point Command Reference* for this release and to the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.2*.

---

This chapter consists of these sections:

- [Understanding SNMP, page 17-2](#)
- [Configuring SNMP, page 17-4](#)
- [Displaying SNMP Status, page 17-10](#)

# Understanding SNMP

SNMP is an application-layer protocol that provides a message format for communication between SNMP managers and agents. The SNMP manager can be part of a network management system (NMS) such as CiscoWorks. The agent and management information base (MIB) reside on the access point. To configure SNMP on the access point, you define the relationship between the manager and the agent.

The SNMP agent contains MIB variables whose values the SNMP manager can request or change. A manager can get a value from an agent or store a value into the agent. The agent gathers data from the MIB, the repository for information about device parameters and network data. The agent can also respond to a manager's requests to get or set data.

An agent can send unsolicited traps to the manager. Traps are messages alerting the SNMP manager to a condition on the network. Traps can mean improper user authentication, restarts, link status (up or down), MAC address tracking, closing of a TCP connection, loss of connection to a neighbor, or other significant events.

This section includes these concepts:

- [SNMP Versions, page 17-2](#)
- [SNMP Manager Functions, page 17-3](#)
- [SNMP Agent Functions, page 17-3](#)
- [SNMP Community Strings, page 17-3](#)
- [Using SNMP to Access MIB Variables, page 17-4](#)

## SNMP Versions

This software release supports these SNMP versions:

- SNMPv1—The Simple Network Management Protocol, a full Internet standard, defined in RFC 1157.
- SNMPv2C, which has these features:
  - SNMPv2—Version 2 of the Simple Network Management Protocol, a draft Internet standard, defined in RFCs 1902 through 1907.
  - SNMPv2C—The Community-based Administrative Framework for SNMPv2, an experimental Internet protocol defined in RFC 1901.

SNMPv2C replaces the Party-based Administrative and Security Framework of SNMPv2Classic with the Community-based Administrative Framework of SNMPv2C while retaining the bulk retrieval and improved error handling of SNMPv2Classic.

Both SNMPv1 and SNMPv2C use a community-based form of security. The community of managers able to access the agent's MIB is defined by an IP address access control list and password.

SNMPv2C includes a bulk retrieval mechanism and more detailed error message reporting to management stations. The bulk retrieval mechanism retrieves tables and large quantities of information, minimizing the number of round-trips required. The SNMPv2C improved error-handling includes expanded error codes that distinguish different kinds of error conditions; these conditions are reported through a single error code in SNMPv1. Error return codes now report the error type.

You must configure the SNMP agent to use the version of SNMP supported by the management station. An agent can communicate with multiple managers; therefore, you can configure the software to support communications with one management station using the SNMPv1 protocol and another using the SNMPv2 protocol.

## SNMP Manager Functions

The SNMP manager uses information in the MIB to perform the operations described in [Table 17-1](#).

**Table 17-1** *SNMP Operations*

Operation	Description
get-request	Retrieves a value from a specific variable.
get-next-request	Retrieves a value from a variable within a table. <sup>1</sup>
get-bulk-request <sup>2</sup>	Retrieves large blocks of data that would otherwise require the transmission of many small blocks of data, such as multiple rows in a table.
get-response	Replies to a get-request, get-next-request, and set-request sent by an NMS.
set-request	Stores a value in a specific variable.
trap	An unsolicited message sent by an SNMP agent to an SNMP manager when some event has occurred.

1. With this operation, an SNMP manager does not need to know the exact variable name. A sequential search is performed to find the needed variable from within a table.
2. The **get-bulk** command works only with SNMPv2.

## SNMP Agent Functions

The SNMP agent responds to SNMP manager requests as follows:

- **Get a MIB variable**—The SNMP agent begins this function in response to a request from the NMS. The agent retrieves the value of the requested MIB variable and responds to the NMS with that value.
- **Set a MIB variable**—The SNMP agent begins this function in response to a message from the NMS. The SNMP agent changes the value of the MIB variable to the value requested by the NMS.

The SNMP agent also sends unsolicited trap messages to notify an NMS that a significant event has occurred on the agent. Examples of trap conditions include, but are not limited to, when a port or module goes up or down, when spanning-tree topology changes occur, and when authentication failures occur.

## SNMP Community Strings

SNMP community strings authenticate access to MIB objects and function as embedded passwords. In order for the NMS to access the access point, the community string definitions on the NMS must match at least one of the three community string definitions on the access point.

A community string can have one of these attributes:

- **Read-only**—Gives read access to authorized management stations to all objects in the MIB except the community strings, but does not allow write access


- Read-write—Gives read and write access to authorized management stations to all objects in the MIB, but does not allow access to the community strings
- Read-write-all—Gives read and write access to authorized management stations to all objects in the MIB, including the community strings

## Using SNMP to Access MIB Variables

An example of an NMS is the CiscoWorks network management software. CiscoWorks 2000 software uses the access point MIB variables to set device variables and to poll devices on the network for specific information. The results of a poll can be displayed as a graph and analyzed to troubleshoot internetworking problems, increase network performance, verify the configuration of devices, monitor traffic loads, and more.

As shown in [Figure 17-1](#), the SNMP agent gathers data from the MIB. The agent can send traps (notification of certain events) to the SNMP manager, which receives and processes the traps. Traps are messages alerting the SNMP manager to a condition on the network such as improper user authentication, restarts, link status (up or down), MAC address tracking, and so forth. The SNMP agent also responds to MIB-related queries sent by the SNMP manager in *get-request*, *get-next-request*, and *set-request* format.

**Figure 17-1** SNMP Network



For information on supported MIBs and how to access them, see [Appendix F, “Supported MIBs.”](#)

## Configuring SNMP

This section describes how to configure SNMP on your access point. It contains this configuration information:

- [Default SNMP Configuration, page 17-5](#)
- [Disabling the SNMP Agent, page 17-5](#)
- [Configuring Community Strings, page 17-5](#)
- [Configuring Trap Managers and Enabling Traps, page 17-7](#)
- [Setting the Agent Contact and Location Information, page 17-9](#)
- [Using the snmp-server view Command, page 17-9](#)
- [SNMP Examples, page 17-9](#)

## Default SNMP Configuration

Table 17-2 shows the default SNMP configuration.

**Table 17-2 Default SNMP Configuration**

Feature	Default Setting
SNMP agent	Enabled
SNMP community strings	Read-Only: Public Read-Write: Private Read-Write-all: Secret
SNMP trap receiver	None configured
SNMP traps	None enabled

## Disabling the SNMP Agent

Beginning in privileged EXEC mode, follow these steps to disable the SNMP agent:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>no snmp-server</b>	Disable the SNMP agent operation.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

No specific IOS command exists to enable SNMP. The first **snmp-server** global configuration command that you enter enables SNMPv1 and SNMPv2.

## Configuring Community Strings

You use the SNMP community string to define the relationship between the SNMP manager and the agent. The community string acts like a password to permit access to the agent on the access point. Optionally, you can specify one or more of these characteristics associated with the string:

- An access list of IP addresses of the SNMP managers that are permitted to use the community string to gain access to the agent
- A MIB view, which defines the subset of all MIB objects accessible to the given community
- Read and write or read-only permission for the MIB objects accessible to the community

Beginning in privileged EXEC mode, follow these steps to configure a community string on the access point:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>snmp-server community</b> <i>string</i> [ <b>ro</b>   <b>rw</b> ] [ <i>access-list-number</i> ]	Configure the community string. <ul style="list-style-type: none"> <li>For <i>string</i>, specify a string that acts like a password and permits access to the SNMP protocol. You can configure one or more community strings of any length.</li> <li>(Optional) Specify either read-only (<b>ro</b>) if you want authorized management stations to retrieve MIB objects, or specify read/write (<b>rw</b>) if you want authorized management stations to retrieve and modify MIB objects. By default, the community string permits read-only access to all objects.</li> <li>(Optional) For <i>access-list-number</i>, enter an IP standard access list numbered from 1 to 99 and 1300 to 1999.</li> </ul>
Step 3	<b>access-list</b> <i>access-list-number</i> { <b>deny</b>   <b>permit</b> } <i>source</i> [ <i>source-wildcard</i> ]	(Optional) If you specified an IP standard access list number in Step 2, then create the list, repeating the command as many times as necessary. <ul style="list-style-type: none"> <li>For <i>access-list-number</i>, enter the access list number specified in Step 2.</li> <li>The <b>deny</b> keyword denies access if the conditions are matched. The <b>permit</b> keyword permits access if the conditions are matched.</li> <li>For <i>source</i>, enter the IP address of the SNMP managers that are permitted to use the community string to gain access to the agent.</li> <li>(Optional) For <i>source-wildcard</i>, enter the wildcard bits in dotted decimal notation to be applied to the source. Place ones in the bit positions that you want to ignore.</li> </ul> Recall that the access list is always terminated by an implicit deny statement for everything.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your entries.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

**Note**

To disable access for an SNMP community, set the community string for that community to the null string (do not enter a value for the community string).

To remove a specific community string, use the **no snmp-server community** *string* global configuration command.

This example shows how to assign the string *comaccess* to SNMP, to allow read-only access, and to specify that IP access list 4 can use the community string to gain access to the access point SNMP agent:

```
AP(config)# snmp-server community comaccess ro 4
```

## Configuring Trap Managers and Enabling Traps

A trap manager is a management station that receives and processes traps. Traps are system alerts that the access point generates when certain events occur. By default, no trap manager is defined, and no traps are issued.

Access points running this IOS release can have an unlimited number of trap managers. Community strings can be any length.

[Table 17-3](#) describes the supported access point traps (notification types). You can enable any or all of these traps and configure a trap manager to receive them.

**Table 17-3 Notification Types**

Notification Type	Description
<b>authenticate-fail</b>	Enable traps for authentication failures.
<b>config</b>	Enable traps for SNMP configuration changes.
<b>deauthenticate</b>	Enable traps for client device deauthentications.
<b>disassociate</b>	Enable traps for client device disassociations.
<b>dot11-qos</b>	Enable traps for QoS changes.
<b>entity</b>	Enable traps for SNMP entity changes.
<b>rogue-ap</b>	Enable traps for rogue access point detections.
<b>snmp</b>	Enable traps for SNMP events.
<b>switch-over</b>	Enable traps for switch-overs.
<b>syslog</b>	Enable syslog traps.
<b>wlan-wep</b>	Enable WEP traps.

Some notification types cannot be controlled with the **snmp-server enable** global configuration command, such as **tty** and **udp-port**. These notification types are always enabled. You can use the **snmp-server host** global configuration command to a specific host to receive the notification types listed in [Table 17-3](#).

Beginning in privileged EXEC mode, follow these steps to configure the access point to send traps to a host:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>snmp-server host</b> <i>host-addr</i> { <b>traps</b>   <b>informs</b> } { <b>version</b> { <b>1</b>   <b>2c</b> }} <i>community-string notification-type</i>	<p>Specify the recipient of the trap message.</p> <ul style="list-style-type: none"> <li>For <i>host-addr</i>, specify the name or address of the host (the targeted recipient).</li> <li>Specify <b>traps</b> (the default) to send SNMP traps to the host. Specify <b>informs</b> to send SNMP informs to the host.</li> <li>Specify the SNMP version to support. Version 1, the default, is not available with informs.</li> </ul> <p><b>Note</b> Though visible in the command-line help string, the <b>version 3</b> keyword (SNMPv3) is not supported.</p> <ul style="list-style-type: none"> <li>For <i>community-string</i>, specify the string to send with the notification operation. Though you can set this string using the <b>snmp-server host</b> command, we recommend that you define this string by using the <b>snmp-server community</b> command before using the <b>snmp-server host</b> command.</li> <li>For <i>notification-type</i>, use the keywords listed in <a href="#">Table 17-3 on page 17-7</a>.</li> </ul>
Step 3	<b>snmp-server enable traps</b> <i>notification-types</i>	<p>Enable the access point to send specific traps. For a list of traps, see <a href="#">Table 17-3 on page 17-7</a>.</p> <p>To enable multiple types of traps, you must issue a separate <b>snmp-server enable traps</b> command for each trap type.</p>
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>show running-config</b>	Verify your entries.
Step 6	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To remove the specified host from receiving traps, use the **no snmp-server host** *host* global configuration command. To disable a specific trap type, use the **no snmp-server enable traps** *notification-types* global configuration command.



## Setting the Agent Contact and Location Information

Beginning in privileged EXEC mode, follow these steps to set the system contact and location of the SNMP agent so that these descriptions can be accessed through the configuration file:

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>snmp-server contact text</code>	Set the system contact string. For example: <code>snmp-server contact Dial System Operator at beeper 21555.</code>
Step 3	<code>snmp-server location text</code>	Set the system location string. For example: <code>snmp-server location Building 3/Room 222</code>
Step 4	<code>end</code>	Return to privileged EXEC mode.
Step 5	<code>show running-config</code>	Verify your entries.
Step 6	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

## Using the snmp-server view Command

In global configuration mode, use the `snmp-server view` command to access Standard IEEE 802.11 MIB objects through IEEE view and the dot11 read-write community string.

This example shows how to enable IEEE view and dot11 read-write community string:

```
AP(config)# snmp-server view ieee ieee802dot11 included
AP(config)# snmp-server community dot11 view ieee RW
```

## SNMP Examples

This example shows how to enable SNMPv1 and SNMPv2C. The configuration permits any SNMP manager to access all objects with read-only permissions using the community string `public`. This configuration does not cause the access point to send any traps.

```
AP(config)# snmp-server community public
```

This example shows how to permit any SNMP manager to access all objects with read-only permission using the community string `public`. The access point also sends config traps to the hosts 192.180.1.111 and 192.180.1.33 using SNMPv1 and to the host 192.180.1.27 using SNMPv2C. The community string `public` is sent with the traps.

```
AP(config)# snmp-server community public
AP(config)# snmp-server enable traps config
AP(config)# snmp-server host 192.180.1.27 version 2c public
AP(config)# snmp-server host 192.180.1.111 version 1 public
AP(config)# snmp-server host 192.180.1.33 public
```

This example shows how to allow read-only access for all objects to members of access list 4 that use the *comaccess* community string. No other SNMP managers have access to any objects. SNMP Authentication Failure traps are sent by SNMPv2C to the host *cisco.com* using the community string *public*.

```
AP(config)# snmp-server community comaccess ro 4
AP(config)# snmp-server enable traps snmp authentication
AP(config)# snmp-server host cisco.com version 2c public
```

This example shows how to send Entity MIB traps to the host *cisco.com*. The community string is restricted. The first line enables the access point to send Entity MIB traps in addition to any traps previously enabled. The second line specifies the destination of these traps and overwrites any previous **snmp-server host** commands for the host *cisco.com*.

```
AP(config)# snmp-server enable traps entity
AP(config)# snmp-server host cisco.com restricted entity
```

This example shows how to enable the access point to send all traps to the host *myhost.cisco.com* using the community string *public*:

```
AP(config)# snmp-server enable traps
AP(config)# snmp-server host myhost.cisco.com public
```

## Displaying SNMP Status

To display SNMP input and output statistics, including the number of illegal community string entries, errors, and requested variables, use the **show snmp** privileged EXEC command. For information about the fields in this display, refer to the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.2*.



## Configuring Repeater and Standby Access Points

---

This chapter describes how to configure your access point as a hot standby unit or as a repeater unit. This chapter contains these sections:

- [Understanding Repeater Access Points, page 18-2](#)
- [Configuring a Repeater Access Point, page 18-3](#)
- [Understanding Hot Standby, page 18-7](#)
- [Configuring a Hot Standby Access Point, page 18-7](#)

# Understanding Repeater Access Points

A repeater access point is not connected to the wired LAN; it is placed within radio range of an access point connected to the wired LAN to extend the range of your infrastructure or to overcome an obstacle that blocks radio communication.


The repeater forwards traffic between wireless users and the wired LAN by sending packets to either another repeater or to an access point connected to the wired LAN. The data is sent through the route that provides the best performance for the client. When you configure an access point as a repeater, the access point's Ethernet port does not forward traffic.

You can set up a chain of several repeater access points, but throughput for client devices at the end of the repeater chain will be quite low. Because each repeater must receive and then re-transmit each packet on the same channel, throughput is cut in half for each repeater you add to the chain.

A repeater access point associates to the access point with which it has the best connectivity. However, you can specify the access point to which the repeater associates. Setting up a static, specific association between a repeater and a root access point improves repeater performance.

To set up repeaters, you must enable Aironet extensions on both the parent (root) access point and the repeater access points. Aironet extensions, which are enabled by default, improve the access point's ability to understand the capabilities of Cisco Aironet client devices associated with the access point. Disabling Aironet extensions sometimes improves the interoperability between the access point and non-Cisco client devices. Non-Cisco client devices might have difficulty communicating with repeater access points and the root access point to which repeaters are associated.

Figure 18-1 shows an access point acting as a repeater.

**Figure 18-1 Access Point as a Repeater**

## Configuring a Repeater Access Point

This section provides instructions for setting up an access point as a repeater and includes these sections:

- [Default Configuration, page 18-4](#)
- [Guidelines for Repeaters, page 18-4](#)
- [Setting Up a Repeater, page 18-4](#)
- [Verifying Repeater Operation, page 18-5](#)
- [Setting Up a Repeater as a LEAP Client, page 18-6](#)

## Default Configuration

Access points are configured as root units by default. Table 18-1 shows the default values for settings that control the access point's role in the wireless LAN.

**Table 18-1 Default Settings for Role in Wireless LAN**

Feature	Default Setting
Station role	Root
Parent	none
Extensions	Aironet

## Guidelines for Repeaters

Follow these guidelines when configuring repeater access points:

- Use repeaters to serve client devices that do not require high throughput. Repeaters extend the coverage area of your wireless LAN, but they drastically reduce throughput.
- Use repeaters when most if not all client devices that associate with the repeaters are Cisco Aironet clients. Non-Cisco client devices sometimes have trouble communicating with repeater access points.

## Setting Up a Repeater

Beginning in Privileged Exec mode, follow these steps to configure an access point as a repeater:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>ssid <i>ssid-string</i></b>	Create the SSID that the repeater uses to associate to a root access point; in the next step designate this SSID as an infrastructure SSID. If you created an infrastructure SSID on the root access point, create the same SSID on the repeater, also.
Step 4	<b>infrastructure-ssid [optional]</b>	Designate the SSID as an infrastructure SSID. The repeater uses this SSID to associate to the root access point. Infrastructure devices must associate to the repeater access point using this SSID unless you also enter the <b>optional</b> keyword.
Step 5	<b>exit</b>	Exit SSID configuration mode and return to radio interface configuration mode.
Step 6	<b>station-role repeater</b>	Set the access point's role in the wireless LAN to repeater.
Step 7	<b>dot11 extensions aironet</b>	If Aironet extensions are disabled, enable Aironet extensions.

	Command	Purpose
Step 8	<b>parent</b> {1-4} <i>mac-address</i> [ <i>timeout</i> ]	(Optional) Enter the MAC address for the access point to which the repeater should associate. <ul style="list-style-type: none"> <li>You can enter MAC addresses for up to four parent access points. The repeater attempts to associate to MAC address 1 first; if that access point does not respond, the repeater tries the next access point in its parent list.</li> <li>(Optional) You can also enter a timeout value in seconds that determines how long the repeater attempts to associate to a parent access point before trying the next parent in the list. Enter a timeout value from 0 to 65535 seconds.</li> </ul>
Step 9	<b>end</b>	Return to privileged EXEC mode.
Step 10	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

This example shows how to set up a repeater access point with three potential parents:

```
AP# configure terminal
AP(config)# interface dot11radio 0
AP(config-if)# ssid chicago
AP(config-ssid)# infrastructure-ssid
AP(config-ssid)# exit
AP(config-if)# station-role repeater
AP(config-if)# dot11 extensions aironet
AP(config-if)# parent 1 0987.1234.h345 900
AP(config-if)# parent 2 7809.b123.c345 900
AP(config-if)# parent 3 6543.a456.7421 900
AP(config-if)# end
```

## Verifying Repeater Operation

After you set up the repeater, check the LEDs on top of the repeater access point. If your repeater is functioning correctly, the LEDs on the repeater and the root access point to which it is associated behave like this:

- The status LED on the root access point is steady green, indicating that at least one client device is associated with it (in this case, the repeater).
- The status LED on the repeater access point is steady green when it is associated with the root access point and the repeater has client devices associated to it. The repeater's status LED flashes (steady green for 7/8 of a second and off for 1/8 of a second) when it is associated with the root access point but the repeater has no client devices associated to it.

The repeater access point should also appear as associated with the root access point in the root access point's Association Table.

## Setting Up a Repeater as a LEAP Client

You can set up a repeater access point to authenticate to your network like other wireless client devices. After you provide a network username and password for the repeater access point, it authenticates to your network using LEAP, Cisco's wireless authentication method, and receives and uses dynamic WEP keys.

Setting up a repeater as a LEAP client requires three major steps:

1. Create an authentication username and password for the repeater on your authentication server.
2. Configure LEAP authentication on the root access point to which the repeater associates. See [Chapter 10, “Configuring Authentication Types,”](#) for instructions on setting up authentication on the access point.
3. Configure the repeater to act as a LEAP client. Beginning in Privileged Exec mode, follow these instructions to set up the repeater as a LEAP client:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
Step 3	<b>ssid <i>ssid-string</i></b>	Create an SSID and enter SSID configuration mode for the new SSID. The SSID can consist of up to 32 alphanumeric characters. SSIDs are case-sensitive.
Step 4	<b>authentication network-eap <i>list-name</i></b>	Enable LEAP authentication on the repeater so that LEAP-enabled client devices can authenticate through the repeater. For <i>list-name</i> , specify the name or IP address of the authentication server.
Step 5	<b>authentication client username <i>username</i> password <i>password</i></b>	Configure the username and password that the repeater uses when it performs LEAP authentication. This username and password must match the username and password that you set up for the repeater on the authentication server.
Step 6	<b>infrastructure ssid [optional]</b>	(Optional) Designate the SSID as the SSID that other access points and workgroup bridges use to associate to this access point. If you do not designate an SSID as the infrastructure SSID, infrastructure devices can associate to the access point using any SSID. If you designate an SSID as the infrastructure SSID, infrastructure devices must associate to the access point using that SSID unless you also enter the <b>optional</b> keyword.
Step 7	<b>end</b>	Return to privileged EXEC mode.
Step 8	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.



## Understanding Hot Standby

Hot Standby mode designates an access point as a backup for another access point. The standby access point is placed near the access point it monitors, configured exactly the same as the monitored access point. The standby access point associates with the monitored access point as a client and queries the monitored access point regularly through both the Ethernet and the radio ports. If the monitored access point fails to respond, the standby access point comes online and takes the monitored access point's place in the network.

Except for the IP address, the standby access point's settings should be identical to the settings on the monitored access point. If the monitored access point goes offline and the standby access point takes its place in the network, matching settings ensures that client devices can switch easily to the standby access point.

Hot standby mode is disabled by default.



### Note

If the monitored access point malfunctions and the standby access point takes its place, repeat the hot standby setup on the standby access point when you repair or replace the monitored access point. The standby access point does not revert to standby mode automatically.

## Configuring a Hot Standby Access Point

When you set up the standby access point, you must enter the MAC address of the access point that the standby unit will monitor. Record the MAC address of the monitored access point before you configure the standby access point.

The standby access point also must duplicate several key settings on the monitored access point. These settings are:

- Primary SSID (as well as additional SSIDs configured on the monitored access point)
- Default IP Subnet Mask
- Default Gateway
- Data rates
- WEP settings
- Authentication Types

Check the monitored access point and record these settings before you set up the standby access point.



### Note

Wireless client devices associated to the standby access point lose their connections during the hot standby setup process.

Beginning in Privileged Exec mode, follow these steps to enable hot standby mode on an access point:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>iapp standby <i>mac-address</i></b>	Puts the access point into standby mode and specifies the MAC address of the monitored access point.

	<b>Command</b>	<b>Purpose</b>
<b>Step 3</b>	<b>interface dot11radio 0</b>	Enter interface configuration mode for the radio interface.
<b>Step 4</b>	<b>ssid <i>ssid-string</i></b>	Create the SSID that the standby access point uses to associate to the monitored access point; in the next step designate this SSID as an infrastructure SSID. If you created an infrastructure SSID on the monitored access point, create the same SSID on the repeater, also.
<b>Step 5</b>	<b>infrastructure-ssid [optional]</b>	Designate the SSID as an infrastructure SSID. The standby uses this SSID to associate to the monitored access point. If the standby access point takes the place of the monitored access point, infrastructure devices must associate to the standby access point using this SSID unless you also enter the <b>optional</b> keyword.
<b>Step 6</b>	<b>exit</b>	Exit SSID configuration mode and return to radio interface configuration mode.
<b>Step 7</b>	<b>iapp standby poll-frequency <i>seconds</i></b>	Sets the number of seconds between queries that the standby access point sends to the monitored access point's radio and Ethernet ports.
<b>Step 8</b>	<b>iapp standby timeout <i>seconds</i></b>	Sets the number of seconds the standby access point waits for a response from the monitored access point before it assumes that the monitored access point has malfunctioned.
<b>Step 9</b>	<b>show iapp standby-parms</b>	Verify your entries. If the access point is in standby mode, this command displays the standby parameters, including the MAC address of the monitored access point and the poll-frequency and timeout values. If the access point is not in standby mode, <i>no iapp standby mac-address</i> appears.
<b>Step 10</b>	<b>end</b>	Return to privileged EXEC mode.
<b>Step 11</b>	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

After you enable standby mode, configure the settings that you recorded from the monitored access point to match on the standby access point.

Use this command to check the standby configuration:

**show iapp standby-parms**

This command displays the MAC address of the standby access point, the standby timeout, and the poll-frequency values. If no standby access point is configured, this message appears:

```
no iapp standby mac-address
```



## Managing Firmware and Configurations

---

This chapter describes how to manipulate the Flash file system, how to copy configuration files, and how to archive (upload and download) software images.



**Note**

---

For complete syntax and usage information for the commands used in this chapter, refer to the *Cisco Aironet 1100 Series Access Point Command Reference* for this release and the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.2*.

---

This chapter consists of these sections:

- [Working with the Flash File System, page 19-2](#)
- [Working with Configuration Files, page 19-8](#)
- [Working with Software Images, page 19-18](#)

# Working with the Flash File System

The Flash file system on your access point provides several commands to help you manage software image and configuration files.

The Flash file system is a single Flash device on which you can store files. This Flash device is called *flash:*.

This section contains this information:

- [Displaying Available File Systems, page 19-2](#)
- [Setting the Default File System, page 19-3](#)
- [Displaying Information about Files on a File System, page 19-3](#)
- [Changing Directories and Displaying the Working Directory, page 19-4](#)
- [Creating and Removing Directories, page 19-4](#)
- [Copying Files, page 19-5](#)
- [Deleting Files, page 19-5](#)
- [Creating, Displaying, and Extracting tar Files, page 19-6](#)
- [Displaying the Contents of a File, page 19-8](#)

## Displaying Available File Systems

To display the available file systems on your access point, use the **show file systems** privileged EXEC command as shown in this example:

```
ap# show file systems
File Systems:

      Size(b)   Free(b)   Type  Flags  Prefixes
*  16128000    11118592  flash  rw     flash:
  16128000    11118592  unknown  rw     zflash:
      32768      26363    nvram   rw     nvram:
      -         -        network  rw     tftp:
      -         -        opaque   rw     null:
      -         -        opaque   rw     system:
      -         -        opaque   ro     xmodem:
      -         -        opaque   ro     ymodem:
      -         -        network  rw     rcp:
      -         -        network  rw     ftp:
```

[Table 19-1](#) lists field descriptions for the **show file systems** command.

**Table 19-1** *show file systems* Field Descriptions

Field	Value
Size(b)	Amount of memory in the file system in bytes.
Free(b)	Amount of free memory in the file system in bytes.

Table 19-1 show file systems Field Descriptions (continued)

Field	Value
Type	Type of file system. <b>flash</b> —The file system is for a Flash memory device. <b>network</b> —The file system is for a network device. <b>nvr</b> <b>am</b> —The file system is for a nonvolatile RAM (NVRAM) device. <b>opaque</b> —The file system is a locally generated <i>pseudo</i> file system (for example, the <i>system</i> ) or a download interface, such as brimux. <b>unknown</b> —The file system is an unknown type.
Flags	Permission for file system. <b>ro</b> —read-only. <b>rw</b> —read/write. <b>wo</b> —write-only.
Prefixes	Alias for file system. <b>flash:</b> —Flash file system. <b>ftp:</b> —File Transfer Protocol network server. Used to transfer files to or from the network device. <b>nvr</b> <b>am:</b> —Non-volatile RAM memory (NVRAM). <b>null:</b> —Null destination for copies. You can copy a remote file to null to determine its size. <b>rcp:</b> —Remote Copy Protocol (RCP) network server. <b>system:</b> —Contains the system memory, including the running configuration. <b>tftp:</b> —Trivial File Transfer Protocol (TFTP) network server. <b>zflash:</b> —Read-only file decompression file system, which mirrors the contents of the Flash file system.

## Setting the Default File System

You can specify the file system or directory that the system uses as the default file system by using the **cd** *filesystem:* privileged EXEC command. You can set the default file system to omit the *filesystem:* argument from related commands. For example, for all privileged EXEC commands that have the optional *filesystem:* argument, the system uses the file system specified by the **cd** command.

By default, the default file system is *flash:*.

You can display the current default file system as specified by the **cd** command by using the **pwd** privileged EXEC command.

## Displaying Information about Files on a File System

You can view a list of the contents of a file system before manipulating its contents. For example, before copying a new configuration file to Flash memory, you might want to verify that the file system does not already contain a configuration file with the same name. Similarly, before copying a Flash configuration file to another location, you might want to verify its filename for use in another command.

To display information about files on a file system, use one of the privileged EXEC commands in Table 19-2:

**Table 19-2 Commands for Displaying Information About Files**

Command	Description
<code>dir [/all] [filesystem:][filename]</code>	Display a list of files on a file system.
<code>show file systems</code>	Display more information about each of the files on a file system.
<code>show file information file-url</code>	Display information about a specific file.
<code>show file descriptors</code>	Display a list of open file descriptors. File descriptors are the internal representations of open files. You can use this command to see if another user has a file open.

## Changing Directories and Displaying the Working Directory

Beginning in privileged EXEC mode, follow these steps to change directories and display the working directory.

	Command	Purpose
Step 1	<code>dir filesystem:</code>	Display the directories on the specified file system. For <i>filesystem:</i> , use <b>flash:</b> for the system board Flash device.
Step 2	<code>cd new_configs</code>	Change to the directory of interest. The command example shows how to change to the directory named <i>new_configs</i> .
Step 3	<code>pwd</code>	Display the working directory.

## Creating and Removing Directories

Beginning in privileged EXEC mode, follow these steps to create and remove a directory:

	Command	Purpose
Step 1	<code>dir filesystem:</code>	Display the directories on the specified file system. For <i>filesystem:</i> , use <b>flash:</b> for the system board Flash device.
Step 2	<code>mkdir old_configs</code>	Create a new directory. The command example shows how to create the directory named <i>old_configs</i> . Directory names are case sensitive. Directory names are limited to 45 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.
Step 3	<code>dir filesystem:</code>	Verify your entry.

To delete a directory with all its files and subdirectories, use the **delete /force /recursive filesystem:/file-url** privileged EXEC command.

Use the **/recursive** keyword to delete the named directory and all subdirectories and the files contained in it. Use the **/force** keyword to suppress the prompting that confirms a deletion of each file in the directory. You are prompted only once at the beginning of this deletion process. Use the **/force** and **/recursive** keywords for deleting old software images that were installed by using the **archive download-sw** command but are no longer needed.

For *filesystem*, use **flash:** for the system board Flash device. For *file-url*, enter the name of the directory to be deleted. All the files in the directory and the directory are removed.

**Caution**


---

When files and directories are deleted, their contents cannot be recovered.

---

## Copying Files

To copy a file from a source to a destination, use the **copy [/erase] source-url destination-url** privileged EXEC command. For the source and destination URLs, you can use **running-config** and **startup-config** keyword shortcuts. For example, the **copy running-config startup-config** command saves the currently running configuration file to the NVRAM section of Flash memory to be used as the configuration during system initialization.

Network file system URLs include **ftp:**, **rcp:**, and **tftp:** and have the following syntax:

- File Transfer Protocol (FTP)—**ftp:**[[//username [:password]@location]/directory]/filename
- Remote Copy Protocol (RCP)—**rcp:**[[//username@location]/directory]/filename
- Trivial File Transfer Protocol (TFTP)—**tftp:**[[//location]/directory]/filename

Local writable file systems include flash:

Some invalid combinations of source and destination exist. Specifically, you cannot copy these combinations:

- From a running configuration to a running configuration
- From a startup configuration to a startup configuration
- From a device to the same device (for example, the **copy flash: flash:** command is invalid)

For specific examples of using the **copy** command with configuration files, see the [“Working with Configuration Files” section on page 19-8](#).

To copy software images either by downloading a new version or uploading the existing one, use the **archive download-sw** or the **archive upload-sw** privileged EXEC command. For more information, see the [“Working with Software Images” section on page 19-18](#).

## Deleting Files

When you no longer need a file on a Flash memory device, you can permanently delete it. To delete a file or directory from a specified Flash device, use the **delete [/force] [/recursive] [filesystem:] /file-url** privileged EXEC command.

**Caution**


---

When files are deleted, their contents cannot be recovered.

---

Use the **/recursive** keyword for deleting a directory and all subdirectories and the files contained in it. Use the **/force** keyword to suppress the prompting that confirms a deletion of each file in the directory. You are prompted only once at the beginning of this deletion process. Use the **/force** and **/recursive** keywords for deleting old software images that were installed by using the **archive download-sw** command but are no longer needed.

If you omit the *filesystem:* option, the access point uses the default device specified by the **cd** command. For *file-url*, you specify the path (directory) and the name of the file to be deleted.

This example shows how to delete the file *myconfig* from the default Flash memory device:

```
ap# delete myconfig
```

## Creating, Displaying, and Extracting tar Files

You can create a tar file and write files into it, list the files in a tar file, and extract the files from a tar file as described in the next sections.

### Creating a tar File

To create a tar file and write files into it, use this privileged EXEC command:

```
archive tar /create destination-url flash:/file-url
```

For *destination-url*, specify the destination URL alias for the local or network file system and the name of the tar file to create. These options are supported:

- For the local Flash file system, the syntax is **flash:/file-url**
- For the File Transfer Protocol (FTP), the syntax is **ftp:[[/username[:password]@location]/directory]/tar-filename.tar**
- For the Remote Copy Protocol (RCP), the syntax is **rcp:[[/username@location]/directory]/tar-filename.tar**
- For the Trivial File Transfer Protocol (TFTP), the syntax is **tftp:[[/location]/directory]/tar-filename.tar**

The *tar-filename.tar* is the tar file to be created.

For **flash:/file-url**, specify the location on the local Flash file system from which the new tar file is created. You can also specify an optional list of files or directories within the source directory to write to the new tar file. If none are specified, all files and directories at this level are written to the newly created tar file.

This example shows how to create a tar file. This command writes the contents of the *new-configs* directory on the local Flash device to a file named *saved.tar* on the TFTP server at 172.20.10.30:

```
ap# archive tar /create tftp:172.20.10.30/saved.tar flash:/new-configs
```

### Displaying the Contents of a tar File

To display the contents of a tar file on the screen, use this privileged EXEC command:

```
archive tar /table source-url
```



For *source-url*, specify the source URL alias for the local or network file system. These options are supported:

- For the local Flash file system, the syntax is  
**flash:**
- For the File Transfer Protocol (FTP), the syntax is  
**ftp:[[/username[:password]@location]/directory]/tar-filename.tar**
- For the Remote Copy Protocol (RCP), the syntax is  
**rcp:[[/username@location]/directory]/tar-filename.tar**
- For the Trivial File Transfer Protocol (TFTP), the syntax is  
**tftp:[[/location]/directory]/tar-filename.tar**

The *tar-filename.tar* is the tar file to display.

You can also limit the display of the files by specifying an optional list of files or directories after the tar file; then only these files are displayed. If none are specified, all files and directories are displayed.

This example shows how to display the contents of the *c3550-i5q3l2-mz.121-6.EA1.tar* file that is in Flash memory:

```
ap# archive tar /table flash:c3550-i5q3l2-mz.121-6.EA1.tar
info (219 bytes)
c3550-i5q3l2-mz.121-6.EA1/ (directory)
c3550-i5q3l2-mz.121-6.EA1/html/ (directory)
c3550-i5q3l2-mz.121-6.EA1/html/foo.html (0 bytes)
c3550-i5q3l2-mz.121-6.EA1/c3550-i5q3l2-mz.121-6.EA1.bin (610856 bytes)
c3550-i5q3l2-mz.121-6.EA1/info (219 bytes)
info.ver (219 bytes)
```

This example shows how to display only the *c3550-i5q3l2-mz.121-6.EA1/html* directory and its contents:

```
ap# archive tar /table flash:c3550-tv0-m.tar c3550-i5q3l2-mz.121-6.EA1/html
c3550-i5q3l2-mz.121-6.EA1/html/ (directory)
c3550-i5q3l2-mz.121-6.EA1/html/foo.html (0 bytes)
```

## Extracting a tar File

To extract a tar file into a directory on the Flash file system, use this privileged EXEC command:

```
archive tar /xtract source-url flash:/file-url
```

For *source-url*, specify the source URL alias for the local or network file system. These options are supported:

- For the local Flash file system, the syntax is  
**flash:**
- For the File Transfer Protocol (FTP), the syntax is  
**ftp:[[/username[:password]@location]/directory]/tar-filename.tar**
- For the Remote Copy Protocol (RCP), the syntax is  
**rcp:[[/username@location]/directory]/tar-filename.tar**
- For the Trivial File Transfer Protocol (TFTP), the syntax is  
**tftp:[[/location]/directory]/tar-filename.tar**

The *tar-filename.tar* is the tar file from which to extract files.

For **flash:/file-url**, specify the location on the local Flash file system into which the tar file is extracted. You can also specify an optional list of files or directories within the tar file for extraction. If none are specified, all files and directories are extracted.

This example shows how to extract the contents of a tar file located on the TFTP server at 172.20.10.30. This command extracts just the *new-configs* directory into the root directory on the local Flash file system. The remaining files in the *saved.tar* file are ignored.

```
ap# archive tar /xtract tftp://172.20.10.30/saved.tar flash:/new-configs
```

## Displaying the Contents of a File

To display the contents of any readable file, including a file on a remote file system, use the **more** [/ascii | /binary | /ebcdic] *file-url* privileged EXEC command:

This example shows how to display the contents of a configuration file on a TFTP server:

```
ap# more tftp://serverA/hampton/savedconfig
!
! Saved configuration on server
!
version 11.3
service timestamps log datetime localtime
service linenumbers
service udp-small-servers
service pt-vty-logging
!
<output truncated>
```

## Working with Configuration Files

This section describes how to create, load, and maintain configuration files. Configuration files contain commands entered to customize the function of the Cisco IOS software. To better benefit from these instructions, your access point contains a minimal default running configuration for interacting with the system software.

You can copy (*download*) configuration files from a TFTP, FTP, or RCP server to the running configuration of the access point for various reasons:

- To restore a backed-up configuration file.
- To use the configuration file for another access point. For example, you might add another access point to your network and want it to have a configuration similar to the original access point. By copying the file to the new access point, you can change the relevant parts rather than recreating the whole file.
- To load the same configuration commands on all the access points in your network so that all the access points have similar configurations.

You can copy (*upload*) configuration files from the access point to a file server by using TFTP, FTP, or RCP. You might perform this task to back up a current configuration file to a server before changing its contents so that you can later restore the original configuration file from the server.

The protocol you use depends on which type of server you are using. The FTP and RCP transport mechanisms provide faster performance and more reliable delivery of data than TFTP. These improvements are possible because FTP and RCP are built on and use the Transmission Control Protocol/Internet Protocol (TCP/IP) stack, which is connection-oriented.

This section includes this information:

- [Guidelines for Creating and Using Configuration Files, page 19-9](#)

- [Configuration File Types and Location, page 19-9](#)
- [Creating a Configuration File by Using a Text Editor, page 19-10](#)
- [Copying Configuration Files by Using TFTP, page 19-10](#)
- [Copying Configuration Files by Using FTP, page 19-12](#)
- [Copying Configuration Files by Using RCP, page 19-15](#)
- [Clearing Configuration Information, page 19-18](#)

## Guidelines for Creating and Using Configuration Files

Creating configuration files can aid in your access point configuration. Configuration files can contain some or all of the commands needed to configure one or more access points. For example, you might want to download the same configuration file to several access points that have the same hardware configuration.

Use these guidelines when creating a configuration file:

- If no passwords have been set on the access point, you must set them on each access point by entering the **enable secret** *secret-password* global configuration command. Enter a blank line for this command. The password is saved in the configuration file as clear text.
- If passwords already exist, you cannot enter the **enable secret** *secret-password* global configuration command in the file because the password verification will fail. If you enter a password in the configuration file, the access point mistakenly attempts to execute the passwords as commands as it executes the file.
- The **copy {ftp: | rcp: | tftp:} system:running-config** privileged EXEC command loads the configuration files on the access point as if you were entering the commands at the command line. The access point does not erase the existing running configuration before adding the commands. If a command in the copied configuration file replaces a command in the existing configuration file, the existing command is erased. For example, if the copied configuration file contains a different IP address in a particular command than the existing configuration, the IP address in the copied configuration is used. However, some commands in the existing configuration might not be replaced or negated. In this case, the resulting configuration file is a mixture of the existing configuration file and the copied configuration file, with the copied configuration file having precedence.

To restore a configuration file to an exact copy of a file stored on a server, copy the configuration file directly to the startup configuration (by using the **copy {ftp: | rcp: | tftp:} nvram:startup-config** privileged EXEC command), and reload the access point.

## Configuration File Types and Location

Startup configuration files are used during system startup to configure the software. Running configuration files contain the current configuration of the software. The two configuration files can be different. For example, you might want to change the configuration for a short time period rather than permanently. In this case, you would change the running configuration but not save the configuration by using the **copy running-config startup-config** privileged EXEC command.

The running configuration is saved in DRAM; the startup configuration is stored in the NVRAM section of Flash memory.

## Creating a Configuration File by Using a Text Editor

When creating a configuration file, you must list commands logically so that the system can respond appropriately. This is one method of creating a configuration file:

- 
- Step 1** Copy an existing configuration from an access point to a server.  
For more information, see the [“Downloading the Configuration File by Using TFTP”](#) section on page 19-11, the [“Downloading a Configuration File by Using FTP”](#) section on page 19-13, or the [“Downloading a Configuration File by Using RCP”](#) section on page 19-16.
- Step 2** Open the configuration file in a text editor such as vi or emacs on UNIX or Notepad on a PC.
- Step 3** Extract the portion of the configuration file with the desired commands, and save it in a new file.
- Step 4** Copy the configuration file to the appropriate server location. For example, copy the file to the TFTP directory on the workstation (usually /tftpboot on a UNIX workstation).
- Step 5** Make sure the permissions on the file are set to world-read.
- 

## Copying Configuration Files by Using TFTP

You can configure the access point by using configuration files you create, download from another access point, or download from a TFTP server. You can copy (upload) configuration files to a TFTP server for storage.

This section includes this information:

- [Preparing to Download or Upload a Configuration File by Using TFTP, page 19-10](#)
- [Downloading the Configuration File by Using TFTP, page 19-11](#)
- [Uploading the Configuration File by Using TFTP, page 19-11](#)

## Preparing to Download or Upload a Configuration File by Using TFTP

Before you begin downloading or uploading a configuration file by using TFTP, perform these tasks:

- Ensure that the workstation acting as the TFTP server is properly configured. On a Sun workstation, make sure that the /etc/inetd.conf file contains this line:

```
tftp dgram udp wait root /usr/etc/in.tftpd in.tftpd -p -s /tftpboot
```

Make sure that the /etc/services file contains this line:

```
tftp 69/udp
```



**Note** You must restart the inetd daemon after modifying the /etc/inetd.conf and /etc/services files. To restart the daemon, either stop the inetd process and restart it, or enter a **fastboot** command (on the SunOS 4.x) or a **reboot** command (on Solaris 2.x or SunOS 5.x). For more information on the TFTP daemon, refer to the documentation for your workstation.

- Ensure that the access point has a route to the TFTP server. The access point and the TFTP server must be in the same subnetwork if you do not have a router to route traffic between subnets. Check connectivity to the TFTP server by using the **ping** command.

- Ensure that the configuration file to be downloaded is in the correct directory on the TFTP server (usually /tftpboot on a UNIX workstation).
- For download operations, ensure that the permissions on the file are set correctly. The permission on the file should be world-read.
- Before uploading the configuration file, you might need to create an empty file on the TFTP server. To create an empty file, enter the **touch filename** command, where *filename* is the name of the file you will use when uploading it to the server.
- During upload operations, if you are overwriting an existing file (including an empty file, if you had to create one) on the server, ensure that the permissions on the file are set correctly. Permissions on the file should be world-write.

## Downloading the Configuration File by Using TFTP

To configure the access point by using a configuration file downloaded from a TFTP server, follow these steps:

- 
- Step 1** Copy the configuration file to the appropriate TFTP directory on the workstation.
  - Step 2** Verify that the TFTP server is properly configured by referring to the [“Preparing to Download or Upload a Configuration File by Using TFTP”](#) section on page 19-10.
  - Step 3** Log into the access point through a Telnet session.
  - Step 4** Download the configuration file from the TFTP server to configure the access point.

Specify the IP address or host name of the TFTP server and the name of the file to download.

Use one of these privileged EXEC commands:

- **copy tftp:[[/location]/directory]/filename system:running-config**
- **copy tftp:[[/location]/directory]/filename nvram:startup-config**

The configuration file downloads, and the commands are executed as the file is parsed line-by-line.

---

This example shows how to configure the software from the file *tokyo-config* at IP address 172.16.2.155:

```
ap# copy tftp://172.16.2.155/tokyo-config system:running-config
Configure using tokyo-config from 172.16.2.155? [confirm] y
Booting tokyo-config from 172.16.2.155:!!! [OK - 874/16000 bytes]
```

## Uploading the Configuration File by Using TFTP

To upload a configuration file from an access point to a TFTP server for storage, follow these steps:

- 
- Step 1** Verify that the TFTP server is properly configured by referring to the [“Preparing to Download or Upload a Configuration File by Using TFTP”](#) section on page 19-10.
  - Step 2** Log into the access point through a Telnet session.
  - Step 3** Upload the access point configuration to the TFTP server. Specify the IP address or host name of the TFTP server and the destination filename.

Use one of these privileged EXEC commands:

- **copy system:running-config tftp:**[[*location*]/*directory*]/*filename*]
- **copy nvram:startup-config tftp:**[[*location*]/*directory*]/*filename*]

The file is uploaded to the TFTP server.

This example shows how to upload a configuration file from an access point to a TFTP server:

```
ap# copy system:running-config tftp://172.16.2.155/tokyo-config
Write file tokyo-config on host 172.16.2.155? [confirm] y
#
Writing tokyo-config!!! [OK]
```

## Copying Configuration Files by Using FTP

You can copy configuration files to or from an FTP server.

The FTP protocol requires a client to send a remote username and password on each FTP request to a server. When you copy a configuration file from the access point to a server by using FTP, the Cisco IOS software sends the first valid username in this list:

- The username specified in the **copy** command if a username is specified.
- The username set by the **ip ftp username** *username* global configuration command if the command is configured.
- Anonymous.

The access point sends the first valid password in this list:

- The password specified in the **copy** command if a password is specified.
- The password set by the **ip ftp password** *password* global configuration command if the command is configured.
- The access point forms a password named *username@apname.domain*. The variable *username* is the username associated with the current session, *apname* is the configured host name, and *domain* is the domain of the access point.

The username and password must be associated with an account on the FTP server. If you are writing to the server, the FTP server must be properly configured to accept your FTP write request.

Use the **ip ftp username** and **ip ftp password** commands to specify a username and password for all copies. Include the username in the **copy** command if you want to specify only a username for that copy operation.

If the server has a directory structure, the configuration file is written to or copied from the directory associated with the username on the server. For example, if the configuration file resides in the home directory of a user on the server, specify that user's name as the remote username.

For more information, refer to the documentation for your FTP server.

This section includes this information:

- [Preparing to Download or Upload a Configuration File by Using FTP, page 19-13](#)
- [Downloading a Configuration File by Using FTP, page 19-13](#)
- [Uploading a Configuration File by Using FTP, page 19-14](#)

## Preparing to Download or Upload a Configuration File by Using FTP

Before you begin downloading or uploading a configuration file by using FTP, perform these tasks:

- Ensure that the access point has a route to the FTP server. The access point and the FTP server must be in the same subnetwork if you do not have a router to route traffic between subnets. Check connectivity to the FTP server by using the **ping** command.
- If you are accessing the access point through a Telnet session and you do not have a valid username, make sure that the current FTP username is the one that you want to use for the FTP download. You can enter the **show users** privileged EXEC command to view the valid username. If you do not want to use this username, create a new FTP username by using the **ip ftp username *username*** global configuration command during all copy operations. The new username is stored in NVRAM. If you are accessing the access point through a Telnet session and you have a valid username, this username is used, and you do not need to set the FTP username. Include the username in the **copy** command if you want to specify a username for only that copy operation.
- When you upload a configuration file to the FTP server, it must be properly configured to accept the write request from the user on the access point.

For more information, refer to the documentation for your FTP server.

## Downloading a Configuration File by Using FTP

Beginning in privileged EXEC mode, follow these steps to download a configuration file by using FTP:

	Command	Purpose
Step 1		Verify that the FTP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload a Configuration File by Using FTP”</a> section on page 19-13.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode on the access point.  This step is required only if you override the default remote username or password (see Steps 4, 5, and 6).
Step 4	<b>ip ftp username <i>username</i></b>	(Optional) Change the default remote username.
Step 5	<b>ip ftp password <i>password</i></b>	(Optional) Change the default password.
Step 6	<b>end</b>	Return to privileged EXEC mode.
Step 7	<b>copy</b> <b>ftp:[[/[<i>username</i>:<i>password</i>]@]<i>location</i>]/<i>directory</i>] <i>/filename</i>] <b>system:running-config</b>  or <b>copy</b> <b>ftp:[[/[<i>username</i>:<i>password</i>]@]<i>location</i>]/<i>directory</i>] <i>/filename</i>] <b>nvr:startup-config</b></b></b>	Using FTP, copy the configuration file from a network server to the running configuration or to the startup configuration file.

This example shows how to copy a configuration file named *host1-config* from the *netadmin1* directory on the remote server with an IP address of 172.16.101.101 and to load and run those commands on the access point:

```
ap# copy ftp://netadmin1:mypass@172.16.101.101/host1-config system:running-config
Configure using host1-config from 172.16.101.101? [confirm]
```

```

Connected to 172.16.101.101
Loading 1112 byte file host1-config:[OK]
ap#
%SYS-5-CONFIG: Configured from host1-config by ftp from 172.16.101.101

```

This example shows how to specify a remote username of *netadmin1*. The software copies the configuration file *host2-config* from the *netadmin1* directory on the remote server with an IP address of 172.16.101.101 to the access point startup configuration.

```

ap# configure terminal
ap(config)# ip ftp username netadmin1
ap(config)# ip ftp password mypass
ap(config)# end
ap# copy ftp: nvram:startup-config
Address of remote host [255.255.255.255]? 172.16.101.101
Name of configuration file[rtr2-config]? host2-config
Configure using host2-config from 172.16.101.101?[confirm]
Connected to 172.16.101.101
Loading 1112 byte file host2-config:[OK]
[OK]
ap#
%SYS-5-CONFIG_NV:Non-volatile store configured from host2-config by ftp from
172.16.101.101

```

## Uploading a Configuration File by Using FTP

Beginning in privileged EXEC mode, follow these steps to upload a configuration file by using FTP:

	Command	Purpose
Step 1		Verify that the FTP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload a Configuration File by Using FTP”</a> section on page 19-13.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode.  This step is required only if you override the default remote username or password (see Steps 4, 5, and 6).
Step 4	<b>ip ftp username</b> <i>username</i>	(Optional) Change the default remote username.
Step 5	<b>ip ftp password</b> <i>password</i>	(Optional) Change the default password.
Step 6	<b>end</b>	Return to privileged EXEC mode.
Step 7	<b>copy system:running-config</b> <b>ftp:[[[[username[:password]@]location]/directory]</b> <b>/filename]</b>  or <b>copy nvram:startup-config</b> <b>ftp:[[[[username[:password]@]location]/directory]</b> <b>/filename]</b>	Using FTP, store the access point running or startup configuration file to the specified location.

This example shows how to copy the running configuration file named *ap2-config* to the *netadmin1* directory on the remote host with an IP address of 172.16.101.101:

```

ap# copy system:running-config ftp://netadmin1:mypass@172.16.101.101/ap2-config
Write file ap2-config on host 172.16.101.101?[confirm]

```



```
Building configuration...[OK]
Connected to 172.16.101.101
ap#
```

This example shows how to store a startup configuration file on a server by using FTP to copy the file:

```
ap# configure terminal
ap(config)# ip ftp username netadmin2
ap(config)# ip ftp password mypass
ap(config)# end
ap# copy nvram:startup-config ftp:
Remote host[]? 172.16.101.101
Name of configuration file to write [ap2-config]?
Write file ap2-config on host 172.16.101.101?[confirm]
![OK]
```

## Copying Configuration Files by Using RCP

The Remote Copy Protocol (RCP) provides another method of downloading, uploading, and copying configuration files between remote hosts and the access point. Unlike TFTP, which uses User Datagram Protocol (UDP), a connectionless protocol, RCP uses TCP, which is connection-oriented.

To use RCP to copy files, the server from or to which you will be copying files must support RCP. The RCP copy commands rely on the rsh server (or daemon) on the remote system. To copy files by using RCP, you do not need to create a server for file distribution as you do with TFTP. You only need to have access to a server that supports the remote shell (rsh). (Most UNIX systems support rsh.) Because you are copying a file from one place to another, you must have read permission on the source file and write permission on the destination file. If the destination file does not exist, RCP creates it for you.

The RCP requires a client to send a remote username with each RCP request to a server. When you copy a configuration file from the access point to a server, the Cisco IOS software sends the first valid username in this list:

- The username specified in the **copy** command if a username is specified.
- The username set by the **ip rcmd remote-username *username*** global configuration command if the command is configured.
- The remote username associated with the current TTY (terminal) process. For example, if the user is connected to the router through Telnet and was authenticated through the **username** command, the access point software sends the Telnet username as the remote username.
- The access point host name.

For a successful RCP copy request, you must define an account on the network server for the remote username. If the server has a directory structure, the configuration file is written to or copied from the directory associated with the remote username on the server. For example, if the configuration file is in the home directory of a user on the server, specify that user's name as the remote username.

This section includes this information:

- [Preparing to Download or Upload a Configuration File by Using RCP, page 19-16](#)
- [Downloading a Configuration File by Using RCP, page 19-16](#)
- [Uploading a Configuration File by Using RCP, page 19-17](#)

## Preparing to Download or Upload a Configuration File by Using RCP

Before you begin downloading or uploading a configuration file by using RCP, perform these tasks:

- Ensure that the workstation acting as the RCP server supports the remote shell (rsh).
- Ensure that the access point has a route to the RCP server. The access point and the server must be in the same subnetwork if you do not have a router to route traffic between subnets. Check connectivity to the RCP server by using the **ping** command.
- If you are accessing the access point through a Telnet session and you do not have a valid username, make sure that the current RCP username is the one that you want to use for the RCP download. You can enter the **show users** privileged EXEC command to view the valid username. If you do not want to use this username, create a new RCP username by using the **ip rcmd remote-username *username*** global configuration command to be used during all copy operations. The new username is stored in NVRAM. If you are accessing the access point through a Telnet session and you have a valid username, this username is used, and you do not need to set the RCP username. Include the username in the **copy** command if you want to specify a username for only that copy operation.
- When you upload a file to the RCP server, it must be properly configured to accept the RCP write request from the user on the access point. For UNIX systems, you must add an entry to the `.rhosts` file for the remote user on the RCP server. For example, suppose that the access point contains these configuration lines:

```
hostname ap1
ip rcmd remote-username User0
```

If the access point IP address translates to `ap1.company.com`, the `.rhosts` file for User0 on the RCP server should contain this line:

```
ap1.company.com ap1
```

For more information, refer to the documentation for your RCP server.

## Downloading a Configuration File by Using RCP

Beginning in privileged EXEC mode, follow these steps to download a configuration file by using RCP:

	Command	Purpose
Step 1		Verify that the RCP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload a Configuration File by Using RCP”</a> section on page 19-16.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode.  This step is required only if you override the default remote username (see Steps 4 and 5).
Step 4	<b>ip rcmd remote-username <i>username</i></b>	(Optional) Specify the remote username.

	Command	Purpose
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>copy</b> <b>rcp:[[/[[username@]location]/directory]/filename]</b> <b>system:running-config</b>  or <b>copy</b> <b>rcp:[[/[[username@]location]/directory]/filename]</b> <b>nvr:startup-config</b>	Using RCP, copy the configuration file from a network server to the running configuration or to the startup configuration file.

This example shows how to copy a configuration file named *host1-config* from the *netadmin1* directory on the remote server with an IP address of 172.16.101.101 and load and run those commands on the access point:

```
ap# copy rcp://netadmin1@172.16.101.101/host1-config system:running-config
Configure using host1-config from 172.16.101.101? [confirm]
Connected to 172.16.101.101
Loading 1112 byte file host1-config:[OK]
ap#
%SYS-5-CONFIG: Configured from host1-config by rcp from 172.16.101.101
```

This example shows how to specify a remote username of *netadmin1*. Then it copies the configuration file *host2-config* from the *netadmin1* directory on the remote server with an IP address of 172.16.101.101 to the startup configuration:

```
ap# configure terminal
ap(config)# ip rcmd remote-username netadmin1
ap(config)# end
ap# copy rcp: nvr:startup-config
Address of remote host [255.255.255.255]? 172.16.101.101
Name of configuration file[rtr2-config]? host2-config
Configure using host2-config from 172.16.101.101?[confirm]
Connected to 172.16.101.101
Loading 1112 byte file host2-config:[OK]
[OK]
ap#
%SYS-5-CONFIG_NV:Non-volatile store configured from host2-config by rcp from
172.16.101.101
```

## Uploading a Configuration File by Using RCP

Beginning in privileged EXEC mode, follow these steps to upload a configuration file by using RCP:

	Command	Purpose
Step 1		Verify that the RCP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload a Configuration File by Using RCP”</a> section on page 19-16.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode.  This step is required only if you override the default remote username (see Steps 4 and 5).
Step 4	<b>ip rcmd remote-username <i>username</i></b>	(Optional) Specify the remote username.

	Command	Purpose
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>copy system:running-config</b> <b>rcp:[[[//[username@]location]/directory]/filename]</b> or <b>copy nvram:startup-config</b> <b>rcp:[[[//[username@]location]/directory]/filename]</b>	Using RCP, copy the configuration file from an access point running or startup configuration file to a network server.

This example shows how to copy the running configuration file named *ap2-config* to the *netadmin1* directory on the remote host with an IP address of 172.16.101.101:

```
ap# copy system:running-config rcp://netadmin1@172.16.101.101/ap2-config
Write file ap-config on host 172.16.101.101?[confirm]
Building configuration...[OK]
Connected to 172.16.101.101
ap#
```

This example shows how to store a startup configuration file on a server:

```
ap# configure terminal
ap(config)# ip rcmd remote-username netadmin2
ap(config)# end
ap# copy nvram:startup-config rcp:
Remote host[]? 172.16.101.101
Name of configuration file to write [ap2-config]?
Write file ap2-config on host 172.16.101.101?[confirm]
! [OK]
```

## Clearing Configuration Information

This section describes how to clear configuration information.

### Deleting a Stored Configuration File



#### Caution

You cannot restore a file after it has been deleted.

To delete a saved configuration from Flash memory, use the **delete flash:filename** privileged EXEC command. Depending on the setting of the **file prompt** global configuration command, you might be prompted for confirmation before you delete a file. By default, the access point prompts for confirmation on destructive file operations. For more information about the **file prompt** command, refer to the *Cisco IOS Command Reference for Release 12.1*.

## Working with Software Images

This section describes how to archive (download and upload) software image files, which contain the system software, IOS code, radio firmware, and the web management HTML files.

You download an access point image file from a TFTP, FTP, or RCP server to upgrade the access point software. You upload an access point image file to a TFTP, FTP, or RCP server for backup purposes. You can use this uploaded image for future downloads to the same access point or another of the same type.

The protocol you use depends on which type of server you are using. The FTP and RCP transport mechanisms provide faster performance and more reliable delivery of data than TFTP. These improvements are possible because FTP and RCP are built on and use the Transmission Control Protocol/Internet Protocol (TCP/IP) stack, which is connection-oriented.

This section includes this information:

- [Image Location on the Access Point, page 19-19](#)
- [tar File Format of Images on a Server or Cisco.com, page 19-19](#)
- [Copying Image Files by Using TFTP, page 19-20](#)
- [Copying Image Files by Using FTP, page 19-23](#)
- [Copying Image Files by Using RCP, page 19-27](#)
- [Reloading the Image Using the Web Browser Interface, page 19-32](#)

**Note**

---

For a list of software images and supported upgrade paths, refer to the release notes for your access point.

---

## Image Location on the Access Point

The IOS image is stored in a directory that shows the version number. A subdirectory contains the HTML files needed for web management. The image is stored on the system board Flash memory (flash:).

You can use the **show version** privileged EXEC command to see the software version that is currently running on your access point. In the display, check the line that begins with `System image file is...` It shows the directory name in Flash memory where the image is stored.

You can also use the **dir filesystem:** privileged EXEC command to see the directory names of other software images you might have stored in Flash memory.

## tar File Format of Images on a Server or Cisco.com

Software images located on a server or downloaded from Cisco.com are provided in a tar file format, which contains these files:

- *info* file  
The info file is always at the beginning of the tar file and contains information about the files within it.
- IOS image
- Web management files needed by the HTTP server on the access point
- radio firmware 5000.img file
- *info.ver* file  
The info.ver file is always at the end of the tar file and contains the same information as the info file. Because it is the last file in the tar file, its existence means that all files in the image have been downloaded.

**Note**

---

The tar file sometimes ends with an extension other than *.tar*.

---

## Copying Image Files by Using TFTP

You can download an access point image from a TFTP server or upload the image from the access point to a TFTP server.

You download an access point image file from a server to upgrade the access point software. You can overwrite the current image with the new one.

You upload an access point image file to a server for backup purposes; this uploaded image can be used for future downloads to the same or another access point of the same type.

This section includes this information:

- [Preparing to Download or Upload an Image File by Using TFTP, page 19-20](#)
- [Downloading an Image File by Using TFTP, page 19-21](#)
- [Uploading an Image File by Using TFTP, page 19-22](#)

## Preparing to Download or Upload an Image File by Using TFTP

Before you begin downloading or uploading an image file by using TFTP, perform these tasks:

- Ensure that the workstation acting as the TFTP server is properly configured. On a Sun workstation, make sure that the `/etc/inetd.conf` file contains this line:

```
tftp dgram udp wait root /usr/etc/in.tftpd in.tftpd -p -s /tftpboot
```

Make sure that the `/etc/services` file contains this line:

```
tftp 69/udp
```




---

**Note** You must restart the `inetd` daemon after modifying the `/etc/inetd.conf` and `/etc/services` files. To restart the daemon, either stop the `inetd` process and restart it, or enter a **fastboot** command (on the SunOS 4.x) or a **reboot** command (on Solaris 2.x or SunOS 5.x). For more information on the TFTP daemon, refer to the documentation for your workstation.

---

- Ensure that the access point has a route to the TFTP server. The access point and the TFTP server must be in the same subnetwork if you do not have a router to route traffic between subnets. Check connectivity to the TFTP server by using the **ping** command.
- Ensure that the image to be downloaded is in the correct directory on the TFTP server (usually `/tftpboot` on a UNIX workstation).
- For download operations, ensure that the permissions on the file are set correctly. The permission on the file should be world-read.
- Before uploading the image file, you might need to create an empty file on the TFTP server. To create an empty file, enter the **touch filename** command, where *filename* is the name of the file you will use when uploading the image to the server.
- During upload operations, if you are overwriting an existing file (including an empty file, if you had to create one) on the server, ensure that the permissions on the file are set correctly. Permissions on the file should be world-write.

## Downloading an Image File by Using TFTP

You can download a new image file and replace the current image or keep the current image.



### Caution

For the download and upload algorithms to operate properly, do *not* rename image directories.

Beginning in privileged EXEC mode, follow Steps 1 through 3 to download a new image from a TFTP server and overwrite the existing image.

	Command	Purpose
Step 1	.	Copy the image to the appropriate TFTP directory on the workstation. Make sure the TFTP server is properly configured; see the “ <a href="#">Preparing to Download or Upload an Image File by Using TFTP</a> ” section on page 19-20
Step 2		Log into the access point through a Telnet session.
Step 3	<b>archive download-sw /overwrite /reload</b> <b>ftp:[[/location]/directory]/image-name</b>	Download the image file from the TFTP server to the access point, and overwrite the current image. <ul style="list-style-type: none"> <li>• The <b>/overwrite</b> option overwrites the software image in Flash with the downloaded image.</li> <li>• The <b>/reload</b> option reloads the system after downloading the image unless the configuration has been changed and not saved.</li> <li>• For <i>/location</i>, specify the IP address of the TFTP server.</li> <li>• For <i>/directory/image-name</i>, specify the directory (optional) and the image to download. Directory and image names are case sensitive.</li> </ul>
Step 4	<b>archive download-sw /leave-old-sw /reload</b> <b>ftp:[[/location]/directory]/image-name</b>	Download the image file from the TFTP server to the access point, and keep the current image. <ul style="list-style-type: none"> <li>• The <b>/leave-old-sw</b> option keeps the old software version after a download.</li> <li>• The <b>/reload</b> option reloads the system after downloading the image unless the configuration has been changed and not saved.</li> <li>• For <i>/location</i>, specify the IP address of the TFTP server.</li> <li>• For <i>/directory/image-name</i>, specify the directory (optional) and the image to download. Directory and image names are case sensitive.</li> </ul>



### Note

To avoid an unsuccessful download, use the **archive download-sw /safe** command, which downloads the image first and does not delete the current running version until the download succeeds.

The download algorithm verifies that the image is appropriate for the access point model and that enough DRAM is present, or it aborts the process and reports an error. If you specify the **/overwrite** option, the download algorithm removes the existing image on the Flash device whether or not it is the same as the new one, downloads the new image, and then reloads the software.

**Note**

If the Flash device has sufficient space to hold two images and you want to overwrite one of these images with the same version, you must specify the **/overwrite** option.

If you specify the **/leave-old-sw**, the existing files are not removed. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message is displayed.

The algorithm installs the downloaded image on the system board Flash device (flash:). The image is placed into a new directory named with the software version string, and the system boot path variable is updated to point to the newly installed image.

If you kept the old image during the download process (you specified the **/leave-old-sw** keyword), you can remove it by entering the **delete /force /recursive filesystem:/file-url** privileged EXEC command. For *filesystem*, use **flash:** for the system board Flash device. For *file-url*, enter the directory name of the old image. All the files in the directory and the directory are removed.

## Uploading an Image File by Using TFTP

You can upload an image from the access point to a TFTP server. You can later download this image to the access point or to another access point of the same type.

**Caution**

For the download and upload algorithms to operate properly, do *not* rename image directories.

Beginning in privileged EXEC mode, follow these steps to upload an image to a TFTP server:

	Command	Purpose
Step 1		Make sure the TFTP server is properly configured; see the <a href="#">“Preparing to Download or Upload an Image File by Using TFTP”</a> section on page 19-20.
Step 1		Log into the access point through a Telnet session.
Step 2	<b>archive upload-sw</b> <b>tftp:[[/location]/directory]/image-name.tar</b>	Upload the currently running access point image to the TFTP server. <ul style="list-style-type: none"> <li>For <i>/location</i>, specify the IP address of the TFTP server.</li> <li>For <i>/directory/image-name.tar</i>, specify the directory (optional) and the name of the software image to be uploaded. Directory and image names are case sensitive. The <i>image-name.tar</i> is the name of the software image to be stored on the server.</li> </ul>

The **archive upload-sw** privileged EXEC command builds an image file on the server by uploading these files in order: info, the IOS image, the HTML files, and info.ver. After these files are uploaded, the upload algorithm creates the tar file format.



## Copying Image Files by Using FTP

You can download an access point image from an FTP server or upload the image from the access point to an FTP server.

You download an access point image file from a server to upgrade the access point software. You can overwrite the current image with the new one or keep the current image after a download.

You upload an access point image file to a server for backup purposes. You can use this uploaded image for future downloads to the access point or another access point of the same type.

This section includes this information:

- [Preparing to Download or Upload an Image File by Using FTP, page 19-23](#)
- [Downloading an Image File by Using FTP, page 19-24](#)
- [Uploading an Image File by Using FTP, page 19-26](#)

### Preparing to Download or Upload an Image File by Using FTP

You can copy images files to or from an FTP server.

The FTP protocol requires a client to send a remote username and password on each FTP request to a server. When you copy an image file from the access point to a server by using FTP, the Cisco IOS software sends the first valid username in this list:

- The username specified in the **archive download-sw** or **archive upload-sw** privileged EXEC command if a username is specified.
- The username set by the **ip ftp username *username*** global configuration command if the command is configured.
- Anonymous.

The access point sends the first valid password in this list:

- The password specified in the **archive download-sw** or **archive upload-sw** privileged EXEC command if a password is specified.
- The password set by the **ip ftp password *password*** global configuration command if the command is configured.
- The access point forms a password named *username@apname.domain*. The variable *username* is the username associated with the current session, *apname* is the configured host name, and *domain* is the domain of the access point.

The username and password must be associated with an account on the FTP server. If you are writing to the server, the FTP server must be properly configured to accept the FTP write request from you.

Use the **ip ftp username** and **ip ftp password** commands to specify a username and password for all copies. Include the username in the **archive download-sw** or **archive upload-sw** privileged EXEC command if you want to specify a username only for that operation.

If the server has a directory structure, the image file is written to or copied from the directory associated with the username on the server. For example, if the image file resides in the home directory of a user on the server, specify that user's name as the remote username.

Before you begin downloading or uploading an image file by using FTP, perform these tasks:

- Ensure that the access point has a route to the FTP server. The access point and the FTP server must be in the same subnetwork if you do not have a router to route traffic between subnets. Verify connectivity to the FTP server by using the **ping** command.

- If you are accessing the access point through a Telnet session and you do not have a valid username, make sure that the current FTP username is the one that you want to use for the FTP download. You can enter the **show users** privileged EXEC command to view the valid username. If you do not want to use this username, create a new FTP username by using the **ip ftp username *username*** global configuration command. This new name will be used during all archive operations. The new username is stored in NVRAM. If you are accessing the access point through a Telnet session and you have a valid username, this username is used, and you do not need to set the FTP username. Include the username in the **archive download-sw** or **archive upload-sw** privileged EXEC command if you want to specify a username for that operation only.
- When you upload an image file to the FTP server, it must be properly configured to accept the write request from the user on the access point.

For more information, refer to the documentation for your FTP server.

## Downloading an Image File by Using FTP

You can download a new image file and overwrite the current image or keep the current image.



### Caution

For the download and upload algorithms to operate properly, do *not* rename image directories.

Beginning in privileged EXEC mode, follow Steps 1 through 7 to download a new image from an FTP server and overwrite the existing image. To keep the current image, skip Step 7.

	Command	Purpose
Step 1		Verify that the FTP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload an Image File by Using FTP”</a> section on page 19-23.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode.  This step is required only if you override the default remote username or password (see Steps 4, 5, and 6).
Step 4	<b>ip ftp username <i>username</i></b>	(Optional) Change the default remote username.
Step 5	<b>ip ftp password <i>password</i></b>	(Optional) Change the default password.
Step 6	<b>end</b>	Return to privileged EXEC mode.

	Command	Purpose
Step 7	<b>archive download-sw /overwrite /reload</b> <b>ftp:[[/username[:password]@location]/directory]</b> <b>image-name.tar</b>	<p>Download the image file from the FTP server to the access point, and overwrite the current image.</p> <ul style="list-style-type: none"> <li>• The <b>/overwrite</b> option overwrites the software image in Flash with the downloaded image.</li> <li>• The <b>/reload</b> option reloads the system after downloading the image unless the configuration has been changed and not saved.</li> <li>• For <b>//username[:password]</b>, specify the username and password; these must be associated with an account on the FTP server. For more information, see the <a href="#">“Preparing to Download or Upload an Image File by Using FTP”</a> section on page 19-23.</li> <li>• For <b>@location</b>, specify the IP address of the FTP server.</li> <li>• For <b>directory/image-name.tar</b>, specify the directory (optional) and the image to download. Directory and image names are case sensitive.</li> </ul>
Step 8	<b>archive download-sw /leave-old-sw /reload</b> <b>ftp:[[/username[:password]@location]/directory]</b> <b>image-name.tar</b>	<p>Download the image file from the FTP server to the access point, and keep the current image.</p> <ul style="list-style-type: none"> <li>• The <b>/leave-old-sw</b> option keeps the old software version after a download.</li> <li>• The <b>/reload</b> option reloads the system after downloading the image unless the configuration has been changed and not saved.</li> <li>• For <b>//username[:password]</b>, specify the username and password. These must be associated with an account on the FTP server. For more information, see the <a href="#">“Preparing to Download or Upload an Image File by Using FTP”</a> section on page 19-23.</li> <li>• For <b>@location</b>, specify the IP address of the FTP server.</li> <li>• For <b>directory/image-name.tar</b>, specify the directory (optional) and the image to download. Directory and image names are case sensitive.</li> </ul>

**Note**

To avoid an unsuccessful download, use the **archive download-sw /safe** command, which downloads the image first and does not delete the current running version until the download succeeds.

The download algorithm verifies that the image is appropriate for the access point model and that enough DRAM is present, or it aborts the process and reports an error. If you specify the **/overwrite** option, the download algorithm removes the existing image on the Flash device, whether or not it is the same as the new one, downloads the new image, and then reloads the software.

**Note**

If the Flash device has sufficient space to hold two images and you want to overwrite one of these images with the same version, you must specify the **/overwrite** option.

If you specify the **/leave-old-sw**, the existing files are not removed. If there is not enough space to install the new image and keep the running image, the download process stops, and an error message is displayed.

The algorithm installs the downloaded image onto the system board Flash device (flash:). The image is placed into a new directory named with the software version string, and the BOOT path-list is updated to point to the newly installed image. Use the privileged EXEC mode **show boot** command to display boot attributes, and use the global configuration **boot** command to change the boot attributes.

If you kept the old image during the download process (you specified the **/leave-old-sw** keyword), you can remove it by entering the **delete /force /recursive filesystem:/file-url** privileged EXEC command. For *filesystem*, use **flash:** for the system board Flash device. For *file-url*, enter the directory name of the old software image. All the files in the directory and the directory are removed.

## Uploading an Image File by Using FTP

You can upload an image from the access point to an FTP server. You can later download this image to the same access point or to another access point of the same type.



### Caution

For the download and upload algorithms to operate properly, do *not* rename image directories.

The upload feature is available only if the HTML pages associated with the Cluster Management Suite (CMS) have been installed with the existing image.

Beginning in privileged EXEC mode, follow these steps to upload an image to an FTP server:

	Command	Purpose
Step 1		Verify that the FTP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload a Configuration File by Using FTP”</a> section on page 19-13.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode. This step is required only if you override the default remote username or password (see Steps 4, 5, and 6).
Step 4	<b>ip ftp username</b> <i>username</i>	(Optional) Change the default remote username.
Step 5	<b>ip ftp password</b> <i>password</i>	(Optional) Change the default password.

	Command	Purpose
Step 6	<b>end</b>	Return to privileged EXEC mode.
Step 7	<b>archive upload-sw</b> <b>ftp:[/[username[:password]@]location]/directory]/</b> <b>image-name.tar</b>	Upload the currently running access point image to the FTP server. <ul style="list-style-type: none"> <li>For <i>//username:password</i>, specify the username and password. These must be associated with an account on the FTP server. For more information, see the “<a href="#">Preparing to Download or Upload an Image File by Using FTP</a>” section on page 19-23.</li> <li>For <i>@location</i>, specify the IP address of the FTP server.</li> <li>For <i>/directory/image-name.tar</i>, specify the directory (optional) and the name of the software image to be uploaded. Directory and image names are case sensitive. The <i>image-name.tar</i> is the name of the software image to be stored on the server.</li> </ul>

The **archive upload-sw** command builds an image file on the server by uploading these files in order: info, the IOS image, the HTML files, and info.ver. After these files are uploaded, the upload algorithm creates the tar file format.

## Copying Image Files by Using RCP

You can download an access point image from an RCP server or upload the image from the access point to an RCP server.

You download an access point image file from a server to upgrade the access point software. You can overwrite the current image with the new one or keep the current image after a download.

You upload an access point image file to a server for backup purposes. You can use this uploaded image for future downloads to the same access point or another of the same type.

This section includes this information:

- [Preparing to Download or Upload an Image File by Using RCP, page 19-27](#)
- [Downloading an Image File by Using RCP, page 19-29](#)
- [Uploading an Image File by Using RCP, page 19-31](#)

## Preparing to Download or Upload an Image File by Using RCP

RCP provides another method of downloading and uploading image files between remote hosts and the access point. Unlike TFTP, which uses User Datagram Protocol (UDP), a connectionless protocol, RCP uses TCP, which is connection-oriented.

To use RCP to copy files, the server from or to which you will be copying files must support RCP. The RCP copy commands rely on the rsh server (or daemon) on the remote system. To copy files by using RCP, you do not need to create a server for file distribution as you do with TFTP. You only need to have access to a server that supports the remote shell (rsh). (Most UNIX systems support rsh.) Because you are copying a file from one place to another, you must have read permission on the source file and write permission on the destination file. If the destination file does not exist, RCP creates it for you.

RCP requires a client to send a remote username on each RCP request to a server. When you copy an image from the access point to a server by using RCP, the Cisco IOS software sends the first valid username in this list:

- The username specified in the **archive download-sw** or **archive upload-sw** privileged EXEC command if a username is specified.
- The username set by the **ip rcmd remote-username** *username* global configuration command if the command is entered.
- The remote username associated with the current TTY (terminal) process. For example, if the user is connected to the router through Telnet and was authenticated through the **username** command, the access point software sends the Telnet username as the remote username.
- The access point host name.

For the RCP copy request to execute successfully, an account must be defined on the network server for the remote username. If the server has a directory structure, the image file is written to or copied from the directory associated with the remote username on the server. For example, if the image file resides in the home directory of a user on the server, specify that user's name as the remote username.

Before you begin downloading or uploading an image file by using RCP, do these tasks:

- Ensure that the workstation acting as the RCP server supports the remote shell (rsh).
- Ensure that the access point has a route to the RCP server. The access point and the server must be in the same subnetwork if you do not have a router to route traffic between subnets. Check connectivity to the RCP server by using the **ping** command.
- If you are accessing the access point through a Telnet session and you do not have a valid username, make sure that the current RCP username is the one that you want to use for the RCP download. You can enter the **show users** privileged EXEC command to view the valid username. If you do not want to use this username, create a new RCP username by using the **ip rcmd remote-username** *username* global configuration command to be used during all archive operations. The new username is stored in NVRAM. If you are accessing the access point through a Telnet session and you have a valid username, this username is used, and there is no need to set the RCP username. Include the username in the **archive download-sw** or **archive upload-sw** privileged EXEC command if you want to specify a username only for that operation.
- When you upload an image to the RCP to the server, it must be properly configured to accept the RCP write request from the user on the access point. For UNIX systems, you must add an entry to the `.rhosts` file for the remote user on the RCP server. For example, suppose the access point contains these configuration lines:

```
hostname ap1
ip rcmd remote-username User0
```

If the access point IP address translates to `ap1.company.com`, the `.rhosts` file for User0 on the RCP server should contain this line:

```
ap1.company.com ap1
```

For more information, refer to the documentation for your RCP server.

## Downloading an Image File by Using RCP

You can download a new image file and replace or keep the current image.



### Caution

For the download and upload algorithms to operate properly, do *not* rename image directories.

Beginning in privileged EXEC mode, follow Steps 1 through 6 to download a new image from an RCP server and overwrite the existing image. To keep the current image, skip Step 6.

	Command	Purpose
Step 1		Verify that the RCP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload an Image File by Using RCP”</a> section on page 19-27.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode. This step is required only if you override the default remote username (see Steps 4 and 5).
Step 4	<b>ip rcmd remote-username <i>username</i></b>	(Optional) Specify the remote username.
Step 5	<b>end</b>	Return to privileged EXEC mode.

	Command	Purpose
Step 6	<b>archive download-sw /overwrite /reload</b> <b>rcp:[[[//[username@]location]/directory]/image-name.tar]</b>	<p>Download the image file from the RCP server to the access point, and overwrite the current image.</p> <ul style="list-style-type: none"> <li>• The <b>/overwrite</b> option overwrites the software image in Flash with the downloaded image.</li> <li>• The <b>/reload</b> option reloads the system after downloading the image unless the configuration has been changed and not saved.</li> <li>• For <i>//username</i>, specify the username. For the RCP copy request to execute successfully, an account must be defined on the network server for the remote username. For more information, see the <a href="#">“Preparing to Download or Upload an Image File by Using RCP”</a> section on page 19-27.</li> <li>• For <i>@location</i>, specify the IP address of the RCP server.</li> <li>• For <i>/directory/image-name.tar</i>, specify the directory (optional) and the image to download. Directory and image names are case sensitive.</li> </ul>
Step 7	<b>archive download-sw /leave-old-sw /reload</b> <b>rcp:[[[//[username@]location]/directory]/image-name.tar]</b>	<p>Download the image file from the RCP server to the access point, and keep the current image.</p> <ul style="list-style-type: none"> <li>• The <b>/leave-old-sw</b> option keeps the old software version after a download.</li> <li>• The <b>/reload</b> option reloads the system after downloading the image unless the configuration has been changed and not saved.</li> <li>• For <i>//username</i>, specify the username. For the RCP copy request to execute, an account must be defined on the network server for the remote username. For more information, see the <a href="#">“Preparing to Download or Upload an Image File by Using RCP”</a> section on page 19-27.</li> <li>• For <i>@location</i>, specify the IP address of the RCP server.</li> <li>• For <i>/directory/image-name.tar</i>, specify the directory (optional) and the image to download. Directory and image names are case sensitive.</li> </ul>

**Note**

To avoid an unsuccessful download, use the **archive download-sw /safe** command, which downloads the image first and does not delete the current running version until the download succeeds.

The download algorithm verifies that the image is appropriate for the access point model and that enough DRAM is present, or it aborts the process and reports an error. If you specify the **/overwrite** option, the download algorithm removes the existing image on the Flash device whether or not it is the same as the new one, downloads the new image, and then reloads the software.



**Note**

If the Flash device has sufficient space to hold two images and you want to overwrite one of these images with the same version, you must specify the **/overwrite** option.

If you specify the **/leave-old-sw**, the existing files are not removed. If there is not enough room to install the new image and keep the running image, the download process stops, and an error message is displayed.

The algorithm installs the downloaded image onto the system board Flash device (flash:). The image is placed into a new directory named with the software version string, and the BOOT environment variable is updated to point to the newly installed image.

If you kept the old software during the download process (you specified the **/leave-old-sw** keyword), you can remove it by entering the **delete /force /recursive filesystem:/file-url** privileged EXEC command. For *filesystem*, use **flash:** for the system board Flash device. For *file-url*, enter the directory name of the old software image. All the files in the directory and the directory are removed.

## Uploading an Image File by Using RCP

You can upload an image from the access point to an RCP server. You can later download this image to the same access point or to another access point of the same type.

**Caution**

For the download and upload algorithms to operate properly, do *not* rename image directories.

The upload feature is available only if the HTML pages associated with the Cluster Management Suite (CMS) have been installed with the existing image.

Beginning in privileged EXEC mode, follow these steps to upload an image to an RCP server:

	Command	Purpose
Step 1		Verify that the RCP server is properly configured by referring to the <a href="#">“Preparing to Download or Upload an Image File by Using RCP”</a> section on page 19-27.
Step 2		Log into the access point through a Telnet session.
Step 3	<b>configure terminal</b>	Enter global configuration mode.  This step is required only if you override the default remote username (see Steps 4 and 5).
Step 4	<b>ip rcmd remote-username</b> <i>username</i>	(Optional) Specify the remote username.

	Command	Purpose
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>archive upload-sw</b> <b>rep:[[/[[username@]location]/directory]/image-name.tar]</b>	Upload the currently running access point image to the RCP server. <ul style="list-style-type: none"> <li>For <i>//username</i>, specify the username; for the RCP copy request to execute, an account must be defined on the network server for the remote username. For more information, see the “<a href="#">Preparing to Download or Upload an Image File by Using RCP</a>” section on page 19-27.</li> <li>For <i>@location</i>, specify the IP address of the RCP server.</li> <li>For <i>/directory/image-name.tar</i>, specify the directory (optional) and the name of the software image to be uploaded. Directory and image names are case sensitive.</li> <li>The <i>image-name.tar</i> is the name of software image to be stored on the server.</li> </ul>

The **archive upload-sw** privileged EXEC command builds an image file on the server by uploading these files in order: info, the IOS image, the HTML files, and info.ver. After these files are uploaded, the upload algorithm creates the tar file format.

## Reloading the Image Using the Web Browser Interface

You can also use the Web browser interface to reload the access point image file. The Web browser interface supports loading the image file using HTTP or TFTP interfaces.



**Note** Your access point configuration is not changed when using the browser to reload the image file.

### Browser HTTP Interface

The HTTP interface allows you to browse to the access point image file on your PC and download the image to the access point. Follow the instructions below to use the HTTP interface:

- Step 1** Open your Internet browser. You must use Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).
- Step 2** Enter the access point’s IP address in the browser address line and press **Enter**. An Enter Network Password screen appears.
- Step 3** Enter your username in the User Name field.
- Step 4** Enter the access point password in the Password field and press **Enter**. The Summary Status page appears.
- Step 5** Click the **System Software** tab and then click **Software Upgrade**. The HTTP Upgrade screen appears.
- Step 6** Click the **Browse** button to locate the image file on your PC.

**Step 7** Click the **Upload** button.

For additional information, click the **Help** icon on the Software Upgrade screen.

---

## Browser TFTP Interface

The TFTP interface allows you to use a TFTP server on a network device to load the access point image file. Follow the instructions below to use a TFTP server:

- 
- Step 1** Open your Internet browser. You must use Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).
- Step 2** Enter the access point's IP address in the browser address line and press **Enter**. An Enter Network Password screen appears.
- Step 3** Enter your username in the User Name field.
- Step 4** Enter the access point password in the Password field and press **Enter**. The Summary Status page appears.
- Step 5** Click the **System Software** tab and then click **Software Upgrade**. The HTTP Upgrade screen appears.
- Step 6** Click the **TFTP Upgrade** tab.
- Step 7** Enter the IP address for the TFTP server in the TFTP Server field.
- Step 8** Enter the file name for the access point image file in the Upload New System Image Tar File field. If the file is located in a subdirectory of the TFTP server root directory, include the relative path of the TFTP server root directory with the filename. If the file is located in the TFTP root directory, enter only the filename.
- Step 9** Click the **Upload** button.

For additional information click the Help icon on the Software Upgrade screen.

---





## Configuring System Message Logging

---

This chapter describes how to configure system message logging on your access point.



**Note**

---

For complete syntax and usage information for the commands used in this chapter, refer to the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.2*.

---

This chapter consists of these sections:

- [Understanding System Message Logging, page 20-2](#)
- [Configuring System Message Logging, page 20-2](#)
- [Displaying the Logging Configuration, page 20-11](#)

# Understanding System Message Logging

By default, access points send the output from system messages and **debug** privileged EXEC commands to a logging process. The logging process controls the distribution of logging messages to various destinations, such as the logging buffer, terminal lines, or a UNIX syslog server, depending on your configuration. The process also sends messages to the console.



## Note

The syslog format is compatible with 4.3 BSD UNIX.

When the logging process is disabled, messages are sent only to the console. The messages are sent as they are generated, so message and debug output are interspersed with prompts or output from other commands. Messages are displayed on the console after the process that generated them has finished.

You can set the severity level of the messages to control the type of messages displayed on the console and each of the destinations. You can timestamp log messages or set the syslog source address to enhance real-time debugging and management.

You can access logged system messages by using the access point command-line interface (CLI) or by saving them to a properly configured syslog server. The access point software saves syslog messages in an internal buffer. You can remotely monitor system messages by accessing the access point through Telnet or by viewing the logs on a syslog server.

# Configuring System Message Logging

This section describes how to configure system message logging. It contains this configuration information:

- [System Log Message Format, page 20-2](#)
- [Default System Message Logging Configuration, page 20-3](#)
- [Disabling and Enabling Message Logging, page 20-4](#)
- [Setting the Message Display Destination Device, page 20-5](#)
- [Enabling and Disabling Timestamps on Log Messages, page 20-6](#)
- [Enabling and Disabling Sequence Numbers in Log Messages, page 20-6](#)
- [Defining the Message Severity Level, page 20-7](#)
- [Limiting Syslog Messages Sent to the History Table and to SNMP, page 20-8](#)
- [Setting a Logging Rate Limit, page 20-9](#)
- [Configuring UNIX Syslog Servers, page 20-9](#)

## System Log Message Format

System log messages can contain up to 80 characters and a percent sign (%), which follows the optional sequence number or timestamp information, if configured. Messages are displayed in this format:

```
seq no:timestamp: %facility-severity-MNEMONIC:description
```

The part of the message preceding the percent sign depends on the setting of the **service sequence-numbers**, **service timestamps log datetime**, **service timestamps log datetime [localtime] [msec]** [**show-timezone**], or **service timestamps log uptime** global configuration command.

Table 20-1 describes the elements of syslog messages.

**Table 20-1 System Log Message Elements**

Element	Description
<i>seq no:</i>	Stamps log messages with a sequence number only if the <b>service sequence-numbers</b> global configuration command is configured.  For more information, see the “ <a href="#">Enabling and Disabling Sequence Numbers in Log Messages</a> ” section on page 20-6.
<i>timestamp</i> formats: <i>mm/dd hh:mm:ss</i> or <i>hh:mm:ss</i> (short uptime) or <i>d h</i> (long uptime)	Date and time of the message or event. This information appears only if the <b>service timestamps log [datetime   log]</b> global configuration command is configured.  For more information, see the “ <a href="#">Enabling and Disabling Timestamps on Log Messages</a> ” section on page 20-6.
<i>facility</i>	The facility to which the message refers (for example, SNMP, SYS, and so forth). A facility can be a hardware device, a protocol, or a module of the system software. It denotes the source or the cause of the system message.
<i>severity</i>	Single-digit code from 0 to 7 that is the severity of the message. For a description of the severity levels, see <a href="#">Table 20-3 on page 20-7</a> .
<i>MNEMONIC</i>	Text string that uniquely describes the message.
<i>description</i>	Text string containing detailed information about the event being reported.

This example shows a partial access point system message:

```
00:00:46: %LINK-3-UPDOWN: Interface Port-channell, changed state to up
00:00:47: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changed state to up
00:00:47: %LINK-3-UPDOWN: Interface GigabitEthernet0/2, changed state to up
00:00:48: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan1, changed state to down
00:00:48: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/1, changed
state to down 2
*Mar  1 18:46:11: %SYS-5-CONFIG_I: Configured from console by vty2 (10.34.195.36)
18:47:02: %SYS-5-CONFIG_I: Configured from console by vty2 (10.34.195.36)
*Mar  1 18:48:50.483 UTC: %SYS-5-CONFIG_I: Configured from console by vty2 (10.34.195.36)
```

## Default System Message Logging Configuration

Table 20-2 shows the default system message logging configuration.

**Table 20-2 Default System Message Logging Configuration**

Feature	Default Setting
System message logging to the console	Enabled
Console severity	Debugging (and numerically lower levels; see <a href="#">Table 20-3 on page 20-7</a> )
Logging buffer size	4096 bytes
Logging history size	1 message

**Table 20-2 Default System Message Logging Configuration (continued)**

Feature	Default Setting
Timestamps	Disabled
Synchronous logging	Disabled
Logging server	Disabled
Syslog server IP address	None configured
Server facility	Local7 (see <a href="#">Table 20-4 on page 20-11</a> )
Server severity	Informational (and numerically lower levels; see <a href="#">Table 20-3 on page 20-7</a> )

## Disabling and Enabling Message Logging

Message logging is enabled by default. It must be enabled to send messages to any destination other than the console. When enabled, log messages are sent to a logging process, which logs messages to designated locations asynchronously to the processes that generated the messages.

Beginning in privileged EXEC mode, follow these steps to disable message logging:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>no logging on</b>	Disable message logging.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b> or <b>show logging</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

Disabling the logging process can slow down the access point because a process must wait until the messages are written to the console before continuing. When the logging process is disabled, messages are displayed on the console as soon as they are produced, often appearing in the middle of command output.

The **logging synchronous** global configuration command also affects the display of messages to the console. When this command is enabled, messages appear only after you press Return. For more information, see the “[Enabling and Disabling Timestamps on Log Messages](#)” section on page 20-6.

To re-enable message logging after it has been disabled, use the **logging on** global configuration command.



## Setting the Message Display Destination Device

If message logging is enabled, you can send messages to specific locations in addition to the console. Beginning in privileged EXEC mode, use one or more of the following commands to specify the locations that receive messages:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>logging buffered</b> <i>[size]</i> <i>[level]</i>	Log messages to an internal buffer. The default buffer size is 4096. The range is 4096 to 2147483647 bytes. Levels include emergencies 0, alerts 1, critical 2, errors 3, warnings 4, notifications 5, informational 6, and debugging 7.  <b>Note</b> Do not make the buffer size too large because the access point could run out of memory for other tasks. Use the <b>show memory</b> privileged EXEC command to view the free processor memory on the access point; however, this value is the maximum available, and you should <i>not</i> set the buffer size to this amount.
Step 3	<b>logging</b> <i>host</i>	Log messages to a UNIX syslog server host.  For <i>host</i> , specify the name or IP address of the host to be used as the syslog server.  To build a list of syslog servers that receive logging messages, enter this command more than once.  For complete syslog server configuration steps, see the <a href="#">“Configuring UNIX Syslog Servers”</a> section on page 20-9.
Step 4	<b>end</b>	Return to privileged EXEC mode.
Step 5	<b>terminal monitor</b>	Log messages to a non-console terminal during the current session.  Terminal parameter-setting commands are set locally and do not remain in effect after the session has ended. You must perform this step for each session to see the debugging messages.
Step 6	<b>show running-config</b>	Verify your entries.
Step 7	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

The **logging buffered** global configuration command copies logging messages to an internal buffer. The buffer is circular, so newer messages overwrite older messages after the buffer is full. To display the messages that are logged in the buffer, use the **show logging** privileged EXEC command. The first message displayed is the oldest message in the buffer. To clear the contents of the buffer, use the **clear logging** privileged EXEC command.

To disable logging to the console, use the **no logging console** global configuration command. To disable logging to a file, use the **no logging file** *[severity-level-number | type]* global configuration command.

## Enabling and Disabling Timestamps on Log Messages

By default, log messages are not timestamped.

Beginning in privileged EXEC mode, follow these steps to enable timestamping of log messages:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>service timestamps log uptime</b> or <b>service timestamps log datetime [msec] [localtime] [show-timezone]</b>	Enable log timestamps.  The first command enables timestamps on log messages, showing the time since the system was rebooted.  The second command enables timestamps on log messages. Depending on the options selected, the timestamp can include the date, time in milliseconds relative to the local time zone, and the time zone name.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable timestamps for both debug and log messages, use the **no service timestamps** global configuration command.

This example shows part of a logging display with the **service timestamps log datetime** global configuration command enabled:

```
*Mar  1 18:46:11: %SYS-5-CONFIG_I: Configured from console by vty2 (10.34.195.36)
```

This example shows part of a logging display with the **service timestamps log uptime** global configuration command enabled:

```
00:00:46: %LINK-3-UPDOWN: Interface Port-channel1, changed state to up
```

## Enabling and Disabling Sequence Numbers in Log Messages

Because there is a chance that more than one log message can have the same timestamp, you can display messages with sequence numbers so that you can unambiguously refer to a single message. By default, sequence numbers in log messages are not displayed.

Beginning in privileged EXEC mode, follow these steps to enable sequence numbers in log messages:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>service sequence-numbers</b>	Enable sequence numbers.
Step 3	<b>end</b>	Return to privileged EXEC mode.
Step 4	<b>show running-config</b>	Verify your entries.
Step 5	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.

To disable sequence numbers, use the **no service sequence-numbers** global configuration command.

This example shows part of a logging display with sequence numbers enabled:

```
000019: %SYS-5-CONFIG_I: Configured from console by vty2 (10.34.195.36)
```

## Defining the Message Severity Level

You can limit messages displayed to the selected device by specifying the severity level of the message, which are described in [Table 20-3](#).

Beginning in privileged EXEC mode, follow these steps to define the message severity level:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>logging console <i>level</i></b>	Limit messages logged to the console.  By default, the console receives debugging messages and numerically lower levels (see <a href="#">Table 20-3 on page 20-7</a> ).
Step 3	<b>logging monitor <i>level</i></b>	Limit messages logged to the terminal lines.  By default, the terminal receives debugging messages and numerically lower levels (see <a href="#">Table 20-3 on page 20-7</a> ).
Step 4	<b>logging trap <i>level</i></b>	Limit messages logged to the syslog servers.  By default, syslog servers receive informational messages and numerically lower levels (see <a href="#">Table 20-3 on page 20-7</a> ).  For complete syslog server configuration steps, see the “ <a href="#">Configuring UNIX Syslog Servers</a> ” section on page 20-9.
Step 5	<b>end</b>	Return to privileged EXEC mode.
Step 6	<b>show running-config</b>  or <b>show logging</b>	Verify your entries.
Step 7	<b>copy running-config startup-config</b>	(Optional) Save your entries in the configuration file.



### Note

Specifying a *level* causes messages at that level and numerically lower levels to be displayed at the destination.

To disable logging to the console, use the **no logging console** global configuration command. To disable logging to a terminal other than the console, use the **no logging monitor** global configuration command. To disable logging to syslog servers, use the **no logging trap** global configuration command.

[Table 20-3](#) describes the *level* keywords. It also lists the corresponding UNIX syslog definitions from the most severe level to the least severe level.

**Table 20-3 Message Logging Level Keywords**

Level Keyword	Level	Description	Syslog Definition
<b>emergencies</b>	0	System unstable	LOG_EMERG
<b>alerts</b>	1	Immediate action needed	LOG_ALERT

Table 20-3 Message Logging Level Keywords (continued)

Level Keyword	Level	Description	Syslog Definition
<b>critical</b>	2	Critical conditions	LOG_CRIT
<b>errors</b>	3	Error conditions	LOG_ERR
<b>warnings</b>	4	Warning conditions	LOG_WARNING
<b>notifications</b>	5	Normal but significant condition	LOG_NOTICE
<b>informational</b>	6	Informational messages only	LOG_INFO
<b>debugging</b>	7	Debugging messages	LOG_DEBUG

The software generates four other categories of messages:

- Error messages about software or hardware malfunctions, displayed at levels **warnings** through **emergencies**. These types of messages mean that the functionality of the access point is affected.
- Output from the **debug** commands, displayed at the **debugging** level. Debug commands are typically used only by the Technical Assistance Center (TAC).
- Interface up or down transitions and system restart messages, displayed at the **notifications** level. This message is only for information; access point functionality is not affected.
- Reload requests and low-process stack messages, displayed at the **informational** level. This message is only for information; access point functionality is not affected.

## Limiting Syslog Messages Sent to the History Table and to SNMP

If you have enabled syslog message traps to be sent to an SNMP network management station by using the **snmp-server enable trap** global configuration command, you can change the level of messages sent and stored in the access point history table. You can also change the number of messages that are stored in the history table.

Messages are stored in the history table because SNMP traps are not guaranteed to reach their destination. By default, one message of the level **warning** and numerically lower levels (see [Table 20-3 on page 20-7](#)) are stored in the history table even if syslog traps are not enabled.

Beginning in privileged EXEC mode, follow these steps to change the level and history table size defaults:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>logging history <i>level</i><sup>1</sup></b>	Change the default level of syslog messages stored in the history file and sent to the SNMP server.  See <a href="#">Table 20-3 on page 20-7</a> for a list of <i>level</i> keywords.  By default, <b>warnings</b> , <b>errors</b> , <b>critical</b> , <b>alerts</b> , and <b>emergencies</b> messages are sent.
Step 3	<b>logging history size <i>number</i></b>	Specify the number of syslog messages that can be stored in the history table.  The default is to store one message. The range is 1 to 500 messages.
Step 4	<b>end</b>	Return to privileged EXEC mode.

	Command	Purpose
Step 5	<code>show running-config</code>	Verify your entries.
Step 6	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

1. [Table 20-3](#) lists the level keywords and severity level. For SNMP usage, the severity level values increase by 1. For example, emergencies equal 1, not 0, and critical equals 3, not 2.

When the history table is full (it contains the maximum number of message entries specified with the **logging history size** global configuration command), the oldest message entry is deleted from the table to allow the new message entry to be stored.

To return the logging of syslog messages to the default level, use the **no logging history** global configuration command. To return the number of messages in the history table to the default value, use the **no logging history size** global configuration command.

## Setting a Logging Rate Limit

You can enable a limit on the number of messages that the access point logs per second. You can enable the limit for all messages or for messages sent to the console, and you can specify that messages of a specific severity are exempt from the limit.

Beginning in privileged EXEC mode, follow these steps to enable a logging rate limit:

	Command	Purpose
Step 1	<code>configure terminal</code>	Enter global configuration mode.
Step 2	<code>logging rate-limit <i>seconds</i></code> [all   console] [except <i>severity</i> ]	Enable a logging rate limit in seconds. <ul style="list-style-type: none"> <li>• (Optional) Apply the limit to all logging or only to messages logged to the console.</li> <li>• (Optional) Exempt a specific severity from the limit.</li> </ul>
Step 3	<code>end</code>	Return to privileged EXEC mode.
Step 4	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

To disable the rate limit, use the **no logging rate-limit** global configuration command.

## Configuring UNIX Syslog Servers

The next sections describe how to configure the 4.3 BSD UNIX server syslog daemon and define the UNIX system logging facility.

## Logging Messages to a UNIX Syslog Daemon

Before you can send system log messages to a UNIX syslog server, you must configure the syslog daemon on a UNIX server. Log in as root, and perform these steps:



### Note

Some recent versions of UNIX syslog daemons no longer accept by default syslog packets from the network. If this is the case with your system, use the UNIX **man syslogd** command to determine what options must be added to or removed from the syslog command line to enable logging of remote syslog messages.

**Step 1** Add a line such as the following to the file `/etc/syslog.conf`:

```
local7.debug /usr/adm/logs/cisco.log
```

The **local7** keyword specifies the logging facility to be used; see [Table 20-4 on page 20-11](#) for information on the facilities. The **debug** keyword specifies the syslog level; see [Table 20-3 on page 20-7](#) for information on the severity levels. The syslog daemon sends messages at this level or at a more severe level to the file specified in the next field. The file must already exist, and the syslog daemon must have permission to write to it.

**Step 2** Create the log file by entering these commands at the UNIX shell prompt:

```
$ touch /usr/adm/log/cisco.log
$ chmod 666 /usr/adm/log/cisco.log
```

**Step 3** Make sure the syslog daemon reads the new changes by entering this command:

```
$ kill -HUP `cat /etc/syslog.pid`
```

For more information, see the **man syslog.conf** and **man syslogd** commands on your UNIX system.

## Configuring the UNIX System Logging Facility

When sending system log messages to an external device, you can cause the access point to identify its messages as originating from any of the UNIX syslog facilities.

Beginning in privileged EXEC mode, follow these steps to configure UNIX system facility message logging:

	Command	Purpose
Step 1	<b>configure terminal</b>	Enter global configuration mode.
Step 2	<b>logging host</b>	Log messages to a UNIX syslog server host by entering its IP address. To build a list of syslog servers that receive logging messages, enter this command more than once.
Step 3	<b>logging trap level</b>	Limit messages logged to the syslog servers. By default, syslog servers receive informational messages and lower. See <a href="#">Table 20-3 on page 20-7</a> for <i>level</i> keywords.

	Command	Purpose
Step 4	<code>logging facility facility-type</code>	Configure the syslog facility. See <a href="#">Table 20-4 on page 20-11</a> for <i>facility-type</i> keywords. The default is <b>local7</b> .
Step 5	<code>end</code>	Return to privileged EXEC mode.
Step 6	<code>show running-config</code>	Verify your entries.
Step 7	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

To remove a syslog server, use the **no logging host** global configuration command, and specify the syslog server IP address. To disable logging to syslog servers, enter the **no logging trap** global configuration command.

[Table 20-4](#) lists the 4.3 BSD UNIX system facilities supported by the Cisco IOS software. For more information about these facilities, consult the operator's manual for your UNIX operating system.

**Table 20-4 Logging Facility-Type Keywords**

Facility Type Keyword	Description
<b>auth</b>	Authorization system
<b>cron</b>	Cron facility
<b>daemon</b>	System daemon
<b>kern</b>	Kernel
<b>local0-7</b>	Locally defined messages
<b>lpr</b>	Line printer system
<b>mail</b>	Mail system
<b>news</b>	USENET news
<b>sys9</b>	System use
<b>sys10</b>	System use
<b>sys11</b>	System use
<b>sys12</b>	System use
<b>sys13</b>	System use
<b>sys14</b>	System use
<b>syslog</b>	System log
<b>user</b>	User process
<b>uucp</b>	UNIX-to-UNIX copy system

## Displaying the Logging Configuration

To display the current logging configuration and the contents of the log buffer, use the **show logging** privileged EXEC command. For information about the fields in this display, refer to the *Cisco IOS Configuration Fundamentals Command Reference for Release 12.2*.

To display the logging history file, use the **show logging history** privileged EXEC command.







## Troubleshooting

---

This chapter provides troubleshooting procedures for basic problems with the access point. For the most up-to-date, detailed troubleshooting information, refer to the Cisco TAC website at the following URL (select **Top Issues** and then select **Wireless Technologies**):

<http://www.cisco.com/tac>


Sections in this chapter include:

- [Checking the Top Panel Indicators, page 21-2](#)
- [Checking Basic Settings, page 21-4](#)
- [Resetting to the Default Configuration, page 21-4](#)
- [Reloading the Access Point Image, page 21-6](#)

## Checking the Top Panel Indicators

If your access point is not communicating, check the three LED indicators on the top panel. You can use them to quickly assess the unit's status. [Figure 21-1](#) shows the indicators.

*Figure 21-1 Access Point Indicators*



The indicators signals have the following meanings (for additional details refer to [Table 21-1](#)):

- The Ethernet indicator signals traffic on the wired LAN, or Ethernet infrastructure. This indicator is normally green when an Ethernet cable is connected, and blinks green when a packet is received or transmitted over the Ethernet infrastructure. The indicator is off when the Ethernet cable is not connected.
- The status indicator signals operational status. Steady green indicates that the access point is associated with at least one wireless client. Blinking green indicates that the access point is operating normally but is not associated with any wireless devices.
- The radio indicator blinks green to indicate radio traffic activity. The light is normally off, but it blinks green whenever a packet is received or transmitted over the access point's radio.

Table 21-1 Top Panel Indicator Signals

Message type	Ethernet indicator	Status indicator	Radio indicator	Meaning
Boot loader status	Green	–	Green	DRAM memory test.
	–	Amber	Red	Board initialization test
	–	Blinking green	Blinking green	Flash memory test.
	Amber	Green	–	Ethernet initialization test.
	Green	Green	Green	Starting IOS.
Association status	–	Green	–	At least one wireless client device is associated with the unit.
	–	Blinking green	–	No client devices are associated; check the unit's SSID and WEP settings.
Operating status	–	Green	Blinking green	Transmitting/receiving radio packets.
	Green	–	–	Ethernet link is operational.
	Blinking green	–	–	Transmitting/receiving Ethernet packets.
Boot Loader Errors	Red	–	Red	DRAM memory test failure.
	–	Red	Red	File system failure.
	Red	Red	–	Ethernet failure during image recovery.
	Amber	Green	Amber	Boot environment error.
	Red	Green	Red	No IOS image file.
	Amber	Amber	Amber	Boot failure.
Operation Errors	–	Green	Blinking amber	Maximum retries or buffer full occurred on the radio.
	Blinking amber	–	–	Transmit/receive Ethernet errors.
	–	Blinking amber	–	General warning.
Configuration Reset	–	Amber	–	Resetting the configuration options to factory defaults.
Failure	Red	Red	Red	Firmware failure; try disconnecting and reconnecting unit power.
Firmware Upgrade	–	Red	–	Loading new firmware image.

# Checking Basic Settings

Mismatched basic settings are the most common causes of lost connectivity with wireless clients. If the access point does not communicate with client devices, check the following areas.

## SSID

Wireless clients attempting to associate with the access point must use the same SSID as the access point. If a client device's SSID does not match the SSID of an access point in radio range, the client device will not associate. The access point default SSID is *tsunami*.

## WEP Keys

The WEP key you use to transmit data must be set up exactly the same on your access point and any wireless devices with which it associates. For example, if you set WEP Key 3 on your client adapter to 0987654321 and select it as the transmit key, you must also set WEP Key 3 on the access point to exactly the same value. The access point does not need to use Key 3 as its transmit key, however.

Refer to [Chapter 9, “Configuring WEP and WEP Features,”](#) for instructions on setting the access point's WEP keys.

## Security Settings

Wireless clients attempting to authenticate with your access point must support the same security options configured in the access point, such as EAP or LEAP, MAC address authentication, Message Integrity Check (MIC), WEP key hashing, and 802.1X protocol versions.

If a wireless client is unable to authenticate with your access point, contact the system administrator for proper security settings in the client adapter and for the client adapter driver and firmware versions that are compatible with the access point settings.



Note

---

The access point MAC address that appears on the Status page in the Aironet Client Utility (ACU) is the MAC address for the access point radio. The MAC address for the access point Ethernet port is printed on the label on the back of the access point.

---

## Resetting to the Default Configuration

If you forget the password that allows you to configure the access point, you may need to completely reset the configuration. You can use the MODE button on the access point or the web-browser interface.



Note

---

The following steps reset *all* configuration settings to factory defaults, including passwords, WEP keys, the IP address, and the SSID.

---

## Using the MODE Button

Follow these steps to delete the current configuration and return all access point settings to the factory defaults using the MODE button:

- 
- Step 1** Disconnect power (the power jack for external power or the Ethernet cable for in-line power) from the access point.
  - Step 2** Press and hold the MODE button while you reconnect power to the access point.
  - Step 3** Hold the MODE button until the Status LED turns amber (approximately 1 to 2 seconds), and release the button.
  - Step 4** After the access point reboots, you must reconfigure the access point by using the Web browser interface, the Telnet interface, or IOS commands.



---

**Note** The access point is configured with the factory default values including the IP address (set to receive an IP address using DHCP).

---

## Using the Web Browser Interface

Follow the steps below to delete the current configuration and return all access point settings to the factory defaults using the web browser interface.

- 
- Step 1** Open your Internet browser. You must use Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).
  - Step 2** Enter the access point's IP address in the browser address line and press **Enter**. An Enter Network Password screen appears.
  - Step 3** Enter your username in the User Name field.
  - Step 4** Enter the access point password in the Password field and press **Enter**. The Summary Status page appears.
  - Step 5** Click **System Software** and the System Software screen appears.
  - Step 6** Click **System Configuration** and the System Configuration screen appears.
  - Step 7** Click the **Default** button.



---

**Note** If the access point is configured with a static IP address, the IP address does not change.

---

- Step 8** After the access point reboots, you must reconfigure the access point by using the Web browser interface, the Telnet interface, or IOS commands.
-

# Reloading the Access Point Image

If your access point has a firmware failure, you must reload the complete access point image file using the Web browser interface or by pressing and holding the MODE button for around 30 seconds. You can use the browser interface if the access point firmware is still fully operational and you want to upgrade the firmware image. However, you can use the MODE button when the access point has a corrupt firmware image.

## Using the MODE button

You can use the MODE button on the access point to reload the access point image file from an active Trivial File Transfer Protocol (TFTP) server on your network or on a PC connected to the access point Ethernet port.



**Note**

If your access point experiences a firmware failure or a corrupt firmware image, indicated by three red LED indicators, you must reload the image from a connected TFTP server.



**Note**

This process resets *all* configuration settings to factory defaults, including passwords, WEP keys, the access point IP address, and SSIDs.

Follow the steps below to reload the access point image file:

- 
- Step 1** The PC you intend to use must be configured with a static IP address in the range of 10.0.0.2 to 10.0.0.30.
  - Step 2** Make sure the PC contains the access point image file (*c1100-k9w7-tar.default*) in the TFTP server folder and the TFTP server is activated. For additional information, refer to the [“Obtaining the Access Point Image File”](#) and [“Obtaining the TFTP Server Software”](#) sections.
  - Step 3** Connect the PC to the access point using a Category 5 (CAT5) Ethernet cable.
  - Step 4** Disconnect power (the power jack for external power or the Ethernet cable for in-line power) from the access point.
  - Step 5** Press and hold the MODE button while you reconnect power to the access point.
  - Step 6** Hold the MODE button until the status LED turns red (approximately 20 to 30 seconds), and release the MODE button.
  - Step 7** Wait until the access point reboots as indicated by all LEDs turning green followed by the Status LED blinking green.
  - Step 8** After the access point reboots, you must reconfigure the access point by using the Web interface, the Telnet interface, or IOS commands.
-

## Web Browser Interface

You can also use the Web browser interface to reload the access point image file. The Web browser interface supports loading the image file using HTTP or TFTP interfaces.



**Note** Your access point configuration is not changed when using the browser to reload the image file.

### Browser HTTP Interface

The HTTP interface enables you to browse to the access point image file on your PC and download the image to the access point. Follow the instructions below to use the HTTP interface:

- 
- Step 1** Open your Internet browser. You must use Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).
  - Step 2** Enter the access point's IP address in the browser address line and press **Enter**. An Enter Network Password screen appears.
  - Step 3** Enter your username in the User Name field.
  - Step 4** Enter the access point password in the Password field and press **Enter**. The Summary Status page appears.
  - Step 5** Click the **System Software** tab and then click **Software Upgrade**. The HTTP Upgrade screen appears.
  - Step 6** Click the **Browse** button to locate the image file on your PC.
  - Step 7** Click the **Upload** button.

For additional information, click the **Help** icon on the Software Upgrade screen.

---

### Browser TFTP Interface

The TFTP interface allows you to use a TFTP server on a network device to load the access point image file. Follow the instructions below to use a TFTP server:

- 
- Step 1** Open your Internet browser. You must use Microsoft Internet Explorer (version 5.x or later) or Netscape Navigator (version 4.x).
  - Step 2** Enter the access point's IP address in the browser address line and press **Enter**. An Enter Network Password screen appears.
  - Step 3** Enter your username in the User Name field.
  - Step 4** Enter the access point password in the Password field and press **Enter**. The Summary Status page appears.
  - Step 5** Click the **System Software** tab and then click **Software Upgrade**. The HTTP Upgrade screen appears.
  - Step 6** Click the **TFTP Upgrade** tab.
  - Step 7** Enter the IP address for the TFTP server in the TFTP Server field.

- Step 8** Enter the file name for the access point image file in the Upload New System Image Tar File field. If the file is located in a subdirectory of the TFTP server root directory, include the relative path of the TFTP server root directory with the filename. If the file is located in the TFTP root directory, enter only the filename.
- Step 9** Click the **Upload** button.
- For additional information click the Help icon on the Software Upgrade screen.
- 

## Obtaining the Access Point Image File

The access point image file can be obtained from the Cisco.com software center using the following steps:

- 
- Step 1** Use your Internet browser to access the Cisco Software Center at the following URL:  
<http://www.cisco.com/public/sw-center/sw-wireless.shtml>
- Step 2** Locate the access point firmware and utilities section and click on the link for the 1100 series access point.
- Step 3** Double-click the latest firmware image file (c1100-k9w7-tar.122-4.JA).
- Step 4** Download the access point image file to a directory on your PC hard drive.
- 

## Obtaining the TFTP Server Software

You can download TFTP server software from several websites. Cisco recommends the shareware TFTP utility available at this URL:

<http://tftpd32.jounin.net>

Follow the instructions on the website for installing and using the utility.





## Translated Safety Warnings

---

This appendix provides translations of the safety warnings that appear in this publication. These translated warnings apply to other documents in which they appear in English. The following safety warnings appear in this appendix:

- [Dipole Antenna Installation Warning, page A-2](#)
- [Explosive Device Proximity Warning, page A-3](#)
- [Lightning Activity Warning, page A-4](#)
- [Installation Warning, page A-5](#)
- [Circuit Breaker \(15A\) Warning, page A-5](#)

# Dipole Antenna Installation Warning


**Warning**

In order to comply with FCC radio frequency (RF) exposure limits, dipole antennas should be located at a minimum of 7.9 inches (20 cm) or more from the body of all persons.

**Waarschuwing**

Om te voldoen aan de FCC radiofrequentie (RF) blootstellingslimieten dienen dipoolantennes zich minstens 20 cm of meer van de lichamen van alle personen bevinden.

**Varoitus**

FCC:n antamien radiotaajuuksille altistumista koskevien rajoitusten mukaan dipoliantennien on sijaittava vähintään 20 cm:n päässä kaikista henkilöistä.

**Attention**

Pour se conformer aux limites d'exposition à la fréquence radio préconisées par la FCC (Federal Communications Commission), les antennes dipôles doivent se situer à un minimum de 20 cm de toute personne.

**Warnung**

Um die in den FCC-Richtlinien festgelegten Expositionshöchstgrenzen für Radiofrequenzen (RF) nicht zu überschreiten, sollten Dipolantennen mindestens 20 cm (7,9 Zoll) vom Körper aller Person entfernt aufgestellt werden.

**Avvertenza**

Per conformarsi ai limiti FCC di esposizione a radiofrequenza (RF), le antenne a dipolo devono stare ad una distanza minima di 20 cm dal corpo di ogni persona.

**Advarsel**

I henhold til eksponeringsgrensene for radiofrekvenser (RF), skal dipole antenner befinne seg på en avstand av minst 20 cm eller mer fra mennesker.

**Aviso**

Para estar de acordo com as normas FCC de limites de exposição para frequência de rádio (RF), as antenas dipolo devem estar distantes no mínimo 20 cm (7,9 pol) do corpo de qualquer pessoa.

**¡Advertencia!**

Para cumplir con los límites de exposición de radio frecuencia (RF) de la Comisión Federal de Comunicaciones (FCC) es preciso ubicar las antenas dipolo a un mínimo de 20 cm (7,9 pulgadas) o más del cuerpo de las personas.

**Varning!**

För att följa FCC-exponeringsgränserna för radiofrekvens (RF), bör dipolantenner placeras på minst 20 cm avstånd från alla människor.

# Explosive Device Proximity Warning



---

<b>Warning</b>	<b>Do not operate your wireless network device near unshielded blasting caps or in an explosive environment unless the device has been modified to be especially qualified for such use.</b>
<b>Waarschuwing</b>	<b>Gebruik dit draadloos netwerkkapparaat alleen in de buurt van onbeschermd ontstekers of in een omgeving met explosieven indien het apparaat speciaal is aangepast om aan de eisen voor een dergelijk gebruik te voldoen.</b>
<b>Varoitus</b>	<b>Älä käytä johdotonta verkkolaitetta suojaamattomien räjäytysnallien läheisyydessä tai räjäytysalueella, jos laitetta ei ole erityisesti muunnettu sopivaksi sellaiseen käyttöön.</b>
<b>Attention</b>	<b>Ne jamais utiliser un équipement de réseau sans fil à proximité d'un détonateur non blindé ou dans un lieu présentant des risques d'explosion, sauf si l'équipement a été modifié à cet effet.</b>
<b>Warnung</b>	<b>Benutzen Sie Ihr drahtloses Netzwerkgerät nicht in der Nähe ungeschützter Sprengkapseln oder anderer explosiver Stoffe, es sei denn, Ihr Gerät wurde eigens für diesen Gebrauch modifiziert und bestimmt.</b>
<b>Avvertenza</b>	<b>Non utilizzare la periferica di rete senza fili in prossimità di un detonatore non protetto o di esplosivi a meno che la periferica non sia stata modificata a tale proposito.</b>
<b>Advarsel</b>	<b>Ikke bruk den trådløse nettverksenheten nært inntil uisolerte fenghetter eller i et eksplosivt miljø med mindre enheten er modifisert slik at den tåler slik bruk.</b>
<b>Aviso</b>	<b>Não opere o dispositivo de rede sem fios perto de cápsulas explosivas não protegidas ou num ambiente explosivo, a não ser que o dispositivo tenha sido modificado para se qualificar especialmente para essa utilização.</b>
<b>¡Advertencia!</b>	<b>No utilizar un aparato de la red sin cable cerca de un detonador que no esté protegido ni tampoco en un entorno explosivo a menos que el aparato haya sido modificado con ese fin.</b>
<b>Varning!</b>	<b>Använd inte den trådlösa nätverksenheten i närheten av oskyddade tändhättar eller i en explosiv miljö om inte enheten modifierats för att kunna användas i sådana sammanhang.</b>

---

# Lightning Activity Warning




---

<b>Warning</b>	<b>Do not work on the system or connect or disconnect cables during periods of lightning activity.</b>
<b>Waarschuwing</b>	<b>Tijdens onweer dat gepaard gaat met bliksem, dient u niet aan het systeem te werken of kabels aan te sluiten of te ontkoppelen.</b>
<b>Varoitus</b>	<b>Älä työskentele järjestelmän parissa äläkä yhdistä tai irrota kaapeleita ukkosilmalla.</b>
<b>Attention</b>	<b>Ne pas travailler sur le système ni brancher ou débrancher les câbles pendant un orage.</b>
<b>Warnung</b>	<b>Arbeiten Sie nicht am System und schließen Sie keine Kabel an bzw. trennen Sie keine ab, wenn es gewittert.</b>
<b>Avvertenza</b>	<b>Non lavorare sul sistema o collegare oppure scollegare i cavi durante un temporale con fulmini.</b>
<b>Advarsel</b>	<b>Utfør aldri arbeid på systemet, eller koble kabler til eller fra systemet når det tordner eller lyner.</b>
<b>Aviso</b>	<b>Não trabalhe no sistema ou ligue e desligue cabos durante períodos de mau tempo (trovoada).</b>
<b>¡Advertencia!</b>	<b>No operar el sistema ni conectar o desconectar cables durante el transcurso de descargas eléctricas en la atmósfera.</b>
<b>Varning!</b>	<b>Vid åska skall du aldrig utföra arbete på systemet eller ansluta eller koppla loss kablar.</b>

---

## Installation Warning



<b>Warning</b>	<b>Read the installation instructions before you connect the system to its power source.</b>
<b>Waarschuwing</b>	<b>Raadpleeg de installatie-aanwijzingen voordat u het systeem met de voeding verbindt.</b>
<b>Varoitus</b>	<b>Lue asennusohjeet ennen järjestelmän yhdistämistä virtalähteeseen.</b>
<b>Attention</b>	<b>Avant de brancher le système sur la source d'alimentation, consulter les directives d'installation.</b>
<b>Warnung</b>	<b>Lesen Sie die Installationsanweisungen, bevor Sie das System an die Stromquelle anschließen.</b>
<b>Avvertenza</b>	<b>Consultare le istruzioni di installazione prima di collegare il sistema all'alimentatore.</b>
<b>Advarsel</b>	<b>Les installasjonsinstruksjonene før systemet kobles til strømkilden.</b>
<b>Aviso</b>	<b>Leia as instruções de instalação antes de ligar o sistema à sua fonte de energia.</b>
<b>¡Advertencia!</b>	<b>Ver las instrucciones de instalación antes de conectar el sistema a la red de alimentación.</b>
<b>Varning!</b>	<b>Läs installationsanvisningarna innan du kopplar systemet till dess strömförsörjningsenhet.</b>

## Circuit Breaker (15A) Warning



<b>Warning</b>	<b>This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that a fuse or circuit breaker no larger than 120 VAC, 15A U.S. (240 VAC, 10A international) is used on the phase conductors (all current-carrying conductors).</b>
<b>Waarschuwing</b>	<b>Dit produkt is afhankelijk van de installatie van het gebouw voor kortsluit- (overstroom)beveiliging. Controleer of er een zekering of stroomverbreker van niet meer dan 120 Volt wisselstroom, 15 A voor de V.S. (240 Volt wisselstroom, 10 A internationaal) gebruikt wordt op de fasegeleiders (alle geleiders die stroom voeren).</b>
<b>Varoitus</b>	<b>Tämä tuote on riippuvainen rakennukseen asennetusta oikosulkusuojauksesta (ylivirtasuojauksesta). Varmista, että vaihevirtajohtimissa (kaikissa virroitetuissa johtimissa) käytetään Yhdysvalloissa alle 120 voltin, 15 ampeerin ja monissa muissa maissa 240 voltin, 10 ampeerin sulaketta tai suojakytkintä.</b>
<b>Attention</b>	<b>Pour ce qui est de la protection contre les courts-circuits (surtension), ce produit dépend de l'installation électrique du local. Vérifier qu'un fusible ou qu'un disjoncteur de 120 V alt., 15 A U.S. maximum (240 V alt., 10 A international) est utilisé sur les conducteurs de phase (conducteurs de charge).</b>

<b>Warnung</b>	<b>Dieses Produkt ist darauf angewiesen, daß im Gebäude ein Kurzschluß- bzw. Überstromschutz installiert ist. Stellen Sie sicher, daß eine Sicherung oder ein Unterbrecher von nicht mehr als 240 V Wechselstrom, 10 A (bzw. in den USA 120 V Wechselstrom, 15 A) an den Phasenleitern (allen stromführenden Leitern) verwendet wird.</b>
<b>Avvertenza</b>	<b>Questo prodotto dipende dall'installazione dell'edificio per quanto riguarda la protezione contro cortocircuiti (sovracorrente). Verificare che un fusibile o interruttore automatico, non superiore a 120 VCA, 15 A U.S. (240 VCA, 10 A internazionale) sia stato usato nei fili di fase (tutti i conduttori portatori di corrente).</b>
<b>Advarsel</b>	<b>Dette produktet er avhengig av bygningens installasjoner av kortslutningsbeskyttelse (overstrøm). Kontroller at det brukes en sikring eller strømbryter som ikke er større enn 120 VAC, 15 A (USA) (240 VAC, 10 A internasjonalt) på faselederne (alle strømførende ledere).</b>
<b>Aviso</b>	<b>Este produto depende das instalações existentes para protecção contra curto-circuito (sobrecarga). Assegure-se de que um fusível ou disjuntor não superior a 240 VAC, 10A é utilizado nos condutores de fase (todos os condutores de transporte de corrente).</b>
<b>¡Advertencia!</b>	<b>Este equipo utiliza el sistema de protección contra cortocircuitos (o sobrecorrientes) del propio edificio. Asegurarse de que se utiliza un fusible o interruptor automático de no más de 240 voltios en corriente alterna (VAC), 10 amperios del estándar internacional (120 VAC, 15 amperios del estándar USA) en los hilos de fase (todos aquellos portadores de corriente).</b>
<b>Varning!</b>	<b>Denna produkt är beroende av i byggnaden installerat kortslutningsskydd (överströmsskydd). Kontrollera att säkring eller överspänningsskydd används på fasledarna (samtliga strömförande ledare) för internationellt bruk max. 240 V växelström, 10 A (i USA max. 120 V växelström, 15 A).</b>



## Declarations of Conformity and Regulatory Information

---

This appendix provides declarations of conformity and regulatory information for the Cisco Aironet 1100 Series Access Points.

This appendix contains the following sections:

- [Manufacturers Federal Communication Commission Declaration of Conformity Statement, page B-2](#)
- [Department of Communications—Canada, page B-2](#)
- [European Community, Switzerland, Norway, Iceland, and Liechtenstein, page B-3](#)
- [Declaration of Conformity for RF Exposure, page B-4](#)
- [Guidelines for Operating Cisco Aironet Access Points and Bridges in Japan, page B-5](#)

# Manufacturers Federal Communication Commission Declaration of Conformity Statement



**Models:** AIR-AP1120B  
**FCC Certification number:** LDK 102042 (AIR-MPI350)  
**Manufacturer:** Cisco Systems, Inc.  
 170 West Tasman Drive  
 San Jose, CA 95134-1706  
 USA

This device complies with Part 15 rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates, uses, and radiates radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference. However, there is no guarantee that interference will not occur. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician.



## Caution

---

The Part 15 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Cisco could void the user's authority to operate this device.

---

## Department of Communications—Canada

### Canadian Compliance Statement

This Class B Digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment Regulations.



Cet appareil numérique de la classe B respecte les exigences du Règlement sur le matériel brouilleur du Canada.

This device complies with Class B Limits of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

The device is certified to the requirements of RSS-139-1 and RSS-210 for 2.4-GHz spread spectrum devices. The use of this device in a system operating either partially or completely outdoors may require the user to obtain a license for the system according to the Canadian regulations. For further information, contact your local Industry Canada office.

## European Community, Switzerland, Norway, Iceland, and Liechtenstein

### Declaration of Conformity with Regard to the R&TTE Directive 1999/5/EC

English:	This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Deutsch:	Dieses Gerät entspricht den grundlegenden Anforderungen und den weiteren entsprechenden Vorgaben der Richtlinie 1999/5/EU.
Dansk:	Dette udstyr er i overensstemmelse med de væsentlige krav og andre relevante bestemmelser i Direktiv 1999/5/EF.
Español:	Este equipo cumple con los requisitos esenciales así como con otras disposiciones de la Directiva 1999/5/EC.
Έλληνας:	Αυτός ο εξοπλισμός συμμορφώνεται με τις ουσιώδεις απαιτήσεις και τις λοιπές διατάξεις της Οδηγίας 1999/5/EK.
Français:	Cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la Directive 1999/5/EC.
Íslenska:	Þessi búnaður samrýmist lögboðnum kröfum og öðrum ákvæðum tilskipunar 1999/5/ESB.
Italiano:	Questo apparato é conforme ai requisiti essenziali ed agli altri principi sanciti dalla Direttiva 1999/5/EC.
Nederlands:	Deze apparatuur voldoet aan de belangrijkste eisen en andere voorzieningen van richtlijn 1999/5/EC.
Norsk:	Dette utstyret er i samsvar med de grunnleggende krav og andre relevante bestemmelser i EU-direktiv 1999/5/EC.

Português:	Este equipamento satisfaz os requisitos essenciais e outras provisões da Directiva 1999/5/EC.
Suomalainen:	Tämä laite täyttää direktiivin 1999/5/EY oleelliset vaatimukset ja on siinä asetettujen muidenkin ehtojen mukainen.
Svenska:	Denna utrustning är i överensstämmelse med de väsentliga kraven och andra relevanta bestämmelser i Direktiv 1999/5/EC.

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The Declaration of Conformity related to this product can be found at the following URL:

<http://www.ciscofax.com>

For the 1100 series access point, the following standards were applied:

- Radio: EN 300.328-1, EN 300.328-2
- EMC: EN 301 489-1, EN 301 489-17
- Safety: EN 60950

The following CE mark is affixed to the 1100 series equipment:



The above CE mark is required as of April 8, 2000 but might change in the future.



**Note**

This equipment is intended to be used in all EU and EFTA countries. Outdoor use may be restricted to certain frequencies and/or may require a license for operation. For more details, contact Cisco Corporate Compliance.



**Note**

Combinations of power levels and antennas resulting in a radiated power level of above 100 mW eirp are considered as not compliant with the above mentioned directive and are not allowed for use within the European community and countries that have adopted the European R&TTE directive 1999/5/EC and/or the CEPT recommendation Rec 70.03. For more details on legal combinations of power levels and antennas, contact Cisco Corporate Compliance.

## Declaration of Conformity for RF Exposure

The radio module has been evaluated under FCC Bulletin OET 65C and found compliant to the requirements as set forth in CFR 47 Sections 2.1091, 2.1093, and 15.247 (b) (4) addressing RF Exposure from radio frequency devices. The access point should be installed more than 20 cm from your body or nearby persons.

# Guidelines for Operating Cisco Aironet Access Points and Bridges in Japan

This section provides guidelines for avoiding interference when operating Cisco Aironet access points and bridges in Japan. These guidelines are provided in both Japanese and English.

## Japanese Translation

この機器の使用周波数帯では、電子レンジ等の産業・科学・医療用機器のほか工場の製造ライン等で使用されている移動体識別用の構内無線局（免許を要する無線局）及び特定小電力無線局（免許を要しない無線局）が運用されています。

- 1 この機器を使用する前に、近くで移動体識別用の構内無線局及び特定小電力無線局が運用されていないことを確認して下さい。
- 2 万一、この機器から移動体識別用の構内無線局に対して電波干渉の事例が発生した場合には、速やかに使用周波数を変更するか又は電波の発射を停止した上、下記連絡先にご連絡頂き、混信回避のための処置等(例えば、パーティションの設置など)についてご相談して下さい。
- 3 その他、この機器から移動体識別用の特定小電力無線局に対して電波干渉の事例が発生した場合など何かお困りのことが起きたときは、次の連絡先へお問い合わせ下さい。

連絡先 : 03-5549-6500

43768

## English Translation

This equipment operates in the same frequency bandwidth as industrial, scientific, and medical devices such as microwave ovens and mobile object identification (RF-ID) systems (licensed premises radio stations and unlicensed specified low-power radio stations) used in factory production lines.

1. Before using this equipment, make sure that no premises radio stations or specified low-power radio stations of RF-ID are used in the vicinity.
2. If this equipment causes RF interference to a premises radio station of RF-ID, promptly change the frequency or stop using the device; contact the number below and ask for recommendations on avoiding radio interference, such as setting partitions.
3. If this equipment causes RF interference to a specified low-power radio station of RF-ID, contact the number below.

Contact Number: 03-5549-6500





## Channels and Antenna Settings

---

This appendix lists the access point radio channels and the maximum power levels supported by the world's regulatory domains.

The following topics are covered in this appendix:

- [Channels, page C-2](#)
- [Maximum Power Levels, page C-3](#)

# Channels

The channel identifiers, channel center frequencies, and regulatory domains of each 22-MHz-wide channel are shown in [Table C-1](#).

**Table C-1 Channels**

Channel Identifier	Center Frequency (MHz)	Regulatory Domains			
		Americas (-A)	EMEA (-E)	Japan (-J)	Israel (-I)
1	2412	X	X	X	-
2	2417	X	X	X	-
3	2422	X	X	X	X
4	2427	X	X	X	X
5	2432	X	X	X	X
6	2437	X	X	X	X
7	2442	X	X	X	X
8	2447	X	X	X	X
9	2452	X	X	X	X
10	2457	X	X	X	-
11	2462	X	X	X	-
12	2467	-	X	X	-
13	2472	-	X	X	-
14	2484	-	-	X	-

For additional information, refer to the [“Configuring Radio Channel Settings”](#) section on page 7-6.



**Note**

Mexico is included in the Americas regulatory domain; however, channels 1 through 8 are for indoor use only while channels 9 through 13 can be used indoors and outdoors with up to 650mW EIRP. Users are responsible for ensuring that the channel set configuration is in compliance with the regulatory standards of Mexico.



**Note**

France is included in the ETSI regulatory domain; however, channels 1 through 9 can be used with up to 10 mW EIRP and channels 10 through 13 can be used with up to 100mW EIRP. Users are responsible for ensuring that the channel set configuration is in compliance with the regulatory standards of France.

# Maximum Power Levels

An improper power level setting can result in equivalent isotropic radiated power (EIRP) above the amount allowed per regulatory domain. [Table C-2](#) indicates the access point's maximum power level allowed for each regulatory domain. For additional information, refer to [“Configuring Radio Transmit Power” section on page 7-5](#).

**Table C-2 Maximum Power Levels**

Regulatory Domain	Antenna Gain (dBi)	Maximum Power Level (mW)
Americas (-A) (4 watts EIRP maximum)	2.2	100
EMEA (-E) (100 mW EIRP maximum)	2.2	50
Japan (-J) (10 mW/MHz EIRP maximum)	2.2	30
Israel (-I) (100 mW EIRP maximum)	2.2	50



**Note**

France is included in the ETSI regulatory domain; however, channels 1 through 9 can be used with up to 10mW EIRP and channels 10 through 13 can be used with up to 100mW EIRP. Users are responsible for ensuring that the channel set configuration is in compliance with the regulatory standards of France.



**Note**

Mexico is included in the Americas regulatory domain; however, channels 1 through 8 are for indoor use only while channels 9 through 13 can be used indoors and outdoors with up to 650mW EIRP. Users are responsible for ensuring that the channel set configuration is in compliance with the regulatory standards of Mexico.







## Mounting Instructions

---

This appendix contains mounting instructions for the access point and contains the following topics:

- [Overview, page D-2](#)
- [Mounting on a Horizontal or Vertical Surface, page D-3](#)
- [Mounting on a Suspended Ceiling, page D-4](#)
- [Using the Security Hasp Adapter, page D-6](#)
- [Mounting on a Cubical Wall Partition, page D-7](#)
- [Using the Desktop Holster, page D-8](#)
- [Using the Cable Lock Feature, page D-9](#)

# Overview

The mounting brackets and hardware shipped with your access point enables you to mount it on any of the following surfaces:

- Horizontal or vertical flat surfaces, such as walls or ceilings
- Suspended ceilings
- Cubical partition walls
- Desktop or other suitable horizontal surface

The 1100 series access point provides adequate fire resistance and low smoke-producing characteristics suitable for operation in a building's environmental air space, such as above suspended ceilings, in accordance with Section 300-22(C) of the National Electrical Code (NEC) and Sections 2-128, 12-010(3) and 12-100 of the Canadian Electrical Code, Part 1, C22.1.



**Caution** Cisco Aironet 1100 Series Power Injectors and the universal power supplies are not tested to UL 2043 and should not be placed in a building's air-handling spaces, such as above suspended ceilings.

Security features for each of these mounting methods are also provided. You can use a Kensington lock (Notebook Microstar, model number 64068), which you must provide, to make the access point more secure when you mount it using any of the mounting options.

You can use the security hasp adapter, provided by Cisco, to secure the access point with a padlock when you use the wall or ceiling mounting bracket. The security hasp adapter provides maximum physical security for your access point.


A mounting hardware kit is provided that contains the hardware and fasteners necessary to mount the access point. Refer to [Table D-1](#) to identify the materials you need to mount your access point, then go to the section containing the specific mounting procedure.

**Table D-1 Mounting Material**

Mounting Method	Materials Required	In Kit
Horizontal or vertical surface	Wall or ceiling mounting bracket	Yes
	Security hasp adapter	Yes
	Four #8 x 1 in. (25.4 mm) screws	Yes
	Four wall anchors	Yes
	3/16 in. (4.7 mm) or 3/32 in. (2.3 mm) drill bit	No
	Drill	No
Suspended ceiling	Wall or ceiling mounting bracket	Yes
	Security hasp adapter	Yes
	Two caddy fasteners with studs	Yes
	Two plastic spacers	Yes
	Two 1/4–20 Keps nuts	Yes
	Standard screwdriver	No
Appropriate wrench or pliers	No	
Office cubical wall partition	Cubical partition mounting bracket assembly	Yes
Desktop	Desktop holster	Yes

The wall or ceiling mounting bracket also serves as a template for transferring the location of the bracket's mounting holes to the mounting surface. Refer to [Figure D-1](#) to locate the various mounting holes for the method you intend to use.

**Figure D-1 Mounting Bracket**



<b>1</b>	Security hasp	<b>3</b>	Suspended ceiling mount holes
<b>2</b>	Access point mounting rail	<b>4</b>	Wall mount holes

## Mounting on a Horizontal or Vertical Surface

Follow these steps to mount the access point on a horizontal or vertical surface, such as a ceiling or wall.

**Step 1** Use the wall or ceiling mounting bracket as a template to mark the locations of the mounting holes.

- You can use any of the 10 holes around the periphery (three of which are identified in the illustration) of the bracket to mount it using the supplied #8 fasteners.

**Step 2** Drill one of the following sized holes at the locations you marked:

- 3/16 in. (4.7 mm) if you are using wall anchors
- 3/32 in. (2.3 mm) if you are not using wall anchors

**Step 3** Install the anchors into the wall if you are using them. Otherwise, go to Step 4.

**Step 4** Secure the mounting bracket to the surface using the #8 fasteners.




**Note** On a vertical surface, be sure to mount the bracket with its security hasp facing down.

**Step 5** Line up the mounting slots on the access point with the mounting rail on the mounting bracket and slide down the mounting rails until it clicks into place.

# Mounting on a Suspended Ceiling

Follow these steps to mount your access point on a suspended ceiling. It may be helpful to refer to [Figure D-2](#) before beginning the process.

**Figure D-2** Suspended Ceiling Mounting Bracket Parts




1	Suspended ceiling T-rail	4	Wall or ceiling mounting bracket
2	Caddy fastener	5	Keps nut
3	Plastic spacer		

- Step 1** Determine the location at which to mount the access point.
- Step 2** Attach two caddy fasteners to the ceiling's T-rail.
- Step 3** Use the wall or ceiling mounting bracket to adjust the distance between the caddy fasteners so that they align with the holes in the bracket.
  - The distance between the caddy fastener studs is 2.5 in (6.35 cm).
- Step 4** Use a standard screwdriver to tighten the caddy fastener studs in place on the T-rail. Do not overtighten.
- Step 5** Install a plastic spacer on each caddy fastener stud. The spacer's legs should contact the ceiling grid T-rail.
- Step 6** Attach the wall or ceiling mounting bracket to the caddy fastener studs and start a Keps nut on each stud.
- Step 7** Use a wrench or pliers to tighten the Keps nuts. Do not overtighten.

- Step 8** Line up the mounting slots on the access point with the mounting rail on the wall or ceiling mounting bracket and slide it down the mounting rails until it clicks into place. See [Figure D-3](#).

**Figure D-3 Access Point Mounting Slots**




## Using the Security Hasp Adapter

The security hasp on the wall or ceiling mounting bracket and the security hasp adapter locks the access point to the bracket to make it more secure. After you have installed the access point on the detachable mounting bracket, follow these steps to secure it with a padlock (Master Lock model 120T, 121T or equivalent).

- 
- Step 1** Connect the Ethernet cable and power jack.
  - Step 2** Insert the T-shaped tab on the security hasp adapter into the Kensington lock slot on the access point. See [Figure D-4](#).


**Figure D-4 Security Hasp Adapter**



81177

- Step 3** Rotate the adapter to engage it with the security hasp. The hole in the adapter should be aligned with the hole in the security hasp.
- Step 4** Secure the adapter to the security hasp with a padlock. Your installation will look similar to [Figure D-5](#).

**Figure D-5 Security Hasp with Padlock**




81176

# Mounting on a Cubical Wall Partition

Follow these steps to mount the access point on a cubical wall partition.

- Step 1** Select the place on the partition where you want to mount the access point.
- Step 2** Determine the width of the partition you going to mount the access point on.
- Step 3** Assemble the cubical partition mounting bracket by sliding the two pieces together. You can use either the short or long part of the bracket to obtain the proper fit to the partition wall.
  - The bracket is adjustable from 2.125 in. (5.39 cm) to 4.25 in. (10.79 cm).
- Step 4** Connect the Ethernet and power cables.
- Step 5** Line up the mounting slots on the access point with the mounting rails on the cubical partition mounting bracket and slide it down the rails until it clicks into place.
- Step 6** Position the mounting bracket over the partition wall and adjust it to fit. See [Figure D-6](#).

**Figure D-6** Cubicle Wall Bracket




## Using the Desktop Holster

Follow these steps to mount the access point on a desktop or other horizontal surface using the supplied desktop holster.

- 
- Step 1** Select a suitable location to place the holster.
- Step 2** Connect the Ethernet and power cables.
- If you are going to secure the access point with a Kensington lock, attach it now.
- Step 3** Position the holster so that its back side is facing you.
- Step 4** Insert the access point into the holster while guiding the cables so that they do not interfere with the sides of the holster. You will hear a click when the access point locks into place. See [Figure D-7](#).

**Figure D-7** Desktop Holster





## Using the Cable Lock Feature

When you mount the access point using the cubical partition mount or desktop holster, you can secure the access point with your own security cable. Follow these steps to install the security cable.


**Note**

Cisco recommends using a Kensington Notebook Microstar (model number 64068) to secure your access point.

- Step 1** Loop the security cable around a nearby immovable object.
- Step 2** Insert the key into the lock.
- Step 3** Insert the lock into the security slot on the access point.
- Step 4** Rotate the key right or left to secure the lock to the access point.
- Step 5** Remove the key.

A properly secured lock and cable look similar to [Figure D-8](#).

**Figure D-8** Kensington Lock







## Protocol Filters

---

The tables in this appendix list some of the protocols that you can filter on the access point. The tables include:

- Table E-1, [Ethernet Protocols](#)
- Table E-2, [IP Protocols](#)
- Table E-3, [IP Port Protocols](#)

In each table, the Protocol column lists the protocol name, the Additional Identifier column lists other names for the same protocol, and the ISO Designator column lists the numeric designator for each protocol.

**Table E-1 Ethertype Protocols**

<b>Protocol</b>	<b>Additional Identifier</b>	<b>ISO Designator</b>
ARP	—	0x0806
RARP	—	0x8035
IP	—	0x0800
Berkeley Trailer Negotiation	—	0x1000
LAN Test	—	0x0708
X.25 Level3	X.25	0x0805
Banyan	—	0x0BAD
CDP	—	0x2000
DEC XNS	XNS	0x6000
DEC MOP Dump/Load	—	0x6001
DEC MOP	MOP	0x6002
DEC LAT	LAT	0x6004
Ethertalk	—	0x809B
Appletalk ARP	Appletalk AARP	0x80F3
IPX 802.2	—	0x00E0
IPX 802.3	—	0x00FF
Novell IPX (old)	—	0x8137
Novell IPX (new)	IPX	0x8138
EAPOL (old)	—	0x8180
EAPOL (new)	—	0x888E
Telxon TXP	TXP	0x8729
Aironet DDP	DDP	0x872D
Enet Config Test	—	0x9000
NetBUI	—	0xF0F0

**Table E-2 IP Protocols**

<b>Protocol</b>	<b>Additional Identifier</b>	<b>ISO Designator</b>
dummy	—	0
Internet Control Message Protocol	ICMP	1
Internet Group Management Protocol	IGMP	2
Transmission Control Protocol	TCP	6
Exterior Gateway Protocol	EGP	8
PUP	—	12
CHAOS	—	16
User Datagram Protocol	UDP	17
XNS-IDP	IDP	22
ISO-TP4	TP4	29
ISO-CNLP	CNLP	80
Banyan VINES	VINES	83
Encapsulation Header	encap_hdr	98
Spectralink Voice Protocol	SVP Spectralink	119
raw	—	255

**Table E-3 IP Port Protocols**

<b>Protocol</b>	<b>Additional Identifier</b>	<b>ISO Designator</b>
TCP port service multiplexer	tcpmux	1
echo	—	7
discard (9)	—	9
systat (11)	—	11
daytime (13)	—	13
netstat (15)	—	15
Quote of the Day	qotd quote	17
Message Send Protocol	misp	18
ttytst source	chargen	19
FTP Data	ftp-data	20
FTP Control (21)	ftp	21
Secure Shell (22)	ssh	22
Telnet	—	23
Simple Mail Transport Protocol	SMTP mail	25
time	timserver	37
Resource Location Protocol	RLP	39
IEN 116 Name Server	name	42
whois	nickname 43	43
Domain Name Server	DNS domain	53
MTP	—	57
BOOTP Server	—	67
BOOTP Client	—	68
TFTP	—	69
gopher	—	70
rje	netrjs	77
finger	—	79
Hypertext Transport Protocol	HTTP www	80
ttylink	link	87
Kerberos v5	Kerberos krb5	88
supdup	—	95
hostname	hostnames	101

**Table E-3 IP Port Protocols (continued)**

<b>Protocol</b>	<b>Additional Identifier</b>	<b>ISO Designator</b>
TSAP	iso-tsap	102
CSO Name Server	cso-ns csnet-ns	105
Remote Telnet	rtelnet	107
Postoffice v2	POP2 POP v2	109
Postoffice v3	POP3 POP v3	110
Sun RPC	sunrpc	111
tap ident authentication	auth	113
sftp	—	115
uucp-path	—	117
Network News Transfer Protocol	Network News readnews nntp	119
USENET News Transfer Protocol	Network News readnews nntp	119
Network Time Protocol	nntp	123
NETBIOS Name Service	netbios-ns	137
NETBIOS Datagram Service	netbios-dgm	138
NETBIOS Session Service	netbios-ssn	139
Interim Mail Access Protocol v2	Interim Mail Access Protocol IMAP2	143
Simple Network Management Protocol	SNMP	161
SNMP Traps	snmp-trap	162
ISO CMIP Management Over IP	CMIP Management Over IP cmip-man CMOT	163
ISO CMIP Agent Over IP	cmip-agent	164
X Display Manager Control Protocol	xdmcp	177
NeXTStep Window Server	NeXTStep	178
Border Gateway Protocol	BGP	179
Prospero	—	191
Internet Relay Chap	IRC	194

**Table E-3 IP Port Protocols (continued)**

<b>Protocol</b>	<b>Additional Identifier</b>	<b>ISO Designator</b>
SNMP Unix Multiplexer	smux	199
AppleTalk Routing	at-rtmp	201
AppleTalk name binding	at-nbp	202
AppleTalk echo	at-echo	204
AppleTalk Zone Information	at-zis	206
NISO Z39.50 database	z3950	210
IPX	—	213
Interactive Mail Access Protocol v3	imap3	220
Unix Listserv	ulistserv	372
syslog	—	514
Unix spooler	spooler	515
talk	—	517
ntalk	—	518
route	RIP	520
timeserver	timed	525
newdate	tempo	526
courier	RPC	530
conference	chat	531
netnews	—	532
netwall	wall	533
UUCP Daemon	UUCP uucpd	540
Kerberos rlogin	klogin	543
Kerberos rsh	kshell	544
rfs_server	remotefs	556
Kerberos kadmin	kerberos-adm	749
network dictionary	webster	765
SUP server	supfilesrv	871
swat for SAMBA	swat	901
SUP debugging	supfiledbg	1127
ingreslock	—	1524
Prospero non-privileged	prospero-np	1525
RADIUS	—	1812
Concurrent Versions System	CVS	2401
Cisco IAPP	—	2887
Radio Free Ethernet	RFE	5002





## Supported MIBs

---

This appendix lists the Simple Network Management Protocol (SNMP) Management Information Bases (MIBs) that the access point supports for this software release. The Cisco IOS SNMP agent supports both SNMPv1 and SNMPv2. This appendix contains these sections:

- [MIB List, page F-1](#)
- [Using FTP to Access the MIB Files, page F-2](#)

### MIB List

- IEEE802dot11-MIB
- Q-BRIDGE-MIB
- P-BRIDGE-MIB
- CISCO-DOT11-IF-MIB
- CISCO-WLAN-VLAN-MIB
- CISCO-IETF-DOT11-QOS-MIB
- CISCO-IETF-DOT11-QOS-EXT-MIB
- CISCO-DOT11-ASSOCIATION-MIB
- CISCO-L2-DEV-MONITORING-MIB
- CISCO-DDP-IAPP-MIB
- CISCO-IP-PROTOCOL-FILTER-MIB
- CISCO-SYSLOG-EVENT-EXT-MIB
- CISCO-TBRIDGE-DEV-IF-MIB
- BRIDGE-MIB
- CISCO-CDP-MIB
- CISCO-CONFIG-COPY-MIB
- CISCO-CONFIG-MAN-MIB
- CISCO-FLASH-MIB
- CISCO-IMAGE-MIB
- CISCO-MEMORY-POOL-MIB

- CISCO-PROCESS-MIB
- CISCO-PRODUCTS-MIB
- CISCO-SMI-MIB
- CISCO-TC-MIB
- CISCO-SYSLOG-MIB
- ENTITY-MIB
- IF-MIB
- OLD-CISCO-CHASSIS-MIB
- OLD-CISCO-SYS-MIB
- OLD-CISCO-SYSTEM-MIB
- OLD-CISCO-TS-MIB
- RFC1213-MIB
- RFC1398-MIB
- SNMPv2-MIB
- SNMPv2-SMI
- SNMPv2-TC

## Using FTP to Access the MIB Files

Follow these steps to obtain each MIB file by using FTP:

- 
- Step 1** Use FTP to access the server **ftp.cisco.com**.
- Step 2** Log in with the username **anonymous**.
- Step 3** Enter your e-mail username when prompted for the password.
- Step 4** At the `ftp>` prompt, change directories to **/pub/mibs/v1** or **/pub/mibs/v2**.
- Step 5** Use the **get *MIB\_filename*** command to obtain a copy of the MIB file.
- 

**Note**

You can also access information about MIBs on the Cisco web site:  
<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

---




## Access Point Specifications

This appendix provides technical specifications for the Cisco Aironet 1100 Series Access Point. [Table G-1](#) lists the technical specifications for the access point.

**Table G-1 Access Point Specifications**

Category	Specification
<b>Physical</b>	
Size	4.1 in. W x 1.5 in. D x 8.1 in. H 10.4 cm W x 3.8 cm D x 20.6 cm H
Status Indicators	Three indicators on the top panel: Ethernet traffic Status Radio traffic
Connectors	End panel (left to right): RJ-45 connector for 10/100 BASE-T Ethernet connections; power connector (for plug-in AC power module).
Input Voltage	48 VDC nominal. Operational up to 60 VDC. Voltage higher than 60 VDC can damage the unit.
Input Current	150 mA
Operating Temperature	32 to 104°F (0 to 40°C) for the access point 32 to 104°F (0 to 40°C) for the power injector
Storage Temperature	-40 to 185°F (-40 to 85°C) for access point
Weight	10.5 oz (297g) with 2.4-GHz radio

**Table G-1 Access Point Specifications (continued)**

Category	Specification
<b>Radio</b>	<b>2.4-GHz Radio</b>
Power Output	100, 50, 30, 20, 5, or 1 mW (Depending on the regulatory domain in which the access point is installed)
Frequency	2.400 to 2.497 GHz (Depending on the regulatory domain in which the access point is installed)
Range	Indoor: 150 ft (45 m) at 11 Mbps 400 ft (122 m) at 1 Mbps  Outdoor: 800 ft (244 m) at 11 Mbps 2000 ft (610 m) at 1 Mbps
Modulation	Direct Sequence Spread Spectrum (DSSS)
Data rates	1, 2, 5.5, and 11 Mbps
Antenna	A diversity system with two integrated 2.2 dBi dipole antennas.
Compliance	<p>Operates license-free under FCC Part 15 and complies as a Class B computing device. Complies with DOC regulations. Complies with the following: EN 300.328, FCC Part 15.107 and 15.109 Class B, ICES-003 Class B (Canada), EN 55022 Class B, AS/NZS 3548 Class B, VCCI Class B, EN 301.489-1 and -17, UL 60950, CSA 22.2 No. 60950, EN 60950, IEC 60950, VCCI, FCC Part 15.247, RSS-210, RSS-139-1, UL 2043, and others (see Appendix B).</p> <p>The 1100 Series access point provides adequate fire resistance and low smoke-producing characteristics suitable for operation in a building's environmental air space, such as above suspended ceilings, in accordance with Section 300-22(C) of the National Electrical Code (NEC) and Sections 2-128, 12-010(3) and 12-100 of the Canadian Electrical Code, Part 1, C22.1.</p> <p> <b>Caution</b> Cisco Aironet 1100 series power injectors and the universal power supplies are not tested to UL 2043 and should not be placed in a building's air-handling spaces, such as above suspended ceilings.</p>



## Error and Event Messages

This appendix lists the CLI error and event messages. [Table H-1](#) lists the errors and events and provides an explanation and recommended action for each message.

**Table H-1 Error and Event Messages**

Message	Explanation	Recommended Action
<b>Software Auto Upgrade Messages</b>		
SW_AUTO_UPGRADE-FATAL: Attempt to upgrade software failed, software on flash may be deleted. Please copy software into flash.	Auto upgrade of the software failed. The software on the flash may be deleted. Copy software into the flash.	Copy software before rebooting the unit.
SW_AUTO_UPGRADE-7-FAILURE: dhcp_client_start_stop failed	Auto upgrade of the software failed due to error in starting/stopping DHCP client process.	Copy the error message exactly as it appears and report it to your technical support representative.
SW_AUTO_UPGRADE-7-FAILURE: Failed to obtain ip addr from dhcp server	Auto upgrade of the software failed.	Copy the error message exactly as it appears and report it to your technical support representative.
SW_AUTO_UPGRADE-7-FAILURE: boot_file_pathent creation failed	Auto upgrade of the software failed due to error in creation of pathent (internal data structure).	Copy the error message exactly as it appears and report it to your technical support representative.
<b>Association Management Messages</b>		
DOT11-3-BADSTATE: [mac-address] [chars] [chars] -> [chars]	802.11 Association and management uses a table-driven state machine to keep track and transition an Association through various states. A state transition occurs when an Association receives one of many possible events. When this error occurs, it means that an Association received an event that it did not expect while in this state.	The system can continue but may lose the Association that generates this error. Copy the message exactly as it appears and report it to your technical service representative.
DOT11-6-ASSOC: Interface [interface], Station [char] [mac] Associated	A station associated to an access point.	None.
DOT11-6-ADD: Interface [interface], Station [mac] Associated to Parent [mac]	A station associated to an access point.	None.

Table H-1 Error and Event Messages (continued)

Message	Explanation	Recommended Action
DOT11-6-DISASSOC: Interface [interface], Deauthenticating Station [mac] [char]	A station disassociated from an access point.	None.
DOT11-6-ROAMED: Station [mac-address] Roamed to [mac-address]	A station has roamed to a new access point.	None.
<b>Proxy Mobile IP Subsystem Messages</b>		
PMIP-3-REG_FAIL: Mobile Node 10.4.1.3 mobile ip registration failed	When a mobile node (MN) moves to a foreign network, the access point registers the MN to its Home Agent. This message indicates that the registration failed.	Check for correct configuration of Mobile IP agents and the access point.
PMIP-3-REG_AUTH_FAIL: Mobile Node 10.4.1.3 registration failed due to authentication failure	When a mobile node (MN) moves to a foreign network, the access point registers the MN to its Home Agent. This message indicates that the registration failed because the HA or FA failed to authenticate each other or the MN.	Make sure the correct authentication information is configured on the Home Agent, the Foreign Agent, and the access point.
PMIP-3-REG_FA_FAIL: Mobile Node 10.4.1.3 registration failed due to Foreign Agent denial	When a Mobile node (MN) moves to a foreign network, the access point registers the MN to its Home Agent. This message indicates that the registration was denied by the Foreign Agent.	Make sure the correct authentication information is configured on the Home Agent, the Foreign Agent, and the access point.
PMIP-3-REG_HA_FAIL: Mobile Node 10.4.1.3 registration failed due to Home Agent denial	When a Mobile node (MN) moves to a foreign network, the access point registers the MN to its Home Agent. This message indicates that the registration was denied by the Home Agent.	Make sure the correct authentication information is configured on the Home Agent, the Foreign Agent, and the access point.
PMIP-3-AUTH_UNAVAIL: Authentication for 10.4.1.3 unavailable	Proxy Mobile IP failed to obtain the Mobile Node's authentication information either locally or from a AAA server.	Make sure the correct Mobile Node information is configured locally or on the AAA server.
PMIP-3-HAFA_UNAVAIL: No response from the Mobile IP Agent to our registration requests	Proxy Mobile IP failed to access the Home or Foreign Agent while trying to register the Mobile Node.	Make sure the HA or FA is not down or is network inaccessible. Also check that the subnet map information regarding the Home Agent is correct.
PMIP-6-HAFA_DOWN: Mobile IP Agent 10.4.1.1 is down or unavailable	Mobile IP Home or Foreign agent has gone down or is inaccessible to the access point.	Make sure there is at least one Home and Foreign Agent configured on that subnet and is accessible to the access point.
PMIP-3-AAP_UNAVAIL: Authoritative Access Point is unavailable	The authoritative access point cannot be reached to obtain the subnet map table.	Make sure all the access points have the same information regarding Authoritative and regular access points.
PMIP-6-START: Proxy Mobile IP services has started	Proxy Mobile IP service has started.	None.

Table H-1 Error and Event Messages (continued)

Message	Explanation	Recommended Action
PMIP-6-STOP: Proxy Mobile IP services have stopped	Proxy Mobile IP service has stopped.	None.
PMIP-6-REPEATER_STOP: AP is now operating as a repeater, disabling Proxy Mobile IP services	Proxy Mobile IP does not run on repeaters or workgroup bridges, and it is disabled automatically when the access point is in repeater mode.	None.
<b>Unzip Messages</b>		
SOAP-4-UNZIP_OVERFLOW: Failed to unzip flash:/c1100-k9w7-mx.122-3.6.JA1/html/level15/ap_xxx.htm.gz, exceeds maximum uncompressed html size	The HTTP server cannot retrieve a compressed file in response to an HTTP GET request because the size of the file is too large for the buffers used in the uncompression process.	Make sure file is a valid HTML page. If so, you'll have to copy an uncompressed version of the file into flash to retrieve it through HTTP.
<b>802.11 Subsystem Messages</b>		
DOT11-6-FREQ_INUSE: Radio frequency [int] is in use	When scanning for an unused frequency, the unit recognized another radio using the displayed frequency.	None.
DOT11-6-FREQ_USED: Radio frequency [int] selected	After scanning for an unused frequency, the unit selected the displayed frequency.	None.
DOT11-4-VERSION_MISMATCH: Require radio version [hex].[int], found version [hex].[int]	When starting the radio, the wrong firmware version was found. The radio will be loaded with the required version.	None.
DOT11-2-VERSION_INVALID: Unable to find required radio version [hex].[int]	When trying to reflash the radio firmware, the access point recognized that the radio firmware packaged with the IOS firmware had the incorrect version.	None.
DOT11-4-NO_SSID: No SSIDs configured, radio not started	All SSIDs were deleted from the configuration. At least one must be configured for the radio to run.	Configure at least one SSID on the access point.
DOT11-4-FLASHING_RADIO: Flashing the radio firmware ([chars])	The radio has been stopped to load new firmware.	None.
DOT11-2-NO_FIRMWARE: No radio firmware file ([chars]) was found	When trying to flash new firmware into the radio, the file for the radio was not found in the flash file system.	The wrong image has been loaded into the unit. Locate the correct image based on the type of radio used.
DOT11-2-BAD_FIRMWARE: Radio firmware file ([chars]) is invalid	When trying to flash new firmware into the radio, the file was found to be invalid.	Put the correct firmware image file in the place where the unit is looking.
DOT11-4-FLASH_RADIO_DONE: Flashing the radio firmware completed	The radio firmware flash is complete, and the radio will be restarted with the new firmware.	None.
DOT11-4-LINK_DOWN: Radio parent lost: [chars]	The connection to the parent access point was lost for the displayed reason. The unit will try to find a new parent access point.	None.

Table H-1 Error and Event Messages (continued)

Message	Explanation	Recommended Action
DOT11-4-CANT_ASSOC: Cannot associate: [chars]	The unit could not establish a connection to a parent access point for the displayed reason.	Check the configuration of both the parent access point and this unit to make sure the basic settings (SSID, WEP, and others) match.
<b>Inter-Access Point Protocol Messages</b>		
DOT11-6-ROAMED: Station [mac-address] Roamed to [mac-address]	A station has roamed to a new access point.	None.
DOT11-6-STANDBY_ACTIVE: Standby to Active, Reason = [chars] ([int])	The access point is transitioning from standby mode to active mode.	None.
DOT11-6-ROGUE_AP: Rogue AP [mac-address] reported. Reason: [chars]	A station has reported a potential rogue access point for the stated reason.	None.
SCHED-3-UNEXPECTEDMESSAGE: Unknown message [hex] received (ptr arg [hex], num arg [hex]).	A process can register to be notified when various events occur in the router. This message indicates that a process received a message from another process that it does not know how to handle.	Copy the error message exactly as it appears, and report it to your technical support representative.
SCHED-3-UNEXPECTEDEVENT: Process received unknown event (maj [hex], min [hex]).	A process can register to be notified when various events occur in the router. This message indicates that a process received an event that it did not know how to handle.	Copy the error message exactly as it appears, and report it to your technical support representative.





---

## A

- abbreviating commands [5-3](#)
- access point
  - security settings [10-9](#)
- access point image [21-6](#)
- accounting
  - with RADIUS [11-12](#)
- antenna
  - connectors [6-2](#)
  - warnings [A-1](#)
- Apply button [4-4](#)
- attributes, RADIUS
  - vendor-proprietary [11-14](#)
  - vendor-specific [11-13](#)
- authentication
  - local mode with AAA [6-12](#)
  - NTP associations [6-17](#)
  - RADIUS
    - key [11-5](#)
    - login [6-8, 11-7](#)
- authentication server
  - EAP [10-3, 11-2](#)
- authentication types
  - Network-EAP [10-3](#)
  - open [10-2](#)
  - shared key [10-3](#)
- authoritative time source, described [6-15](#)
- authorization
  - with RADIUS [6-11, 11-11](#)

---

## B

- Back button [4-4](#)
- banners
  - configuring
    - login [6-33](#)
    - message-of-the-day login [6-32](#)
  - default configuration [6-32](#)
  - when displayed [6-31](#)
- basic settings
  - checking [21-4](#)
- broadcast key rotation [9-1](#)

---

## C

- Cancel button [4-4](#)
- CDP
  - disabling for routing device [16-4](#)
  - enabling and disabling
    - on an interface [16-4](#)
  - monitoring [16-4](#)
- Cisco TAC [21-1](#)
- CiscoWorks 2000 [17-4](#)
- CLI
  - abbreviating commands [5-3](#)
  - command modes [5-2](#)
  - editing features
    - enabling and disabling [5-5](#)
    - keystroke editing [5-6](#)
    - wrapped lines [5-7](#)
  - error messages [5-4](#)
  - filtering command output [5-8](#)
  - getting help [5-3](#)

- history
  - changing the buffer size [5-4](#)
  - described [5-4](#)
  - disabling [5-5](#)
  - recalling commands [5-5](#)
- no and default forms of commands [5-3](#)
- clock
  - See system clock
- command-line interface
  - See CLI
- command modes [5-2](#)
- commands
  - abbreviating [5-3](#)
  - no and default [5-3](#)
  - setting privilege levels [6-6](#)
- community strings
  - configuring [17-5](#)
  - overview [17-3](#)
- compliance [G-2](#)
- configuration files
  - creating using a text editor [19-10](#)
  - deleting a stored configuration [19-18](#)
  - downloading
    - preparing [19-10, 19-13, 19-16](#)
    - reasons for [19-8](#)
    - using FTP [19-13](#)
    - using RCP [19-16](#)
    - using TFTP [19-11](#)
  - guidelines for creating and using [19-9](#)
  - invalid combinations when copying [19-5](#)
  - system contact and location information [17-9](#)
  - types and location [19-9](#)
  - uploading
    - preparing [19-10, 19-13, 19-16](#)
    - reasons for [19-8](#)
    - using FTP [19-14](#)
    - using RCP [19-17](#)
    - using TFTP [19-11](#)
- connections, secure remote [6-13](#)

- connectors [G-1, G-2](#)
- crypto software image [6-13](#)

---

## D

- data rates [G-2](#)
- daylight saving time [6-27](#)
- declarations of conformity [B-1](#)
- default
  - configuration, resetting [21-5](#)
- default commands [5-3](#)
- default configuration
  - banners [6-32](#)
  - DNS [6-30](#)
  - NTP [6-17](#)
  - password and privilege level [6-2](#)
  - RADIUS [6-8, 11-4](#)
  - SNMP [17-5](#)
  - system message logging [20-3](#)
  - system name and prompt [6-29](#)
- directories
  - changing [19-4](#)
  - creating and removing [19-4](#)
  - displaying the working [19-4](#)
- DNS
  - default configuration [6-30](#)
  - displaying the configuration [6-31](#)
  - overview [6-30](#)
  - setting up [6-30](#)
- domain names
  - DNS [6-30](#)
- Domain Name System
  - See DNS
- downloading
  - configuration files
    - preparing [19-10, 19-13, 19-16](#)
    - reasons for [19-8](#)
    - using FTP [19-13](#)
    - using RCP [19-16](#)

using TFTP [19-11](#)

#### image files

deleting old image [19-22](#)

preparing [19-20, 19-23, 19-27](#)

reasons for [19-18](#)

using FTP [19-24](#)

using RCP [19-29](#)

using TFTP [19-21](#)

## E

### EAP authentication

overview [10-3](#)

### EAP-MD5 authentication

setting on client and access point [10-10](#)

### EAP-SIM authentication

setting on client and access point [10-11](#)

### EAP-TLS authentication

setting on client and access point [10-10](#)

### editing features

enabling and disabling [5-5](#)

keystrokes used [5-6](#)

wrapped lines [5-7](#)

### EIRP, maximum [C-3](#)

enable password [6-4](#)

enable secret password [6-4](#)

encrypted software image [6-13](#)

encryption for passwords [6-4](#)

### error messages

during command entry [5-4](#)

setting the display destination device [20-5](#)

severity levels [20-7](#)

system message format [20-2](#)

Ethernet indicator [21-2](#)

extended temperature range [2-3](#)

## F

fallback role [7-3](#)

FCC Declaration of Conformity [B-2](#)

FCC Safety Compliance [2-2](#)

### files

copying [19-5](#)

deleting [19-5](#)

displaying the contents of [19-8](#)

#### tar

creating [19-6](#)

displaying the contents of [19-6](#)

extracting [19-7](#)

image file format [19-19](#)

### file system

displaying available file systems [19-2](#)

displaying file information [19-3](#)

local file system names [19-2](#)

network file system names [19-5](#)

setting the default [19-3](#)

### filtering

show and more command output [5-8](#)

Flash device, number of [19-2](#)

frequencies [C-2](#)

frequency range [G-2](#)

### FTP

accessing MIB files [F-2](#)

#### configuration files

downloading [19-13](#)

overview [19-12](#)

preparing the server [19-13](#)

uploading [19-14](#)

#### image files

deleting old image [19-26](#)

downloading [19-24](#)

preparing the server [19-23](#)

uploading [19-26](#)

**G**

get-bulk-request operation [17-3](#)  
 get-next-request operation [17-3, 17-4](#)  
 get-request operation [17-3, 17-4](#)  
 get-response operation [17-3](#)  
 global configuration mode [5-2](#)

**H**

help, for the command line [5-3](#)  
 history  
   changing the buffer size [5-4](#)  
   described [5-4](#)  
   disabling [5-5](#)  
   recalling commands [5-5](#)  
 history table, level and number of syslog messages [20-8](#)  
 Home button [4-3](#)

**I**

indicators [21-2](#)  
 input power [G-1](#)  
 installation guidelines [2-3](#)  
 interface configuration mode [5-2](#)  
 IP address, finding and setting [3-9](#)  
 IPSU [3-8](#)  
 ISO designators for protocols [E-1](#)

**K**

key features [1-2](#)

**L**

LEAP authentication  
   setting on client and access point [10-9](#)  
 LED indicators

Ethernet [21-2](#)  
   radio traffic [21-2](#)  
   status [21-2](#)  
 limiting client power level [7-5](#)  
 login authentication  
   with RADIUS [6-8, 11-7](#)  
 login banners [6-31](#)  
 log messages  
   See system message logging

**M**

MAC [3-9, 3-10](#)  
 management options  
   CLI [5-1](#)  
 Message Integrity Check [9-1](#)  
 messages  
   to users through banners [6-31](#)  
 MIBs  
   accessing files with FTP [F-2](#)  
   location of files [F-2](#)  
   overview [17-2](#)  
   SNMP interaction with [17-4](#)  
 MIC [9-1](#)  
 Mode button [21-6](#)  
 modulation [G-2](#)  
 monitoring  
   CDP [16-4](#)

**N**

Network-EAP [10-3](#)  
 Network Time Protocol  
   See NTP  
 no commands [5-3](#)  
 NTP  
   associations  
   authenticating [6-17](#)

- defined [6-15](#)
- enabling broadcast messages [6-20](#)
- peer [6-19](#)
- server [6-19](#)
- default configuration [6-17](#)
- displaying the configuration [6-24](#)
- overview [6-15](#)
- restricting access
  - creating an access group [6-22](#)
  - disabling NTP services per interface [6-23](#)
- source IP address, configuring [6-23](#)
- stratum [6-15](#)
- synchronizing devices [6-19](#)
- time
  - services [6-15](#)
  - synchronizing [6-15](#)

---

## O

- OK button [4-4](#)
- operating temperature [G-1](#)

---

## P

- package contents [2-3](#)
- password reset [21-5](#)
- passwords
  - default configuration [6-2](#)
  - encrypting [6-4](#)
  - overview [6-2](#)
  - setting
    - enable [6-3](#)
    - enable secret [6-4](#)
    - with usernames [6-5](#)
- PEAP authentication
  - setting on client and access point [10-10](#)
- power
  - connecting [2-5](#)

- injector [2-5](#)
- input [G-1](#)
- output [G-2](#)
- power level, maximum [C-3](#)
- preferential treatment of traffic
  - See QoS
- preventing unauthorized access [6-2](#)
- privileged EXEC mode [5-2](#)
- privilege levels
  - exiting [6-7](#)
  - logging into [6-7](#)
  - overview [6-2, 6-6](#)
  - setting a command with [6-6](#)

---

## Q

- QoS
  - configuration guidelines [13-4](#)
  - overview [13-2](#)
- quality of service
  - See QoS

---

## R

- radio
  - indicator [21-2](#)
  - specifications [G-2](#)
- RADIUS
  - attributes
    - vendor-proprietary [11-14](#)
    - vendor-specific [11-13](#)
  - configuring
    - accounting [11-12](#)
    - authentication [6-8, 11-7](#)
    - authorization [6-11, 11-11](#)
    - communication, global [11-5, 11-13](#)
    - communication, per-server [11-4, 11-5](#)
    - multiple UDP ports [11-5](#)

default configuration [6-8, 11-4](#)  
 defining AAA server groups [6-9, 11-9](#)  
 displaying the configuration [6-12, 11-15](#)  
 identifying the server [11-4](#)  
 limiting the services to the user [6-11, 11-11](#)  
 method list, defined [11-4](#)  
 operation of [11-2](#)  
 overview [11-2](#)  
 suggested network environments [11-2](#)  
 tracking services accessed by user [11-12](#)  
 range [G-2](#)  
 rate limit, logging [20-9](#)  
 RCP  
   configuration files  
     downloading [19-16](#)  
     overview [19-15](#)  
     preparing the server [19-16](#)  
     uploading [19-17](#)  
   image files  
     deleting old image [19-31](#)  
     downloading [19-29](#)  
     preparing the server [19-27](#)  
     uploading [19-31](#)  
 regulatory [B-1, G-2](#)  
   domains [C-2](#)  
 reloading access point image [21-6](#)  
 Remote Authentication Dial-In User Service  
   See RADIUS  
 Remote Copy Protocol  
   See RCP  
 repeater  
   chain of access points [18-2](#)  
 restricting access  
   NTP services [6-21](#)  
   overview [6-2](#)  
   passwords and privilege levels [6-2](#)  
   RADIUS [6-7, 11-1](#)  
 RFC  
   1157, SNMPv1 [17-2](#)

  1305, NTP [6-15](#)  
   1901, SNMPv2C [17-2](#)  
   1902 to 1907, SNMPv2 [17-2](#)  
 RF exposure [B-4](#)  
 roaming [1-5](#)  
 rotation, broadcast key [9-1](#)

---

## S

safety warnings, translated [A-1](#)  
 secure remote connections [6-13](#)  
 Secure Shell  
   See SSH  
 security features  
   synchronizing [10-9](#)  
 sequence numbers in log messages [20-6](#)  
 set-request operation [17-4](#)  
 severity levels, defining in system messages [20-7](#)  
 shared key [10-5](#)  
 show cdp traffic command [16-5](#)  
 Simple Network Management Protocol  
   See SNMP  
 size [G-1](#)  
 SNMP  
   accessing MIB variables with [17-4](#)  
   agent  
     described [17-3](#)  
     disabling [17-5](#)  
   community strings  
     configuring [17-5](#)  
     overview [17-3](#)  
   configuration examples [17-9](#)  
   default configuration [17-5](#)  
   limiting system log messages to NMS [20-8](#)  
   manager functions [17-3](#)  
   MIBs  
     location of [F-2](#)  
   overview [17-2, 17-4](#)  
   snmp-server view [17-9](#)

- status, displaying [17-10](#)
  - system contact and location [17-9](#)
  - trap manager, configuring [17-8](#)
  - traps
    - described [17-3](#)
    - enabling [17-7](#)
    - overview [17-2, 17-4](#)
    - types of [17-7](#)
    - versions supported [17-2](#)
  - software images
    - location in Flash [19-19](#)
    - tar file format, described [19-19](#)
  - SSH [5-9](#)
    - configuring [6-14](#)
    - crypto software image [6-13](#)
    - described [6-13](#)
    - displaying settings [6-14](#)
    - SSH Communications Security, Ltd. [5-9](#)
  - SSID
    - multiple SSIDs [8-1](#)
    - troubleshooting [21-4](#)
  - static WEP
    - with open authentication, setting on client and access point [10-9](#)
    - with shared key authentication, setting on client and access point [10-9](#)
  - statistics
    - CDP [16-4](#)
    - SNMP input and output [17-10](#)
  - status indicators [21-2, G-1](#)
  - storage temperature [G-1](#)
  - stratum, NTP [6-15](#)
  - summer time [6-27](#)
  - syslog
    - See system message logging
  - system clock
    - configuring
      - daylight saving time [6-27](#)
      - manually [6-25](#)
    - summer time [6-27](#)
    - time zones [6-26](#)
    - displaying the time and date [6-25](#)
    - overview [6-14](#)
    - See also NTP
  - system message logging
    - default configuration [20-3](#)
    - defining error message severity levels [20-7](#)
    - disabling [20-4](#)
    - displaying the configuration [20-11](#)
    - enabling [20-4](#)
    - facility keywords, described [20-11](#)
    - level keywords, described [20-7](#)
    - limiting messages [20-8](#)
    - message format [20-2](#)
    - overview [20-2](#)
    - rate limit [20-9](#)
    - sequence numbers, enabling and disabling [20-6](#)
    - setting the display destination device [20-5](#)
    - timestamps, enabling and disabling [20-6](#)
    - UNIX syslog servers
      - configuring the daemon [20-10](#)
      - configuring the logging facility [20-10](#)
      - facilities supported [20-11](#)
  - system name
    - default configuration [6-29](#)
    - manual configuration [6-29](#)
    - See also DNS
  - system prompt
    - default setting [6-29](#)
- 
- ## T
- TAC [21-1](#)
  - tar files
    - creating [19-6](#)
    - displaying the contents of [19-6](#)
    - extracting [19-7](#)
    - image file format [19-19](#)

Telnet [3-11](#)

temperature

- operating [G-1](#)
- storage [G-1](#)

Temporal Key Integrity Protocol [9-1](#)

TFTP

- configuration files
  - downloading [19-11](#)
  - preparing the server [19-10](#)
  - uploading [19-11](#)
- image files
  - deleting [19-22](#)
  - downloading [19-21](#)
  - preparing the server [19-20](#)
  - uploading [19-22](#)

TFTP server [21-6](#)

time

- See NTP and system clock

timestamps in log messages [20-6](#)

time zones [6-26](#)

TKIP [9-1](#)

traps

- configuring managers [17-7](#)
- defined [17-3](#)
- enabling [17-7](#)
- notification types [17-7](#)
- overview [17-2, 17-4](#)

troubleshooting [21-1](#)

- with CiscoWorks [17-4](#)
- with system message logging [20-2](#)

---

## U

UNIX syslog servers

- daemon configuration [20-10](#)
- facilities supported [20-11](#)
- message logging configuration [20-10](#)

unpacking [2-3](#)

upgrading software images

See downloading

uploading

- configuration files
  - preparing [19-10, 19-13, 19-16](#)
  - reasons for [19-8](#)
  - using FTP [19-14](#)
  - using RCP [19-17](#)
  - using TFTP [19-11](#)
- image files
  - preparing [19-20, 19-23, 19-27](#)
  - reasons for [19-18](#)
  - using FTP [19-26](#)
  - using RCP [19-31](#)
  - using TFTP [19-22](#)

user EXEC mode [5-2](#)

username-based authentication [6-5](#)

---

## V

voltage range [G-1](#)

---

## W

warnings [2-2, A-1](#)

Web-based interface

- common buttons [4-3](#)
- compatible browsers [4-1](#)

web site

- Cisco Software Center [3-8, 21-8](#)

weight [G-1](#)

WEP [9-1](#)

- with EAP [10-3](#)

WEP key [21-4](#)